


# 5 - SA1 CALC Cross-section

### Description

Calculates the cross-section distance with the separate input from the "leading system".

### Icon



#### Parameters



There are no parameters to set!

### Measured values for plotter



# Subgraphs interface

# IN bridges

# **OUT** bridges

<b></b> image	Img	<b></b> image	ROI preSeam
	ROI grey	☑ value	ROI preSeam X
Line	Line	value	ROI preSeam Y
	ROI grey X ROI grey Y ROI grey W ROI grey H ROI line valid		ROI preSeam W ROI preSeam H ROI preSeam valid Seam pos left Seam pos right

### ■ Graph block diagram

