`config/layers.json` and `config/rule_params.json` load into `adk_layers` and `drc_rules`; both must exist or the run aborts

`-rd manifest=...` parses into `boundary_manifest`; mandatory unless `legacy_exchange0`

`-rd adapter=...`; a missing or non-existent adapter aborts the run

`config/interconnect.json` loads into `interconnect_rules`; tolerated if absent

`layers_def.drc`

builds `chiplet_boundary`, one `RBA::Polygon` per manifest entry, or from the legacy `exchange0` layer in compat mode

<interposer adapter>

declares `chiplet_attachment_input`; MAY declare `wire_bond_pad_input`; MAY override `drc_rules`

generated validation

one `raise ... unless defined?(name) && !name.nil?` per `required_inputs` entry

`wire_bond_pads.drc`

the adapter's wire-bond pads, read from the carrier with every die cell pruned, or ASM.g not applicable

<interconnect adapter>

sets `interconnect_rules`; MAY narrow `interconnect_region`

generated IXN validation

raises unless `IXN_spacing`, `IXN_pitch` and `IXN_pad_size` are all present

`8_1_assembly.drc`

the ASM rules

`8_2_interconnect.drc`

the IXN rules

joined with newlines and evaluated once

`ALWAYS EVALUATED.`
With neither supplied, no interconnect segment is evaluated.

`APPENDED ONLY`
when an interconnect adapter and/or a per-method methods file is supplied; the adapter and its validation need an adapter, `8_2` needs either.

`ALWAYS EVALUATED`

`APPENDED ONLY`

All locals are shared.
`drc_rules`, `interconnect_rules`, `boundary_manifest` and `adk_layers` are wrapper locals the adapter and the rule decks see directly.

Validation runs in the adapter's own scope,
so a stale adapter fails loudly, by name, before any rule runs.