Frontend bandwidth

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\[linux-master][Documentation][userspace-api][media][dvb]fe-bandwidth-t.rst, line 7)

Unknown directive type "c:type".

.. c:type:: fe_bandwidth
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linuxmaster\Documentation\userspace-api\media\dvb\[linux-master][Documentation][userspaceapi] [media] [dvb] fe-bandwidth-t.rst, line 9) Unknown directive type "flat-table". .. flat-table:: enum fe_bandwidth :header-rows: 1 :stub-columns: 0 - .. row 1 - ID - Description - .. row 2 - .. BANDWIDTH-AUTO: ``BANDWIDTH AUTO`` - Autodetect bandwidth (if supported) - .. row 3 - .. BANDWIDTH-1-712-MHZ: ``BANDWIDTH 1 712 MHZ`` - 1.712 MHz - .. row 4 - .. _BANDWIDTH-5-MHZ: ``BANDWIDTH_5_MHZ`` - 5 MHz - .. row 5 - .. _BANDWIDTH-6-MHZ: ``BANDWIDTH 6 MHZ`` - 6 MHz - .. row 6 - .. _BANDWIDTH-7-MHZ: ``BANDWIDTH 7 MHZ`` - 7 MHz - .. row 7 - .. _BANDWIDTH-8-MHZ: ``BANDWIDTH 8 MHZ`` - 8 MHz

- .. row 8
 - .. _BANDWIDTH-10-MHZ:
 - ``BANDWIDTH_10_MHZ``
 - 10 MHz