## V4L2\_SDR\_FMT\_RU12LE ('RU12')

Real unsigned 12-bit little endian sample

## **Description**

This format contains sequence of real number samples. Each sample is represented as a 12 bit unsigned little endian number. Sample is stored in 16 bit space with unused high bits padded with 0.

Byte Order. Each cell is one byte.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-
api][media][v41]pixfmt-sdr-ru12le.rst, line 26)

Unknown directive type "flat-table".

.. flat-table::
    :header-rows: 0
    :stub-columns: 0

* - start + 0:
    - I'\ :sub:`0[7:0]`
    - I'\ :sub:`0[11:8]`
```