## **ACPI Fan Performance States**

When the optional \_FPS object is present under an ACPI device representing a fan (for example, PNP0C0B or INT3404), the ACPI fan driver creates additional "state\*" attributes in the sysfs directory of the ACPI device in question. These attributes list properties of fan performance states.

For more information on FPS refer to the ACPI specification at:

http://uefi.org/specifications

For instance, the contents of the INT3404 ACPI device sysfs directory may look as follows:

```
$ ls -1 /sys/bus/acpi/devices/INT3404:00/
total 0
...
-r--r--r-- 1 root root 4096 Dec 13 20:38 state0
-r--r--r-- 1 root root 4096 Dec 13 20:38 state1
-r--r--r-- 1 root root 4096 Dec 13 20:38 state10
-r--r--r-- 1 root root 4096 Dec 13 20:38 state10
-r--r--r-- 1 root root 4096 Dec 13 20:38 state11
-r--r--r-- 1 root root 4096 Dec 13 20:38 state2
-r--r--r-- 1 root root 4096 Dec 13 20:38 state3
-r--r--r-- 1 root root 4096 Dec 13 20:38 state4
-r--r---- 1 root root 4096 Dec 13 20:38 state5
-r--r---- 1 root root 4096 Dec 13 20:38 state6
-r--r---- 1 root root 4096 Dec 13 20:38 state6
-r--r---- 1 root root 4096 Dec 13 20:38 state7
-r--r---- 1 root root 4096 Dec 13 20:38 state8
-r--r---- 1 root root 4096 Dec 13 20:38 state8
-r--r---- 1 root root 4096 Dec 13 20:38 state9
-r--r---- 1 root root 4096 Dec 13 20:38 state9
-r--r---- 1 root root 4096 Dec 13 01:00 status
```

where each of the "state\*" files represents one performance state of the fan and contains a colon-separated list of 5 integer numbers (fields) with the following interpretation:

```
control_percent:trip_point_index:speed_rpm:noise_level_mdb:power_mw
```

- control percent: The percent value to be used to set the fan speed to a specific level using the FSL object (0-100).
- trip point index: The active cooling trip point number that corresponds to this performance state (0-9).
- speed rpm: Speed of the fan in rotations per minute.
- noise level mdb: Audible noise emitted by the fan in this state in millidecibels.
- power mw: Power draw of the fan in this state in milliwatts.

## For example:

```
$cat /sys/bus/acpi/devices/INT3404:00/state1
25:0:3200:12500:1250
```

When a given field is not populated or its value provided by the platform firmware is invalid, the "not-defined" string is shown instead of the value.

## **ACPI Fan Fine Grain Control**

When \_FIF object specifies support for fine grain control, then fan speed can be set from 0 to 100% with the recommended minimum "step size" via \_FSL object. User can adjust fan speed using thermal sysfs cooling device.

Here use can look at fan performance states for a reference speed (speed\_rpm) and set it by changing cooling device cur\_state. If the fine grain control is supported then user can also adjust to some other speeds which are not defined in the performance states.

The support of fine grain control is presented via sysfs attribute "fine\_grain\_control". If fine grain control is present, this attribute will show "1" otherwise "0".

This sysfs attribute is presented in the same directory as performance states.

## **ACPI Fan Performance Feedback**

The optional\_FST object provides status information for the fan device. This includes field to provide current fan speed in revolutions per minute at which the fan is rotating.

This speed is presented in the sysfs using the attribute "fan speed rpm", in the same directory as performance states.