Frontend bandwidth

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\(linux-master) (Documentation) (userspace-api) (media) (dvb) fe-bandwidth-t.rst, line 7)
Unknown directive type "c:type".
```

.. c:type:: fe_bandwidth

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\(linux-master) (Documentation) (userspace-api) (media) (dvb) fe-bandwidth-t.rst, line 9)

Unknown directive type "flat-table".

```
.. flat-table:: enum fe_bandwidth
   :header-rows: 1
   :stub-columns: 0
   - .. row 1
      - ID
      - Description
   - .. row 2
      - .. BANDWIDTH-AUTO:
         ``BANDWIDTH AUTO``
      - Autodetect bandwidth (if supported)
   - .. row 3
      - .. BANDWIDTH-1-712-MHZ:
         ``BANDWIDTH 1 712 MHZ``
      - 1.712 MHz
    - .. row 4
      - .. _BANDWIDTH-5-MHZ:
         ``BANDWIDTH_5_MHZ``
      - 5 MHz
    - .. row 5
      - .. _BANDWIDTH-6-MHZ:
         ``BANDWIDTH 6 MHZ``
      - 6 MHz
   - .. row 6
      - .. _BANDWIDTH-7-MHZ:
         ``BANDWIDTH 7 MHZ``
      - 7 MHz
   - .. row 7
      - .. _BANDWIDTH-8-MHZ:
         ``BANDWIDTH 8 MHZ``
      - 8 MHz
```

- .. row 8
 - .. _BANDWIDTH-10-MHZ:
 - ``BANDWIDTH_10_MHZ``
 - 10 MHz