


SAFE USE OF MINI EXCAVATORS





Employees who drive company


LICENSE


vehicles **MUST** have the correct licence for the vehicle they are driving and notify the company of any endorsements that they receive. Operators of mobile plant MUST

fully competent and authorised to use mini excavators. Operatives MUST NOT use any vehicle/plant that they are not suitably trained to operate.

be over 18 years of age and

• They MUST hold a recognised and current certificate of competency.






• Tow bar is secured to the vehicle

TOWING

position. • Pin is located correctly, breakaway cable attached.

and towing eye is in correct

- Light cord is attached, Jockey wheel is raised.
- Secure the load by use of straps or by bars, straps (3 minimum)
- MUST have a proper tensioning device and be capable of withstanding a force no less than twice the load.





influence of drink or drugs.


DRIVING

• Observe speed limits: 60 mph motorway and dual carriageway, 50 mph single carriageway.

NEVER drive under the

- Remember you are not allowed in
- the third lane of a motorway when towing. • When reversing and your view is limited and / or restricted, ensure
- you use a Banksman.





RISK ASSESSMENT

LOOK AROUND Who or what could affect you? **THINK**

Who might be affected by your actions? **RECORD**

guarded work area.

Your control measures on your Site Specific Risk Assessment.





Ensure that the excavator is

sited on firm level ground paying

and ground condition / stability.

DO NOT OPERATE ON AN INCLINE

• Ensure you have suitable access

and egress from the work area.

• Remember not to store spoil on

Remember: In the event of a mini

vehicle and do not attempt to jump

excavator overturning, stay in

out of vehicle.

any defined access / egress route.

particular attention to surroundings

that you familiarise yourself with the controls prior to use. Check: Fluid levels / Hoses

Ensure correct use by referring to the operator manual and ensure


PRE USER CHECKS

Lights Guards Seat / Seat belts Tracks

Check correct pins are in place for all attachments (buckets)

Ensure all bolts are secure

Inform your Supervisor of any faults and do not use machine until faults are rectified.



Whilst excavating ensure use of a Banksman, making sure he is aware of the safe working range of

the excavator and that he and no

• The excavator is sited within the

The seatbelt is worn at all times

are closed where supplied.

one else encroaches within

during operation and that the doors

USE OF EXCAVATOR

working range of the excavator.

Ensure:

safe working area.

EXCLUSION ZONE

MAXIMUM

OPERATING REACH



Ensure that no plant is within the exclusion zone of any overhead lines.

In all circumstances, if in

doubt ask your Supervisor.

UNDERGROUND/


Mini Excavator is not to be used

within 0.5m of underground plant.

OVERHEAD SERVICES

operate mini excavators

load with straps or bars



limits associated with towing · Banksman required when reversing · Carry out a Risk Assessment upon arrival to site and ensure plant can be used safely within the guarded working area

- · Ensure excavator is sited on firm level ground and do not operate on an incline • In the event of a mini excavator overturning, remain in the vehicle and do not attempt to jump out • Seatbelts to be worn at all times when in operation

• Be aware of plant limitations in the vicinity of underground/overhead services



FOR MORE INFORMATION OR IF YOU HAVE ANY CONCERNS CONTACT YOUR SHEQ DEPARTMENT

