

| | | |
|-----|---------------------------|---------------------------------------------|
| 105 | SIM_ERR_CMD_X | ▼ |
| 106 | SIM_ERR_CMD_Y | ▼ |
| 107 | SIM_BATTERY_ERROR | ▼ |
| 108 | CRITICALLY_LOW_BCRT | ▼ |
| 109 | PROG_ERROR | ▼ |
| 110 | LOW_BATTERY_ON_CHARGER | ▼ |
| 115 | MAIN_TIMER_OVERRUN | ▼ |
| 116 | CONFIG_NOT_READABLE | ▼ |
| 117 | COMMAND_STATE_ERROR | ▼ |
| 118 | STARTUP_ERROR | ▼ |
| 119 | BCRT_REJECT | ▼ |
| 120 | MISSING_DIRECTION | ▼ |
| 121 | MISSING_POSITION | ▼ |
| 122 | MOTOR_OVERLOAD | ▼ |
| 123 | TRANSISTOR_OVERLOAD_LIFT | ▼ |
| 124 | BATTERY_TOO_LOW | ▼ |
| 125 | MISSING_MOTOR_POWER | ▼ |
| 126 | MOTOR_OVERLOAD_LIFT | ▼ |
| 127 | MOTOR_OVERLOAD_TRACK | ▼ |
| 128 | MOTOR_OVERLOAD_X | ▼ |
| 129 | MOTOR_OVERLOAD_Y | ▼ |
| 130 | TRANSISTOR_OVERLOAD_TRACK | Última actualización: 27/8/2024, 18:31:16 ▲ |

| Explicación | Causa | Acción |
|------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| El motor de la pista está sobrecargado. El sorteo actual estaba por encima de un umbral para más de que unos pocos segundos. | Cable de codificador de cambio de pista suelto. O el mecanismo de cambio de pista no funciona propiamente | Compruebe si hay problemas mecánicos que puedan causar una resistencia anormal. Reemplace o Recargue la batería. Compruebe si hay conexiones sueltas. Reemplace la placa de alimentación en caso de que Hay un |

cortocircuito en un transistor. Reemplace el conector de carga en el Robot y/o en la red. Reemplace el cargador. Pruebe las baterías.

Compruebe si el cable del codificador de cambio de pista está colocado correctamente. Comprobar si hay anomalías Resistencia mecánica al pasar de X a Y y viceversa.

| | | |
|-----|-----------------------|---|
| 131 | TRANSISTOR_OVERLOAD_X | ▼ |
| 132 | TRANSISTOR_OVERLOAD_Y | ▼ |
| 134 | ILLEGAL_MOVE_MOTOR | ▼ |
| 135 | SF_ERROR | ▼ |
| 136 | LOG_ERROR | ▼ |
| 137 | LOG_OVERFLOW | ▼ |
| 139 | CBUS_FAILURE | ▼ |
| 140 | UCAP_CHARGE_FAILURE | ▼ |
| 141 | MISSING_UCAP | ▼ |
| 142 | MISSING_BATTERY | ▼ |
| 143 | BATTERY_HOOK_STATE | ▼ |
| 144 | UNEXPECTED_BATTERY | ▼ |
| 146 | EARLY_STOP_TO_CHARGER | ▼ |
| 147 | SHUTDOWN_VOLTAGE | ▼ |
| 148 | DIODE_BLOCKED | ▼ |
| 149 | TIMED_SHUTDOWN | ▼ |
| 150 | COMMAND_OUT_OF_GRID | ▼ |
| 151 | COMMANDPOS_MISSMATCH | ▼ |
| 152 | NO_STOPPOS | ▼ |
| 153 | NO_MIDPOS | ▼ |
| 154 | EARLY_STOP_TO_X | ▼ |