

Industrial Pump Maintenance Manual

Model: P-101 Centrifugal Pump

Manufacturer: Apex Industrial Systems

SECTION 1: TECHNICAL SPECIFICATIONS

Operating Pressure: 150 PSI

Max Temperature: 220°F

Motor Voltage: 480V

Torque Requirement (Bearing Housing): 75 ft-lbs

Flow Rate: 500 GPM

SECTION 2: BEARING REPLACEMENT PROCEDURE

1. Disconnect electrical supply and lockout/tagout.
2. Remove pump housing cover.
3. Inspect shaft alignment.
4. Remove damaged bearing using puller tool.
5. Install new bearing and torque housing bolts to 75 ft-lbs.
6. Reassemble pump and test operation.

SECTION 3: TROUBLESHOOTING

Symptom: Excessive vibration | Cause: Bearing wear | Action: Replace bearing

Symptom: Low flow rate | Cause: Clogged impeller | Action: Clean impeller

Symptom: Overheating | Cause: Seal failure | Action: Inspect seals

SECTION 4: SAFETY WARNINGS

Always wear PPE during maintenance.

Follow OSHA lockout/tagout procedures.

Do not exceed pressure ratings.