Cisco Room Devices Driver 8.0003

GENERAL INFORMATION

SIMPLWINDOWS NAME:	Cisco Room Devices 8.0003
CATEGORY:	Conferencing
VERSION:	8.0003
VERSION DATE:	4/24/2025
DESCRIPTION:	Used to control a Cisco room device
VENDOR SETUP	**User Setup** A user profile must be set up in the codec. This will be the profile used to allow the module to connect to the codec for control. This profile must have Room Control, Integrator and User permissions. Admin privileges are typically not allowed by network administrators. The user setup can be found here: https://<codec ip address>/web/users The default login is 'admin' with no password unless this has been previously setup.
GENERAL NOTES:	**Database Version Requirements** This module requires v215 or newer of the Crestron database. It will not work with older versions. Ethernet Only (VC4) systems can run any program that uses a 4 series processor. This can be used until the "Ethernet-Only" control definition is available in the database. **How communication operates** For best performance of the module, it is recommended to use IP control or a serial port onboard to a control system. Crestron cannot guarantee performance of the module when used with CEN-IO and DM-RMC comm ports. This module can be used on a COM port or it can use SSH. Only one type may be used at run-time. The socket connections are handled internally. No prior initialization is required by the programmer – the module will begin communicating with the codec once the signal Connect has a rising edge regardless of the transport used. SSH has two modes: Secure and Unsecure. Unsecure mode auto-accepts a connection while Secure mode will check a file of host key fingerprints before sending any sensitive data. This file is stored in \NVRAM\CiscoRoomDevice\ and is a JSON formatted List<string> collection. The module outputs a connection state on all three types of transports. The LoggedIn state (4d) should be used to buffer any commands that need to be sent once the system is logged in and ready to process commands. Any commands triggered before being logged in will be ignored. Each transport connection has a digital output that specifies if the module is busy processing data received from the codec. When the module initially connects to the device it will request a lot of information from the codec depending on the settings on the module. The programmer can enable/disable initial phonebook requests, call history requests, and booking requests. All other sections are automatically polled at the start. Depending on these settings and the transport used, it may take several minutes until the module is complete with initialization.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

How the phonebook operates

-Download as needed:

Local Phonebook:
The first 500 entries (or all entries depending on the download settings) are downloaded initially either by the user or as a programmed function. The module will only output 20 entries using an individual signals for each entry. To view all entries the programmer must use the signals Navigate Up/Down Page to see more entries.

The module will keep downloading entries so that the 10 entries are always populated as long as there are entries on the codec. The internal code will make sure there is a buffer of at least 5 pages before requesting more.

This same logic is used on folders and on searches with a search parameter.

Support for the Address Book smart object is disabled with this setting.
Support for setting the number of contacts to display a time is disabled with this setting.

Corporate Phonebook:

The corporate will operate different than the local phonebook if the Cisco Room OS is v11 or greater in the codec. The biggest difference is that the phonebook will no longer paginate the list. The search feature is the only way to use this phonebook (similar to the Cisco UI included with the codec.) This is done because the majority of Corporate Phonebooks will likely be cloud based with no restrictions of size. Codec models that use Cisco Room OS v10 or less will operate the same as the Local Phonebook.

-Download All
All entries are retrieved from the phonebook using a recursive search.
Support for the Address Book smart object is enabled with this setting.
Support for setting the number of contacts to display a time is enabled with this setting.

How the call system works

A call is divided into three main types: Incoming, Outgoing, and Connected

-Any call dialed will be available as an Outgoing call until it is connected.

-Any call incoming will be available as an Incoming call until it is connected.

Only 5 concurrent calls within each section are supported. Calls will automatically move up in index as other calls are removed.

Props on the Address Book Smart Object:

The property names will be:

-"callRate"
-"callType"
-"number"

Known Issues

There is a known issue when using a codec with a fixed camera that does not pan/tilt. If zoomed in and pressing focus in/out, the image will appear to shift left or right.

CRESTRON HARDWARE REQUIRED:	3 Series Processor, 4 Series Processor

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

Cisco TelePresence Software tested versions	TC 7.3, CE 8.3.4, CE 9.1.X through CE 11.06.X
Cisco TelePresence SX-10	1. Only supports Microphones 1 & 2 2. Only supports Camera 1 3. Only supports video input connectors 1, 2, & 3 4. Only supports video output connector 1
Cisco TelePresence SX-20	1. Only supports Microphones 1 & 2 2. Only supports Camera 1 3. Only supports video input connectors 1 & 2 4. Only supports video output connectors 1 & 2
Cisco TelePresence SX-80	All features should be supported that are exposed by this module
Cisco TelePresence MX200 G2	1. Only supports Microphones 1 & 2 2. Only supports Camera 1 3. Only supports video input connectors 1 & 2 4. Only supports video output connector 1
Cisco TelePresence MX300 G2	1. Only supports Microphones 1 & 2 2. Only supports Camera 1 3. Only supports video input connectors 1 & 2 4. Only supports video output connector 1
Cisco TelePresence MX700	1. Only supports Camera 1 & 2 2. Only supports video input connector 1 3. Only supports video output connector 1
Cisco TelePresence MX800	1. Only supports Camera 1 & 2 2. Only supports video input connector 1 3. Only supports video output connector 1
Cisco DX80	1. Only supports Microphone 1 2. Only supports Camera 1 3. Only supports video input connector 1 4. Does not support video output connectors
Cisco DX70	1. Only supports Microphone 1 2. Only supports Camera 1 3. Only supports video input connector 1 4. Does not support video output connectors
Cisco Webex Room 55	1. Only supports Microphones 1, 2, & 3 2. Only supports Camera 1 3. Only supports video input connectors 1 & 2 4. Only supports video output connector 1
Cisco Webex Room 70	1. Only supports Microphones 1, 2, & 3 2. Only supports Camera 1 3. Only supports video input connectors 1, 2, & 3 4. Only supports video output connectors 1 & 2
Cisco Webex Room Kit	1. Only supports Microphones 1, 2, & 3 2. Only supports Camera 1 3. Only supports video input connector 1, 2, & 3 4. Only supports video output connector 1 & 2

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

Cisco Webex Room Kit Plus	1. Only supports Microphones 1, 2, & 3 2. Only supports Camera 1 3. Only supports video input connector 1, 2, & 3 4. Only supports video output connector 1 & 2

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com

Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL - LOCAL & CORPORATE PHONEBOOK:

LocalPhonebook_EnableInitialPoll CorporatePhonebook_EnableInitialPoll	D	If enabled, once the system gets into a logged-in state it will use the functionality provided by <PhonebookType>_Request. If disabled, the user/programmer are required to pulse <PhonebookType>_Request.
LocalPhonebook_Request CorporatePhonebook_Request	D	Download As Needed – Requests the first 500 entries of the phonebook in the root directory. Download All – Requests all the entries in the phonebook including all folders.
LocalPhonebook_Search CorporatePhonebook_Search	D	Requests the first 500 entries of the phonebook in any directory that match the SearchString specified.
LocalPhonebook_SearchString CorporatePhonebook_SearchString	S	Used to specify the search parameters of a phonebook search.
LocalPhonebook_SelectEntry CorporatePhonebook_SelectEntry	A	Selects an entry in the phonebook. Valid values are 1 - 10
LocalPhonebook_SelectContactMethod CorporatePhonebook_SelectContactMethod	A	Selects a contact method that is associated with the currently selected entry. Valid values are 1 - 5
LocalPhonebook_ClearSelectedEntry CorporatePhonebook_ClearSelectedEntry	D	Clears all feedback on the currently selected entry.
LocalPhonebook_DialSelected CorporatePhonebook_DialSelected (Room OS 10 or less)	D	Dials the currently selected entry with either the first available contact method if one is not specified or the specified contact method.
LocalPhonebook_NavigateToPreviousDirectory CorporatePhonebook_NavigateToPreviousDirectory	D	Navigates the phonebook to the parent folder of the current folder.
LocalPhonebook_NavigateToRootDirectory (Local Only)	D	Navigates the phonebook to the root folder.
LocalPhonebook_NavigateDownPage (Local Only)	D	Navigates the phonebook down one page. There are a total of 50 pages with 10 items on each page. As the user navigates through the pages, the internal code will keep requesting and removing entries to allow for navigation through all entries in the phonebook, not limited by the original 500 entries downloaded when RequestPhonebook is pulsed.
LocalPhonebook_NavigateUpPage (Local Only)	D	Navigates the phonebook up one page.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400
www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

FEEDBACK - LOCAL & CORPORATE PHONEBOOK:

Corporate_Phonebook_Supports_Pagination	D	Signal used to indicate that the codec firmware supports phonebook pagination. RoomOS Firmware v 11 and greater no longer can support pagination.
LocalPhonebook_Status CorporatePhonebook_Status	S	The current status of the phonebook. This will specify if a download is taking place, how many entries are downloading, and how many entries were found in a download. The will also display any errors with a search.
LocalPhonebook_DownloadState CorporatePhonebook_DownloadState	A	1 = Downloading 2 = Download Complete
LocalPhonebook_NumberOfEntries CorporatePhonebook_NumberOfEntries	A	Specifies the number of entries in the current selected page. Values are 1-10
LocalPhonebook_Entry1-20 CorporatePhonebook_Entry1-20	S	Specifies the names for up to 20 entries on the current page.
LocalPhonebook_Selected_NumberOfContactMethods CorporatePhonebook_Selected_NumberOfContactMethods	A	Specifies the number of contact methods for a selected entry. Values are 1 - 5
LocalPhonebook_Selected_Numbers_Entry1-5 LocalPhonebook_Selected_Protocols_Entry1-5 LocalPhonebook_Selected_CallRatess_Entry1-5 LocalPhonebook_Selected_CallTypess_Entry1-5 LocalPhonebook_Selected_Device_Entry1-5 CorporatePhonebook _Selected_Numbers_Entry1-5 CorporatePhonebook _Selected_Protocols_Entry1-5 CorporatePhonebook _Selected_CallRatess_Entry1-5 CorporatePhonebook _Selected_CallTypess_Entry1-5 CorporatePhonebook _Selected_Device_Entry1-5	S	Specifies up to five contact methods for the selected entry.
LocalPhonebook_CurrentFolder CorporatePhonebook_CurrentFolder	S	Specifies the current folder the phonebook is displaying.
LocalPhonebook_Selected_Name CorporatePhonebook_Selected_Name	S	Specifies the Name field of the currently selected entry.
LocalPhonebook_Selected_Title CorporatePhonebook_Selected_Title	S	Specifies the Title field of the currently selected entry.
LocalPhonebook_Selected_Number CorporatePhonebook_Selected_Number	S	Specifies the Number field of the currently selected entry and contact method. This will be the first available option if one is not selected.
LocalPhonebook_Selected_Device	S	Specifies the Device field of the currently selected entry.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CorporatePhonebook_Selected_Device		
LocalPhonebook_Selected_Protocol CorporatePhonebook_Selected_Protocol	S	Specifies the Protocol field of the currently selected entry and contact method. This will be the first available option if one is not selected.
LocalPhonebook_Selected_CallRate CorporatePhonebook_Selected_CallRate	S	Specifies the CallRate field of the currently selected entry and contact method. This will be the first available option if one is not selected.

FEEDBACK - LOCAL & CORPORATE PHONEBOOK:

LocalPhonebook_Selected_CallType CorporatePhonebook_Selected_CallType	S	Specifies the CallType field of the currently selected entry and contact method. This will be the first available option if one is not selected.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – NEAR END CAMERAS:

NearEnd_RequestPresets	D	This will request a list of camera presets currently available on the codec.
NearEnd_SelectCamera	A	Determines which camera will be controlled.
NearEnd_ResetPosition	D	Resets the position of the selected camera.
NearEnd_PanLeft	D	Pan Left operation on the selected camera.
NearEnd_PanRight	D	Pan Right operation on the selected camera.
NearEnd_TiltUp	D	Tilt Up operation on the selected camera.
NearEnd_TiltDown	D	Tilt Down operation on the selected camera.
NearEnd_ZoomIn	D	Zoom In operation on the selected camera.
NearEnd_ZoomOut	D	Zoom Out operation on the selected camera.
NearEnd_FocusNear	D	Focus Near operation on the selected camera.
NearEnd_FocusFar	D	Focus Far operation on the selected camera.
NearEnd_AutoFocus	D	AutoFocus operation on the selected camera.
NearEnd_BrightnessMode	A	Sets the Brightness Mode of the selected camera. Valid values: 1 – Auto 2 – Manual
NearEnd_BrightnessLevel	A	Sets the default brightness level of the selected camera. This will only be used when NearEnd_BrightnessMode is set to Manual but the value can still be altered regardless of the current state.
NearEnd_SelectPreset	A	Selects a camera preset on the selected camera.
NearEnd_ActivateSelectedPreset	D	Activates the selected camera preset.
NearEnd_SaveSettingsAsCurrentPreset	D	Saves the current camera position as the currently selected preset. If the preset is not defined on the codec, then this will not be saved.
NearEnd_RemoveSelectedPreset	D	Removes the selected preset from the selected camera.
NearEnd_AddNewPreset	D	Adds a new preset to the selected camera with the name NearEnd_NewPresetName. This will use the current camera's position.
NearEnd_NewPresetName	S	Specifies the name of any new preset that would be added by

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400
www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

		NearEnd_AddNewPreset.

FEEDBACK – NEAR END CAMERAS:

NearEnd_SelectCamera_FB	A	Signal used to indicate the current camera selected.
NearEnd_NumberOfCameras	A	The number of cameras the module supports.
NearEnd_CameraNames_XSIG	S	The names of all the cameras.
NearEnd_CurrentPresetSaved	D	This signal will pulse when a preset is successfully saved.
NearEnd_NumberOfPresets	A	The number of presets for the currently selected camera.
NearEnd_CameraPresetName1-35	S	The names of the presets for the currently selected camera.

CONTROL – FAR END CAMERAS:

FarEnd_SelectCall	A	Selects a connected call for camera control. All camera controls are per-call. Valid values: 1- 5
FarEnd_PanLeft	D	Performs the Pan Left operation on the selected call's camera.
FarEnd_PanRight	D	Performs the Pan Right operation on the selected call's camera.
FarEnd_TiltUp	D	Performs the Tilt Up operation on the selected call's camera.
FarEnd_TiltDown	D	Performs the Tilt Down operation on the selected call's camera.
FarEnd_ZoomIn	D	Performs the Zoom In operation on the selected call's camera.
FarEnd_ZoomOut	D	Performs the Zoom Out operation on the selected call's camera.
FarEnd_SelectSource	A	Selects a source on the selected call. Valid values: 0 – 15 where 0 = No source and 15 = Source 15
FarEnd_SelectPreset	A	Activates a room preset on the selected call (This must be enabled on the far end to function). Valid values: 1 - 15

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

CONTROL – CALL CONTROL:		
Answer All	D	Answers all incoming calls.
Answer[1] - Answer[5]	D	Answers the selected incoming call.
RejectAll	D	Rejects all incoming calls.
Reject[1] - Reject[5]	D	Rejects the selected incoming call.
HangUpAll	D	Hangs up all connected & outgoing calls.
HangUpConnectedCall[[1] - HangUpConnectedCall[[5]	D	Hangs up the selected connected call.
HangUpOutgoingCall[1] - HangUpOutgoingCall[5]	D	Hangs up the selected outgoing call.
HoldAll	D	Puts all connected calls on hold.
Hold[1] - Hold[5]	D	Puts the selected connected call on hold.
ResumeAll	D	Resumes all connected calls on hold
Resume[1] - Resume[5]	D	Resumes the selected connected call on hold
Ignore All	D	Ignores all incoming calls.
Ignore[1] - Ignore[5]	D	Ignores the selected incoming call.
Join All	D	Joins all connected calls.
Transfer[1] - Transfer[5]	D	Transfers the selected connected call to the TransferDestination.
TransferDestination	S	The URI that should be used when transferring a connected call.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

FEEDBACK – INCOMING CALL STATUS:

IncomingCall[1] - IncomingCall[5]	D	Specifies if there is an incoming call.
IncomingCall_Number[1] - IncomingCall_Number[5]	S	The number of the incoming call(s).
IncomingCall_DisplayName[1] to IncomingCall_DisplayName[5]	S	The display name of the incoming call(s).
IncomingCall_Status[1] - IncomingCall_Status[5]	S	The status of the incoming call(s).
IncomingCall_CallType[1] - IncomingCall_CallType[5]	S	The call type of the incoming call(s).

FEEDBACK – CONNECTED CALL STATUS:

ConnectedCall_IsActive[1] - ConnectedCall_IsActive[5]	S	Specifies if there is a connected call
ConnectedCall_Number[1] - ConnectedCall_Number[5]	S	The number of the connected call(s).
ConnectedCall_DisplayName[1] to ConnectedCall_DisplayName[5]	S	The display name of the connected call(s).
ConnectedCall_Status[1] - ConnectedCall_Status[5]	S	The status of the connected call(s).
ConnectedCall_CallType[1] - ConnectedCall_CallType[5]	S	The call type of the connected call(s).
ConnectedCall_OnHold[1] - ConnectedCall_OnHold[5]	D	Specifies if a connected call is on hold.

FEEDBACK – OUTGOING CALL STATUS:

OutgoingCallIsActive[1] - OutgoingCallIsActive[5]	D	Specifies if there is an outgoing call. Any calls dialed on the Touch 10 or similar Cisco panel will also appear here.
OutgoingCall_Number[1] - OutgoingCall_Number[5]	S	The number of the outgoing call(s).
OutgoingCall_DisplayName[1] to OutgoingCall_DisplayName[5]	S	The display name of the outgoing call(s).
OutgoingCall_Status[1] - OutgoingCall_Status[5]	S	The status of the outgoing call(s).
OutgoingCall_CallType[1] - OutgoingCall_CallType[5]	S	The call type of the outgoing call(s).

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – CALL SETTINGS:

EnableDoNotDisturb	D	1 - Enables Do Not Disturb
DisableDoNotDisturb		1 - Disables Do Not Disturb
EnableAutoAnswer	D	1 - Enables Auto Answer
DisableAutoAnswer		1 - Disables Auto Answer
AutoAnswerDelay	A	The number of seconds the codec will wait until auto-answering an incoming call. Valid values: 0 - 50
DefaultCallRate	A	The default call rate the codec will use. Valid values: 128, 256, 384, 512, 768, 1152, 1472, 1920, 2560, 3072, 4000, 6000
DefaultCallProtocol	A	The default call protocol the codec will use. Valid values: 1 – Auto 2 – H320 3 – H323 4 – SIP 5 - Spark
EncryptionMode	A	The encryption mode the codec will use. Valid values: 1 – Off 2 – On 3 – Best Effort

FEEDBACK – CALL SETTINGS:

DoNotDisturb_IsEnabled	D	0 = Do Not Disturb is disabled 1 = Do Not Disturb is enabled
AutoAnswer_IsEnabled	D	0 = Auto Answer is disabled 1 = Auto Answer is enabled
AutoAnswerDelay	A	The number of seconds the codec will wait until auto-answering an incoming call. Outputs 0 - 50
DefaultCallRate	A	The default call rate of the codec. 128, 256, 384, 512, 768, 1152, 1472, 1920, 2560, 3072, 4000, 6000
DefaultCallProtocol	A	The default call protocol of the codec. 1 – Auto 2 – H320 3 – H323 4 – SIP 5 – Spark
EncryptionMode	A	The encryption mode of the codec. 1 – Off 2 – On 3 – Best Effort

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – CALL HISTORY:

CallHistory_EnableInitialPoll	D	Enables polling for call history entries when the system gets to a logged in state.
CallHistory_Request	D	Requests the first 100 call history entries.
CallHistory_SearchString	S	The search parameters for a call history request.
CallHistory_AcknowledgeAll	D	Acknowledges all call history entries (this will be all entries, not just the ones displayed).
CallHistory_DeleteAll	D	Deletes all call history entries (this will be all entries, not just the ones displayed).
CallHistory_SelectEntry	A	Selects an entry. Valid values: 1 – 10
CallHistory_AcknowledgeSelected	D	Acknowledges the selected entry.
CallHistory_DeleteSelected	D	Deletes the selected entry.
CallHistory_DialSelected	D	Dials the selected entry.
CallHistory_NextPage	D	Navigates to the next 10 entries.
CallHistory_PreviousPage	D	Navigates to the previous 10 entries.

FEEDBACK – CALL HISTORY:

CallHistory_NumberOfEntries	A	The number of call history entries on the current page.
CallHistory_Entry1-25	S	The current call history entries on the current page.
CallHistory_DownloadState	A	Specifies if call history is currently being downloaded. 1 – Downloading 2 – Download Complete

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – DIALING:

Dialing_StringToDial	S	The URI that should be dialed when PlaceCall is pulsed.
Dialing_PlaceCall	D	Places a call using StringToDial as the URI and the settings below if set.
Dialing_CallType	A	Defines the type of call that should be specified when using PlaceCall. Valid values: 0 = Default 1 = Audio 2 = Video
Dialing_CallProtocol	A	Defines the protocol that should be used when using PlaceCall If left unset the codec will use its default protocol for the call. Valid values: 1 – Auto 2 – H320 3 – H323 4 – SIP 5 – Spark
Dialing_CallSpeed	A	Defines the call speed that should be used when using PlaceCall. If left unset the codec will use its default call rate for the call. Valid values: 128, 256, 384, 512, 768, 1152, 1472, 1920, 2560, 3072, 4000, 6000

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – DTMF:

DTMF_SelectCall	A	Selects a connected call to send DTMF tones to. Valid values: 1 – 5
DTMF_Key0 - DTMF_Key9, DTMF_Key* and DTMF_Key#	D	Sends the DTMF key to the selected connected call.
DTMF_SendCustomString	D	Sends StringToSend to the selected connected call.
DTMF_StringToSend	S	The string that should be sent as a DTMF tone to the connected call.

CONTROL – AUDIO:

SetVolume	A	Sets the volume on the codec. Valid values: 0% – 100% (0d – 65535)
VolumeUp	D	Increases the volume by one step.
VolumeDown	D	Decreases the volume by one step.
VolumeRampingRate	A	The rate (ms) at which the module should increase/decrease volume. Default value is 250ms.
VolumeMuteOn	D	Enables volume mute.
VolumeMuteOff	D	Disables volume mute.
VolumeRampingRate	A	The rate at which volume up/down will be sent while ramping. This value is in milliseconds. The default value is 250ms.
VolumeMuteToggle	D	Toggles volume mute. CE 9.X Only.
MicrophoneMuteOn	D	Enables microphone mute (all microphones).
MicrophoneMuteOff	D	Disables microphone mute (all microphones).
MicrophoneMuteToggle	D	Toggles microphone mute (all microphones). CE 9.X Only.
MicrophoneGain[1] - MicrophoneGain[8]	A	Set the gain on a microphone. Valid values: 0 to 70

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

FEEDBACK – AUDIO:

VolumeLevel_Value	A	The current volume level of the codec . 0 – 100
VolumeIsMuted	D	Specifies if volume mute is enabled.
MicrophonesAreMuted	D	Specifies if microphone mute is enabled.
MicrophoneGainValue[1] - MicrophoneGainValue[8]	A	Specifies the gain of each individual microphone. 0 - 70

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – VIDEO:

SetMainVideoSource	A	Sets the main video source. Valid values: 1 – 4 (Source 1 through Source 4)
SetActiveConnector	A	Sets the active connector on Source 4. Valid values: 1 – DVI 2 - S-Video / Composite
SelfView_Enable	D	Enables Self View.
SelfView_Disable	D	Disables Self View.
SelfView_EnableFullscreen	D	Enables fullscreen.
SelfView_DisableFullscreen	D	Disables fullscreen.
SelfView_Monitor	A	Sets the monitor role. Valid values: 1- 4 (Monitor Role 1 – through Monitor Role 4)
SelfView_PIP_Position	A	Sets the PIP Position. Valid values: 1 – Center Left 2 – Center Right 3 – Lower Left 4 – Lower Right 5 – Upper Center 6 – Upper left 7 – Upper Right
PictureLayout	A	Sets the picture layout. Valid values: 1 – Auto 2 - Equal 3 – Overlay 4 – Prominent 5 - Single 6 - Custom

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

FEEDBACK – VIDEO:

MainVideoSource	A	Specifies the main video source. 1 – 4 (Source 1 through Source 4)
SelfView_IsOn	D	0 = Self view is disabled 1 = Self view is enabled
SelfView_IsFullscreen	D	0 = Fullscreen is disabled 1 = Fullscreen is enabled
SelfView_Monitor_Value	A	Specifies the monitor role. 1- 4 (Monitor Role 1 – through Monitor Role 4)
SelfView_PIP_Position_Value	A	Specifies the PIP position. 1 – Center Left 2 – Center Right 3 – Lower Left 4 – Lower Right 5 – Upper Center 6 – Upper left 7 – Upper Right
PictureLayout_Value	A	Specifies the picture layout. 1 – Auto 2 - Equal 3 – Overlay 4 – Prominent 5 - Single

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – PRESENTATION:

Presentation_Start	D	Starts the presentation. Settings below must be set prior to starting the presentation.
Presentation_Stop	D	Stops the presentation.
Presentation_InputSource	A	Specifies the input source that should be used on the presentation. Only InputSource or Connector can be used. If both are set then InputSource takes priority. Valid values: 1 – 4 = Input 1 through Input 4 5 = None
Presentation_Connector	A	Specifies the input connector that should be used on the presentation. Only InputSource or Connector can be used. If both are set then InputSource takes priority. Valid values: 1 – 5 = Connector 1 through Connector 5 6 = None
Presentation_SendingMode	A	Specifies the sending mode that should be used on the presentation. Valid values: 1 – Local and Remote 2 – Local Only
Presentation_Instance	A	Specifies the instance that should be used on the presentation. Valid values: 1 – New 2 – Instance 1 3 – Instance 2 4 – Instance 3 5 – Instance 4 6 – Instance 5 7 – Instance 6

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

FEEDBACK – PRESENTATION:

LocalPresentation_IsStarted	D	Specifies if a local presentation has started.
Presentation_Mode	A	Specifies the current presentation mode: 1 – Off 2 – Sending 3 - Receiving
PresentationSource_Is_Input[x]	D	Specifies the current source/input that is being used by an active presentation.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – ROOM PRESETS:

ActivateRoomPreset	A	Activates and selects a room preset . Room presets differ to camera presets in that they store video settings as well as camera positions. Valid values: 1 - 15
DeleteRoomPreset	A	Deletes the currently selected preset.
StoreRoomPreset	A	Stores the current camera and room settings as the selected preset.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

CONTROL – MESSAGE WINDOW:

ClearMessageAlert	D	Clears the current message alert being displayed by the codec.
ShowMessageAlert	D	Shows a new message alert on the codec with the settings set below.
NewMessageAlertTitle	S	The title that should be used when showing a message alert.
NewMessageAlertText	S	The text that should be used when showing a message alert.
ClearMessagePrompt	D	Clears the current message prompt being displayed by the codec.
SelecMessagePromptOption1 through SelecMessagePromptOption5	D	Selects one of the five message prompt options being displayed by the codec.
ShowMessagePrompt	D	Shows a new message prompt on the codec with the settings set below.
NewMessagePromptTitle	S	The title that should be used when showing a message prompt.
NewMessagePromptText	S	The text that should be used when showing a message prompt.
NewMessagePromptOption1 through NewMessagePromptOption5	D	The options that should be used when showing a message prompt.

FEEDBACK – MESSAGE WINDOW:

MessageAlertIsActive	D	0 – No message alert is active 1 - Message alert is active
MessageAlertTitle	S	The title of the active message alert.
MessageAlertText	S	The text of the active message alert.
MessagePromptActive	D	0 – No message prompt is active 1 – Message prompt is active
MessagePromptTitle	S	The title of the active message prompt.
MessagePromptText	S	The text of the active message prompt.
MessagePromptOptionIsSelectable[1] through MessagePromptOptionIsSelectable[5]	D	Specifies if an option is available on the active message prompt.
MessagePromptOptionText[1] through MessagePromptOptionText[5]	S	The text on the active message prompt.
MessagePromptOptionSelected[1] through MessagePromptOptionSelected[5]	D	Specifies which option was selected on the active message prompt.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – BOOKINGS:

Bookings_EnableInitialPoll	D	Enables polling for booking entries when the system gets to a logged in state.
GetBookings	D	Gets the first 50 bookings for the current day.
TimeDisplayMode	A	Sets how time is displayed on all the string outputs. Valid values: 1 = 24 Hour 2 = 12 Hour
SelectBooking	A	Selects a booking entry.
JoinSelectedBooking	D	Joins the selected booking entry.
ClearSelectedBooking	D	Clears all string outputs associated with the selected booking.
SelectContactForSelectedBooking	A	Selects the contact method for the selected booking. (Not implemented)
JoinActiveBooking	D	Joins the next available booking if it is joinable.
SelectContactForActiveBooking	A	Selects the contact method for the active booking. (Not implemented)

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

FEEDBACK – BOOKINGS:

NumberOfBookings	A	The number of bookings that are available.
BookingTitle1-25 BookingAgenda1-25 BookingStartTime1-25 BookingEndTime1-25	S	Signals containing information about the current bookings.
Booking_SelectedIsJoinable	D	Specifies if the selected booking is joinable.
Booking_SelectedInProgress	D	Specifies if the selected booking is in progress.
Booking_SelectedName	S	The selected booking's name field.
Booking_SelectedDescription	S	The selected booking's description field.
Booking_SelectedStartTime	S	The selected booking's start time field.
Booking_SelectedEndTime	S	The selected booking's end time field.
Booking_SelectedDuration	S	The selected booking's duration field.
Booking_SelectedOrganizer	S	The selected booking's organizer full name field.
Booking_SelectedWebExUrl	S	The selected booking's WebEx URL field.
Booking_SelectedWebExNumber	S	The selected booking's WebEx Number field.
Booking_SelectedWebExPassword	S	The selected booking's WebEx Password field.
Booking_SelectedWebExHostKey	S	The selected booking's WebEx Host Key field.
Booking_SelectedNumberOfContacts	A	The amount of numbers available for the selected booking. (Not implemented)
Booking_ActiveIsJoinable	D	Specifies if the active booking is joinable.
Booking_ActiveInProgress	D	Specifies if the active booking is in progress.
Booking_ActiveProgress	A	(Not implemented)
Booking_ActiveName	D	The active booking's name field.
Booking_ActiveDescription	S	The active booking's description field.
Booking_ActiveStartTime	S	The active booking's start time field.
Booking_ActiveEndTime	S	The active booking's end time field.
Booking_ActiveDuration	S	The active booking's duration field.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Booking_ActiveOrganizer	S	The active booking's organizer full name field.
Booking_ActiveWebExUrl	S	The active booking's WebEx URL field.
Booking_ActiveWebExNumber	S	The active booking's WebEx Number field.
Booking_ActiveWebExPassword	S	The active booking's WebEx Password field.
Booking_ActiveWebExHostKey	S	The active booking's WebEx Host Key field.
Booking_ActiveNumberOfNumbers	A	The amount of numbers available for the active booking. (Not implemented)
Booking_ActiveNumbers_XSIG	S	XSIG containing all of the numbers available for the active booking. (Not implemented)

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – SPEAKER TRACK:

SpeakerTrack_Activate	D	Activates Speaker Track.
SpeakerTrack_Deactivate	D	Deactivates Speaker Track.

FEEDBACK – SPEAKER TRACK:

SpeakerTrack_IsActivated	D	Specifies whether or not Speaker Track is currently activated.

CONTROL – PRESENTER TRACK:

PresenterTrack_Mode	A	Sets the Presenter Track mode: 1 – Off 2 – Follow 3 – Diagnostic 4 – Background 5 – Setup 6 - Persistent

FEEDBACK – PRESENTER TRACK:

PresenterTrack_IsAvailable	D	Specifies whether or not Presenter Track is available on the codec.
PresenterTrack_ModeValue	A	Specifies the current Presenter Track mode: 1 – Off 2 – Follow 3 – Diagnostic 4 – Background 5 – Setup 6 - Persistent

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

CONTROL – SYSTEM:

ActivateStandby	D	Activates standby.
DeactivateStandby	D	Deactivates standby.
LoggingMode	A	Changing the logging mode. Valid values: 1 – No logging 2 – Regular logging 3 – Verbose logging
OverrideUsername	S	Allows the programmer to set the username used and override the one specified by the property. The programmer must disconnect and reconnect to use the new username.
OverridePassword	S	Allows the programmer to set the password used and override the one specified by the property. The programmer must disconnect and reconnect to use the new password.

FEEDBACK – SYSTEM:

SoftwareVersion	S	The current software version running on the codec.
ProductID	S	The product name of the codec.
StandbyState	S	The current standby state of the codec.
MACAddress	S	The MAC address of the codec.
IPV4Address	S	The IP V4 address of the codec.
IPV6Address	S	The IP V6 address of the codec.
SIPURI	S	The SIP URI in use by the codec.
SIPStatus	S	The current SIP state.
H323GatekeeperAddress	S	The H323 Gatekeeper address.
H323GatekeeperPort	S	The H323 Gatekeeper port.
H323GatekeeperStatus	S	The H323 Gatekeeper status.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

CONTROL – DIAGNOSTICS:

RunDiagnostics	D	This will clear the current set of diagnostics and query the device for a new list. It will use the filter specified by the signal DiagnosticsFilter.
DiagnosticsFilter	A	This selects the type of filter to use when running diagnostics. 0 – No Filter 1 – Alerts 2 – All 3 - None

FEEDBACK – DIAGNOSTICS:

DiagnosticsCount	A	The number of diagnostic messages received from the device. The limit is 10 messages.
Diagnostics_Description[1 – 10]	S	A description of the diagnostic message. This is automatically truncated to 255 characters.
Diagnostics_Level[1 - 10]	S	The level of the diagnostic message
Diagnostics_Type[1 - 10]	S	The type of diagnostic message
Diagnostics_Reference[1 - 10]	S	Any references that were included in the diagnostic message. This is automatically truncated to 255 characters.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

CONTROL – SSH:

SSHServerAddress	S	The address that should be used for the connection. This can be the hostname or the IP address of the device.
SSHServerPort	A	The port that should be used for the connection. Valid values: 1 – 65535 Default value: 22
SSH_Connect	D	Connects to the codec using an SSH connection.
SSH_Disconnect	D	Disconnects from the codec.
SSH_AcceptKey	D	Accepts the currently received SSH key and stores it in a file in NVRAM.
SSH_RejectKey	D	Rejects the currently received SSH key and closes the connection.
SSH_CustomCommandToDevice	S	Sends data to the device. The driver will append a CRLF.

FEEDBACK – SSH:

SSH_UnknownKeyReceived	D	0 – No unknown keys have been received 1 – An unknown key has been received. Must accept or reject.
SSH_Key	S	The received host key fingerprint.
SSH_Connected	D	0 – Not connected 1 – Connected
SSH_ConnectionState	A	1 – Connected 2 – Connecting 3 – Disconnected 4 – Logged In (Ready to receive and process commands)
SSH_FromDevice	S	Data received from the device.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – COM:

COM_Start	D	When pulsed, this will allow the driver to communicate with the codec.
COM_Stop	D	When pulsed, this will stop all communication with the codec.
FromDevice	S	Data received on the COM port.

FEEDBACK – COM:

COM_Connected	D	0 – Not connected 1 – Connected Note: This is determined by Start/Stop.
COM_ConnectionState	A	1 – Connected 2 – Connecting (Not applicable) 3 – Disconnected 4 – Logged In (Ready to receive and process commands)
ToDevice	S	Data that should be sent to the COM port.

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

FEEDBACK – VIDEO INPUTS:

VideoInput[x]_Exists	D	Specifies if the video input exists on the device.
VideoInput[x]_IsConnected	D	Specifies if there is a source connected to the video input.
VideoInput[x]_SignalState	A	Specifies the current signal state: 1 – OK – There is a valid input source connected 2 – Unknown – There is no input source connected 3 – Unsupported – The current source is not supported
VideoInput[x]_ConnectorType	A	Specifies the connector type of the input: 1 - Camera 2 – Composite 3 – DVI 4 – 3G-SDI 5 – HDMI 6 – USB 7 – Unknown 8 – VGA 9 – Component 10 – HD-SDI
VideoInput[x]_ResolutionHeight	S	The resolution height of the connected video source. This will be 0 if there is no source connected.
VideoInput[x]_ResolutionWidth	S	The resolution width of the connected video source. This will be 0 if there is no source connected.
VideoInput[x]_RefreshRate	S	The refresh rate of the connected video source. This will be 0 if there is no source connected.

CONTROL – LOBBY CONTROL:

LobbyActiveParticipantSelect	A	Selects and outputs the specified participant
LobbyParticipantAdmit_[x] (1 – 25)	D	Selects the lobby participant to admit to the collaboration.
LobbyParticipantDeny_[x] (1 – 25)	D	Selects the lobby participant to expel from the collaboration.
LobbyParticipantMute_[x] (1 – 25)	D	Mutes the lobby participant audio in the collaboration.
LobbyParticipantUnmute_[x] (1 – 25)	D	Unmutes the lobby participant audio in the collaboration

FEEDBACK – LOBBY CONTROL:

LobbyTotalNumberOfParticipants	A	Value indicating the total number of participants active/waiting
LobbyNumParticipating	A	Indicates the number of participants in the meeting
LobbyActiveParticipantName	S	Outputs the name of the selected participant

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

LobbyActiveParticipantId	S	Outputs the active participant ID
LobbyParticipantName_[x] (1 – 25)	S	Output to indicate the participant name on the GUI
LobbyParticipantStatus_[x] (1 – 25)	S	Output to indicate the status of the participant in the meeting
LobbyParticipantCallId_[x] (1 – 25)	A	Indicates the call id that the participant is connected to
LobbyParticipantMuteState_[x] (1 to 25)	A	Indicates the mute state of the participant 0 = unmuted 1 = muted

CONTROL – LOBBY WAITING CONTROL:

LobbyWaitingParticipantAdmit_[x] (1 – 25)	D	Selects the waiting participant to admit to the collaboration.

FEEDBACK – LOBBY WAITING CONTROL:

LobbyNumWaiting	A	Indicates the number of participants waiting in the lobby
LobbyWaitingParticipantName_[x] (1 – 25)	S	Output to indicate the waiting participant name on the GUI
LobbyWaitingParticipantStatus_[x] (1 – 25)	S	Output to indicate the status of the participant waiting in lobby
LobbyWaitingParticipantCallId_[x] (1 – 25)	A	Indicates the call id that the waiting participant is connected to

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

CONTROL – MICROST TEAMS MEETING CONTROL:

MicrosoftTeams_JoinMeeting	D	Joins a meeting using the values below.
MicrosoftTeams_Passcode	S	Sets the passcode that will be used when the meeting is joined.
MicrosoftTeams_Title	S	Sets the title that will be used when the meeting is joined.
MicrosoftTeams_TrackingData	S	A tag or labeled that will be stored in the call history.
MicrosoftTeams_URL	S	Sets the URL that will be used when the meeting is joined.

CONTROL – GOOGLE MEETING CONTROL:

GoogleMeet_JoinMeeting	D	Joins a meeting using the values below.
GoogleMeet_MeetingNumber	S	Sets the meeting number that will be used when the meeting is joined.
GoogleMeet_Passcode	S	Sets the passcode that will be used when the meeting is joined.
GoogleMeet_Title	S	Sets the title that will be used when the meeting is joined.
GoogleMeet_TrackingData	S	A tag or labeled that will be stored in the call history
GoogleMeet_URL	S	Sets the URL that will be used when the meeting is joined.

CONTROL – ZOOM MEETING CONTROL:

Zoom_JoinMeeting	D	Joins a meeting using the values below. Dialing into a Zoom meeting is only supported if the Zoom account has SIP dial-in enabled.
Zoom_MeetingID	S	Sets the meeting ID that will be used when the meeting is joined.
Zoom_Hostkey	S	Sets the host key that will be used when the meeting is joined.
Zoom_Passcode	S	Sets the passcode that will be used when the meeting is joined.
Zoom_TrackingData	S	A tag or labeled that will be stored in the call history

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

PARAMETERS:

Username	S	The username that is used in the login sequence. User level determines what commands and feedback are available during run-time. This module will not stop any command from being sent due to user level.
Password	S	The password that is used in the login sequence.
Communication Mode	A	COM – Use the COM port and the COM group of signals. SSH – Use the SSH transport and the SSH group of signals.
SSH Security Mode	A	Unsecure – Allows all connections. Secure – Requires matching host key fingerprints with either user input or using a file in NVRAM (or 'User' with Ethernet Only systems)
LocalPhonebook Download Settings	A	Download All – Downloads all entries in the phonebook when Request is used Download As Needed – Downloads entries when they are needed. Request will limit the search to 500 entries and then continue requesting entries as the user navigates the phonebook using Page Up/Down
LocalPhonebook Provider Name	S	The provider name that is used to specify which phonebook is used on the AddressBook Smart Object.
LocalPhonebook Entries Per Page	A	When Download All is used, this will be used to determine how many entries are outputted on the entry name signals. Valid range: 10-20
CorporatePhonebook Entries Per Page	A	When Download All is used, this will be used to determine how many entries are outputted on theentry name signals. Valid range: 10-20
CallHistory Entries to Download	A	Specifies how many call history entries to download. Valid range: 1-200
UniqueModuleID	S	Required unique ID for the module to use May be up to 100 characters long.

TESTING:

OPS USED FOR TESTING:	RMC3: v1.8000.4522.26360 MC4 v2.8000.00003
SIMPL WINDOWS USED FOR TESTING:	4.2000.00
DEVICE DB USED FOR TESTING:	200.235.001.00

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*

Cisco Room Devices Driver 8.0003

CRES DB USED FOR TESTING:	215.00.003.00
SYMBOL LIBRARY USED FOR TESTING:	1168
REVISION HISTORY:	v. 3.0 – Release v. 3.1 – Feature additions & bug fixes v. 3.2 – Feature additions & bug fixes v 3.2.1 – Bug fixes v 3.2.3 – Feature additions & bug fixes v 3.2.4 – Feature additions & bug fixes v 3.3 – Bug fixes v 3.4 – Updated AddressBook reference & fixes for international characters v 4.0 – Updated for Newtonsoft v4.0.8.0 v 4.1 – International character support fixes, spark protocol support, & bug fixes v 5.0.0 – OSD Keys added. Added Ethernet Only (VC4) Compliance v 6.0.0 – Added lobby feature for Webex v 6.0.1 – Corrected null reference exception when rejecting multiple calls v 6.0.2 – Corrected ignore call references and properly updated call list v6.0.3 – Corrected issue with 3 series boot malfunction v6.0.4 – Remove pagination from Corporate Phonebook (Cisco no longer supports) v7.0.0 – Add ability for module to detect firmware version in codec. Enhance corporate phonebook search functionality v7.0.1 – Add near end camera select feedback v7.002 – Corrected 3 series load issue v8.0002 – Add Web RTC and Zoom support v8.0003 – Add use default connection option for JoinActiveBooking & switched FromDevice input handling from GatherAsyncByLength to Threadsafe

©2017 Crestron Electronics, Inc.
15 Volvo Drive • Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

www.crestron.com
Crestron Certified Integrated Partner Modules can be found archived on our website in the Design Center. For more information please contact our Technical Sales Department at techsales@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CAIP Members, A+ Partners and Certified Integrated Partners only. *Specifications subject to change without notice.*