OTP CRC Check


Ivan Seet 12/05/2023



OTP Store




OTP is store with basic configuration in partition 0(Data Partition)



OTP Store




OTP is store with basic configuration in partition 0(Data Partition)








> FW Patch is store to RAM









- Write 0xB2.
- Write Data 0
 - Return read: Sum of CRC(Header and Data) in partition 0, except
 Partial Data(Config Partial/PMBus Partial)
- Write Data not equal 0
 - Return result is sum of header CRC + data CRC
 - Write Data Format

[0:7]: file system image type see Otp_File_System_Cmd_Types_t


[8:15]: xvalent number 0-15

[16:23]: reserved

[24:31]: otp partition see

Otp_Partition_Selector_t for details


should be number between 0-17;







- Click Read 0xB2 after Write to get the result.
- Note: The sum of CRC is round to 4bytes. The 5th bytes is not display for sum of CRC.





Part of your life. Part of tomorrow.