

PSOC™ Edge E84: Extended Boot training manual

About this document

Scope and purpose

This document is a training manual for the hands-on exercise with an Extended Boot on PSOC™ Edge using ModusToolbox™.

Intended audience

The document is intended for design engineers, technicians, and developers of electronic systems.

Table of contents

Table of contents

About this document.....	1
Table of contents.....	2
1 Introduction	3
2 Required development tools	4
3 Prerequisites	5
4 Replacing Extended Boot	6
4.1 Pre-requisite	6
4.2 Objective.....	6
4.3 Detailed solution	6
4.3.1 Conclusion.....	7
5 SRAM loading of the user application using the Extended Boot.....	8
5.1 Prerequisite	8
5.2 Objective.....	8
5.3 Description	8
5.4 Detailed solution	8
5.4.1 Creating the project	8
5.4.2 Configure proj_cm33_s to run from SRAM	9
5.4.3 Observing the results	11
5.5 Conclusion	11
Revision history.....	12
Disclaimer.....	13

Introduction

1 Introduction

This manual provides specific instructions to create, configure, build, and run the code examples on the PSOC™ Edge E84. In this lab session, you will learn:

- How to replace the Extended Boot on the device with a new version
- Extended Boot capability to copy an image from the external flash to SRAM and launch it from SRAM

Required development tools

2 Required development tools

- ModusToolbox™ software v3.7 or later
 - Recommended installation via [ModusToolbox™ Setup tool](#)
- Eclipse IDE for ModusToolbox™ v2026.1.0 or later
 - Recommended installation via [ModusToolbox™ Setup tool](#)
- Edge Protect Security Suite v1.6 or later.
 - Installed by [ModusToolbox™ Setup tool](#) as a dependency of ModusToolbox™
- ModusToolbox™ Programming Tools v1.7.0 or later
 - Installed by [ModusToolbox™ Setup tool](#) as a dependency of ModusToolbox™
- Board support package (BSP):
 - KIT_PSE84_EVAL_EPC2: v1.0.0 or later (available with ModusToolbox™)
- Terminal emulator
 - Instructions in this document use Tera Term
- [PSOC™ Edge E84 Evaluation Kit](#) (KIT_PSE84_EVAL)
 - Ensure device boots from external memory:
 - BOOT SW/SW6 in 'ON/HIGH' position
 - Disable alternate serial interface configuration:
 - J20/J21 in Tristate/Not-Connected (NC) position

Prerequisites

3 Prerequisites

Install all required software and hardware listed in the [Required development tools](#) section.

Note that this class will not cover the basics of ModusToolbox™ and PSOC™ Edge.

- For an introduction to PSOC™, including a getting started guide to ModusToolbox™, go to: <https://www.infineon.com/product-information/psocdeveloper>
- For PSOC™ Edge trainings, from beginner tutorials to advanced trainings, go to: [PSOC™ Edge E84 Training Collection](#)

Replacing Extended Boot

4 Replacing Extended Boot

4.1 Pre-requisite

To replace the Extended Boot, you should have already taken ownership of the device via the provisioning process. **Training Manual for getting started with PSOC™ Edge E84 Security using ModusToolbox™** provides detailed step-by-step instructions. If you have not already followed those steps, please complete them before getting further into this lab session.

4.2 Objective

The objective of this lab session is to understand how to replace the Extended Boot on PSOC™ Edge devices. You can replace the Extended Boot on the device with the version that is shipped with Edge Protect Tools.

4.3 Detailed solution

1. Follow the step-by-step instructions provided in the **Training Manual for getting started with PSOC™ Edge E84 Security using the ModusToolbox™** guide to obtain the device ownership. If you have already completed the steps to obtain ownership, you need not re-obtain the ownership.
2. Run the command below to observe the version of the Extended Boot.

```
edgeprotecttools -t pse84 device-info
```

3. Open the policy file *policy_oem_provisioning.json* located in *<application-directory>/policy/* directory.
4. Update the *extended_boot_image* policy with an absolute path to the Extended Boot image. For example, see the “value” field in the policy below, which points to the new version of the Extended Boot image.

```
"extended_boot_image": {  
    "description": "Image of Extended Boot in CBOR format, signed by IFX",  
  
    "value": "C:/WS/PSOC_Edge_Basic_Secure_App/packets/apps/prov_oem/extended-  
boot- serial.cbor"  
}
```

5. Now, provision the device using the following command and observe the log message that indicates provisioning completed successfully.

```
edgeprotecttools -t pse8xs2 provision-device -p  
policy/policy_oem_provisioning.json --key keys/oem_private_key_0.pem --ifx-  
oem-cert packets/apps/prov_oem/oem_cert.bin
```

Replacing Extended Boot

```

: O : INFO : ** Detected Device: PSE846GPS2DBZC4A
: O : INFO : ** SROM Boot version: 2.0.0.6022
: O : INFO : ** RRAM Boot version: 2.0.0.7127
: O : INFO : ** SE RT Services Base version: 1.0.0.2361
: O : INFO : ** SE RT Services version: 0.0.0.0
: O : INFO : ** Extended Boot version: 1.1.0.1700
: O : INFO : ** Boot Status : CYBOOT_SUCCESS
: O : INFO : ** Life Cycle : DEVELOPMENT
: O : INFO : Info : [catld.sys] Examination succeed
: O : INFO : Info : gdb port disabled
: O : INFO :
: O : INFO : TargetName      Type      Endian TapName      State
: O : INFO : -----
: O : INFO : 0* catld.sys      mem_ap      little catld.cpu      halted
: O : INFO : Info : Listening on port 6668 for tcl connections
: E : INFO : Chip lifecycle stage: DEVELOPMENT
: E : INFO : ROM Boot is ready for DLM package upload
: E : INFO : Load application 'C:\workspace\Security_Intro\Basic_secure_app\packets\apps\prov_oem\cyapp_prov_oem_dlm.he
x'
: E : INFO : Validation of the DLM package success
: E : INFO : Start DLM package execution
: E : INFO : Application execution completed with status code: (0xf2a00001) - CYAPP_SUCCESS: The provisioning applicati
on completed successfully
: E : INFO : Chip lifecycle stage: DEVELOPMENT
: E : INFO : *****
: E : INFO : PROVISIONING PASSED
: E : INFO : *****

```

Figure 1 Terminal output for provisioning

- On the successful completion of the provisioning, the Extended Boot is replaced. The updated version of the Extended Boot will be displayed on the console, as shown in [Figure 2](#). Compare this version with the one shown before the replacement to confirm the update.

```

: INFO : ** Silicon: 0xED94, Family: 0x115, Rev.: 0x21 (B0)
: INFO : ** Detected Device: PSE846GPS2DBZC4A
: INFO : ** SROM Boot version: 2.0.0.6022
: INFO : ** RRAM Boot version: 2.0.0.7127
: INFO : ** SE RT Services Base version: 1.0.0.2361
: INFO : ** SE RT Services version: 0.0.0.0
: INFO : ** Extended Boot version: 1.1.0.1700
: INFO : ** Boot Status : CYBOOT_SUCCESS
: INFO : ** Life Cycle : DEVELOPMENT

```

Figure 2 Extended Boot version

Note: Replacement of Extended Boot is not necessarily an update or downgrade of Extended Boot. You can replace the image on the device with the same version.

4.3.1 Conclusion

The Extended Boot on the device has been replaced with the latest version provided in the Edge Protect Tools.

SRAM loading of the user application using the Extended Boot

5 SRAM loading of the user application using the Extended Boot

5.1 Prerequisite

You should have completed the ownership transfer via the provisioning process in the previous lab, **Training manual for getting started with PSOC™ Edge E84 Security using ModusToolbox™**.

5.2 Objective

By default, the ‘Basic Secure Application’ code example is configured to program and run from external flash. All three projects (proj_cm33_s, proj_cm33_ns, and proj_cm55) in this code example are built, programmed, and executed in-place from external flash. Upon reset, the Extended Boot searches for a valid image (in MCUboot format) in the predefined location and launches it. For the Extended Boot to search for the image in external flash, the boot source must be set to external flash.

In this lab session, let us learn how to load a project from an external flash to SRAM and launch it in SRAM. Before that, let us first understand the fundamental design concepts for this use case.

5.3 Description

The ‘Basic Secure Application’ code example is built to boot from the external flash (XIP).

To select the boot source in external flash, the BOOT Pin and Boot Policy must be set accordingly.

1. Default policy defines oem_alt_app_address as 0x7010_0000, which is in external flash. This is the default start address of the application if external flash is selected as a boot source.
2. Default policy also enables oem_alt_boot, which indicates alternate boot option is enabled.
3. To select external flash as the boot source, BOOT.1 Pin (BOOT SW) (P17.6) must be in 'ON/HIGH' position.

Note: This is a DIY (Do it yourself) lab exercise. Look into the detailed solution below, only if you need guidance.

5.4 Detailed solution

5.4.1 Creating the project

This hands-on session uses the ‘Basic Secure Application’ code example. This is the same code example that is used in the “Introduction to PSOC™ Edge Security” training. See the “Training Manual for getting started with PSOC™ Edge E84 Security using ModusToolbox™” for more details.

To create a new Basic Secure code example, follow the detailed instructions provided in the **Introduction to PSOC™ Edge Security** lab session.

Note: The code example is configured to use the GCC_ARM compiler by default. We use the same compiler in this lab session.

SRAM loading of the user application using the Extended Boot

5.4.2 Configure proj_cm33_s to run from SRAM

In the default configuration, proj_cm33_s of Basic Secure Application is built to run from an external flash. Modify the default memory map and linker to run it from SRAM.

1. Select **Basic Secure App** in the Project Explorer and open the **Device configurator** from the Quick Panel.




Figure 4 Open Device Configurator

2. Under the **Memory** tab, add a new region in SRAM for loading the CM33 S project.




Figure 3 Create a new region for SRAM loading

SRAM loading of the user application using the Extended Boot

Note: You may need to adjust the existing regions in the default memory map to make space.

3. Save the configuration in the **Device Configurator** and close.
4. In the Basic Secure Application, open the cm33s linker file in editor
`<pathto>PSOC_Edge_Basic_Secure_App/bsps/
TARGET_APP_KIT_PSE84_EVAL_EPC2/COMPONENT_CM33/TOOLCHAIN_GCC_ARM/pse84_s_cm33.ld` and make the following change in linker file.
5. Find and replace all **m33s_nvm_sel_S** with **m33s_sram_load_sel_S** and save your changes.




Figure 4 Edit CM33 S linker

6. Open the file `<pathto>PSOC_Edge_Basic_Secure_App/configs/boot_with_extended_boot.json` and add the following additional “load-address” input for the sign command and save.

```
{
  "command" : "sign",
  "inputs" :
  [
    {
      "file" : "../build/project_hex/proj_cm33_s.hex",
      "header-size": "0x400",
      "fill-value" : "0xff",
      "slot-size" : "0x240000",
      "hex-address" : "{{CYMEM_CM33_0_S_m33s_nvm_S_START}}",
      "load-address" : "{{CYMEM_CM33_0_S_m33s_sram_load_S_START}}"
    }
  ],
}
```

7. If the cm33_s application contains veneer files, remove them. This is required because the address of the secure project was modified after the last build.

SRAM loading of the user application using the Extended Boot


8. Build and program the Basic Secure Application in the ModusToolbox™.

Note: The Instructions to build and program are the same as the previous lab in the previous session – “Introduction to PSOC™ Edge Security”. See the “Training Manual for getting started with PSOC™ Edge E84 Security using ModusToolbox™” for more details.

9. Ensure that the BOOT.1-pin (SW6) is in HIGH/ON position. This is required for the Extended Boot to determine the external flash as the boot source.

5.4.3 Observing the results

1. Observe the console logs for successful booting of the Basic Secure Application.
2. Observe that the red LED is blinking on the device.



```
***** PSOC Edge MCU: Basic Secure Application *****  
Welcome to Basic Secure Application!!!  
For more projects, visit our code examples repositories:  
https://github.com/Infineon/Code-Examples-for-ModusToolbox-Software
```

Figure 5 Terminal output

5.5 Conclusion

The secure project (proj_cm33_s) in the Basic Secure Application is programmed to the external flash. The Extended Boot copies it to SRAM and launches it from there.

Revision history

Revision history

Document revision	Date	Description of changes
**	2025-12-10	Initial release
*A	2026-03-03	Update the version of tools. Updated instructions and screenshot for lab 2.

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition 2026-03-03

Published by

Infineon Technologies AG
81726 Munich, Germany

© 2026 Infineon Technologies AG.
All Rights Reserved.

Do you have a question about this document?

Email:
erratum@infineon.com

Important Notice

Products which may also include samples and may be comprised of hardware or software or both ("Product(s)") are sold or provided and delivered by Infineon Technologies AG and its affiliates ("Infineon") subject to the terms and conditions of the frame supply contract or other written agreement(s) executed by a customer and Infineon or, in the absence of the foregoing, the applicable Sales Conditions of Infineon. General terms and conditions of a customer or deviations from applicable Sales Conditions of Infineon shall only be binding for Infineon if and to the extent Infineon has given its express written consent.

For the avoidance of doubt, Infineon disclaims all warranties of non-infringement of third-party rights and implied warranties such as warranties of fitness for a specific use/purpose or merchantability.

Infineon shall not be responsible for any information with respect to samples, the application or customer's specific use of any Product or for any examples or typical values given in this document.

The data contained in this document is exclusively intended for technically qualified and skilled customer representatives. It is the responsibility of the customer to evaluate the suitability of the Product for the intended application and the customer's specific use and to verify all relevant technical data contained in this document in the intended application and the customer's specific use. The customer is responsible for properly designing, programming, and testing the functionality and safety of the intended application, as well as complying with any legal requirements related to its use.

Unless otherwise explicitly approved by Infineon, Products may not be used in any application where a failure of the Products or any consequences of the use thereof can reasonably be expected to result in personal injury. However, the foregoing shall not prevent the customer from using any Product in such fields of use that Infineon has explicitly designed and sold it for, provided that the overall responsibility for the application lies with the customer.

Infineon expressly reserves the right to use its content for commercial text and data mining (TDM) according to applicable laws, e.g. Section 44b of the German Copyright Act (UrhG). If the Product includes security features:

Because no computing device can be absolutely secure, and despite security measures implemented in the Product, Infineon does not guarantee that the Product will be free from intrusion, data theft or loss, or other breaches ("Security Breaches"), and Infineon shall have no liability arising out of any Security Breaches.

If this document includes or references software:

The software is owned by Infineon under the intellectual property laws and treaties of the United States, Germany, and other countries worldwide. All rights reserved. Therefore, you may use the software only as provided in the software license agreement accompanying the software.

If no software license agreement applies, Infineon hereby grants you a personal, non-exclusive, non-transferable license (without the right to sublicense) under its intellectual property rights in the software (a) for software provided in source code form, to modify and reproduce the software solely for use with Infineon hardware products, only internally within your organization, and (b) to distribute the software in binary code form externally to end users, solely for use on Infineon hardware products. Any other use, reproduction, modification, translation, or compilation of the software is prohibited. For further information on the Product, technology, delivery terms and conditions, and prices, please contact your nearest Infineon office or visit <https://www.infineon.com>