

AIO Printer QuickStart Guide

Contents

- QuickStart.....3**
 - Whats in the Box.....3
 - Unpack the Box and Assemble Printer.....4
 - Printer Components.....5
 - Operation Panel.....6
 - Install Ink Cartridges.....7
 - Load the Paper.....9
 - Paper Loading Guidelines.....9
 - Connect the Printer to the Computer.....9
- Index.....10**

QuickStart

It's easy to start using your new AIO series printer!

Related concepts

[Whats in the Box](#) on page 3

All the components you need to get started are in one box.

[Printer Components](#) on page 5

Take a moment to become familiar with the printer.

Whats in the Box

All the components you need to get started are in one box.

The AIO includes the following items:





Ink — 4 PERMAInk® Ink cartridges (ABC-10 standard-capacity Black, Cyan, Magenta, and Yellow ink cartridges)



CD-ROMs — Software / drivers



Paper — Sample pack



User Assistance — *QuickStart Guide* and *User Guide*

Related concepts

[QuickStart](#) on page 3

It's easy to start using your new AIO series printer!

Related tasks

[Unpack the Box and Assemble Printer](#) on page 4

The first step is to unpack the items in the box.

Unpack the Box and Assemble Printer

The first step is to unpack the items in the box.

Prepare a clean place where you have space to layout all the items in the box.

You must provide a USB cable to connect the printer to your computer. If you are connecting the printer to a network, you need a LAN cable.

1. Lay out all the items from the box and group like items together.
For example, keep all ink cartridges together.
2. Verify that you have all the items that should be in the box.
3. Place the printer in the location where you intend to use it.
The printer must be close enough to your computer for the USB cable to connect it to the computer.
4. Remove the packaging materials from the paper tray and insert the tray in the front of the printer.
5. Remove the packaging materials from the secondary paper tray and insert the tray in the back of the printer.
6. Remove the packaging materials from the automatic document feeder tray and insert the tray on the top of the printer.
7. Connect the power cord to the printer and plug the power cord into the wall.

Related concepts

[Whats in the Box](#) on page 3

All the components you need to get started are in one box.

Printer Components

Take a moment to become familiar with the printer.

External View

Click on the numbers to find out more about the printer components.



1. LCD Display Panel
2. Fax Button
3. OK Button
4. Setup Button
5. Operation Panel
6. Eco Mode Button
7. The Paper Tray
8. Operation Panel
9. LCD Display Panel

Related concepts

[QuickStart](#) on page 3

It's easy to start using your new AIO series printer!

Operation Panel

The operation panel of the printer is described.



The Operation Panel is used to operate the printer and to configure the settings.

Table 1: Operation Panel Descriptions

Function	Description
Address Button	The address button of the printer.
Redial Button	Redials the last fax number called.
Dialtone Button	Toggles the dialtone between speaker mode and silent mode.
Numeric Keypad	Enter phone numbers using the numeric keypad.
LCD Display Panel	Errors and progress messages will be displayed within the LCD Display Panel.
Setup Button	Use the Setup Button to access the printer configuration menus.
Eco Mode Button	The Eco Mode Button allows the printer to enter standby mode.
Back Button	Go back to previous settings.
Copy Button	Use the Copy function of the printer.
Scan Button	Use the Scan function of the printer.
Fax Button	Use the Fax function of the printer.
Photo Button	Use the Photo Printing features of the printer.
OK Button	Press the OK button to start a printer function.
Color Buttons	Print in color.

Install Ink Cartridges

There are four ink cartridges to install.

Use the illustrations as a guide for this procedure.



1. Turn the printer on and open the top of the printer to expose the ink cartridge tray. The ink tray automatically moves to the center of the printer.
2. Open the gate to the ink cartridge tray.
Notice that the ink cartridge tray indicates the proper ink color to install.
3. Unwrap the black ink cartridge and remove the protective tape.
Note: Do not remove or touch the copper contacts on the ink cartridge. Touching these parts may adversely affect the performance of the printer.
4. Gently insert the black ink cartridge into the proper position until it snaps into place.

5. Repeat the steps for each of the ink cartridge positions.

The cartridge tray contains the appropriate ink cartridges for each position.

Load the Paper

The paper tray can accommodate different paper sizes.

1. Raise the top of the paper tray and fully extend the paper width and length adjusters.
2. Place the paper into the tray and gently press the paper guides to the edges of the paper.

For paper larger than 8.5" x 11", pull the paper length guide beyond the edge of the paper tray to accommodate the page length.

For papers that have a right side and a wrong side, such as photo paper, you must load the right or print side down in the paper tray.



CAUTION: Be careful not to cut your fingers on the sharp paper edges.

3. Close the paper tray lid and slide the paper tray into place.
4. Press the **Power** button to turn on the printer.

When you install new ink cartridges, the printer will automatically print a diagnostic page.

Paper Loading Guidelines

To avoid paper jams, it is important that you load the paper properly in the paper tray.

- When loading more than two sheets of paper, align the edges of the sheets before loading.
- Regardless of the print orientation, always load the paper in portrait orientation.
- Load paper print side down in the paper tray.
- Do not load paper past the Maximum Paper line in the paper tray.
- Do not load pages of different sizes in the paper tray at the same time.



CAUTION: Be careful not to cut your fingers on the sharp paper edges.

Connect the Printer to the Computer

You connect the printer to the computer using a USB cable.

1. Turn on your computer and insert the *Printer Software* CD-ROM.
2. Install the printer software following the set up wizard instructions.
3. Plug the USB cable into the printer and the computer.

Note: To have improved performance, plug the USB cable directly into the computer. Do not plug it into a USB hub.

Index

A

automatic document feeder tray [4](#)

C

cables

USB [9](#)

CD-ROMs

in box [3](#)

Printer Software [9](#)

cords

power [3, 4](#)

telephone [3](#)

D

diagnostic pages [9](#)

documentation [3](#)

I

ink cartridges [3](#)

installing [7](#)

L

loading paper [9](#)

guidelines [9](#)

O

operation panel [5](#)

P

paper [3](#)

loading [9](#)

loading guidelines [9](#)

paper trays [3, 4](#)

power cord [3, 4](#)

printer components [5](#)

S

setting up

installing ink cartridges [7](#)

loading paper [9](#)

software

Printer Software CD-ROM [9](#)

T

telephone cord [3](#)

U

USB cable [9](#)

user assistance [3](#)