

920AIO Printer Troubleshooting Guide

Contents

- Troubleshooting.....3**
 - Unable to Print Diagnostic Page..... 3
 - Improve Print Quality.....3
 - Improve Copy Quality.....4
 - Printer Error Codes.....5
 - Clear Paper Jams..... 5
 - Install Ink Cartridges.....6
- Index.....8**

Troubleshooting

Follow these instructions to correct common issues.

Unable to Print Diagnostic Page

The diagnostic page prints when you install new ink cartridges or reset the printer after clearing a paper jam.

The common causes for not being able to print the diagnostic page are:

- Paper jam inhibits printing.
 - Ink cartridges are low or empty.
 - Paper tray is empty.
1. Have you cleared any jammed paper from the printer?
 - If Yes, then go to the [next step](#).
 - If No, then [clear paper jam](#).
 2. Is [Error Code 206](#) displayed on the LCD or are any of the ink cartridges empty?
 - If Yes, then replace the empty ink cartridge.
 - If No, then go to the [next step](#).
 3. Is [Error Code 207](#) displayed on the LCD?
 - If Yes, then properly install ink cartridges.
 - If No, then go to the [next step](#).
 4. Is [Error Code 203](#) displayed on the LCD?

The paper tray must have at least 1 piece of paper.

 - If Yes, then load paper.
 - If No, then go to the [next step](#).
 5. Press the **GO** button to print the diagnostic page.

Related reference

[Printer Error Codes](#) on page 5

Error codes are displayed on the LCD when a diagnosable error occurs.

Improve Print Quality

If the quality of your printed documents does not meet your expectations, there are common causes to address.

Common causes of poor print quality are:

- Paper loaded improperly.
 - Paper type needs to be appropriate for document type.
 - Print quality setting is too low for the type of document.
 - Ink cartridges are low or empty.
1. Identify the specific issues with the print quality.
 - If the colors are wrong, then go to [step 2](#).
 - If the print output is fuzzy or blurry, then go to [step 3](#).
 2. Is [Error Code 206](#) displayed on the LCD or are any of the ink cartridges empty?
 - If Yes, then [replace the empty ink cartridge](#).

- In No, then go to [step 3](#).
3. Is the paper loaded with the right or print side down?
- For papers that have a right side and a wrong side, such as photo paper, you must load the right or print side down in the paper tray.
- If Yes, then go to the [next step](#).
 - In No, place the paper in the tray with the print side down.
4. If you are printing a photograph or an illustration, do you have proper paper in the paper tray?
- If Yes, then go to the [next step](#).
 - If No, place the appropriate paper in the tray right side down.
- For example, if you want to print a photograph with good quality, you must use photo paper.
5. Is the print quality set to High?
- When you print a document from the computer, the document application allows you to specify the settings, including the quality, for the printer.
- In Yes, then go to the BestTech, Inc. web site(<http://www.besttechoffice.com> <http://www.besttechoffice.de> .
 - If No, then you need to change the print quality setting.

Related reference

[Printer Error Codes](#) on page 5

Error codes are displayed on the LCD when a diagnosable error occurs.

Improve Copy Quality

If the quality of your copies does not meet your expectations, there are common causes to address.

Perform the [Improve Print Quality](#) steps.

Common causes of poor copy quality are:

- Mismatched paper size with the size of the original document.
 - Original document is not properly loaded.
 - Original document is loaded with the wrong side facing up.
 - There is dirt on the original document or in the printer.
1. Is the copy missing content at the bottom of the page?
- If Yes, then the paper is shorter than your original document and you must replace the paper with paper of the proper size.
 - If No, then go to [step 2](#).
2. Is copy crooked?
- If Yes, then adjust the original in the ADF or on the Document Glass.
 - In No, then go to [step 3](#).
3. Is the copy blank?
- If Yes, then the original is facing the way and you must load it with the right side facing down.
 - In No, then go to [step 4](#).
4. Does the copy have marks or smudges on it?
- If Yes, then there is dirt on the original document, in the ADF or on the Document Glass, which you need to remove.
 - In No, then go to the BestTech, Inc. web site(<http://www.besttechoffice.com> <http://www.besttechoffice.de> .

Related reference

[Printer Error Codes](#) on page 5

Error codes are displayed on the LCD when a diagnosable error occurs.

Printer Error Codes

Error codes are displayed on the LCD when a diagnosable error occurs.

Error Code	Description
Error Code 202	Paper jam. Refer to Clear Paper Jams to resolve.
Error Code 203	Paper tray is empty
Error Code 205	Ink is low in cartridge
Error Code 206	Ink cartridge is empty
Error Code 207	Ink cartridge is not properly installed
Error Code 310	No dial tone
Error Code 312	Cannot connect to number

Clear Paper Jams

Paper jams occur when the paper from the paper tray misfeeds in the printer.

Note: Cancel print jobs and turn off the printer before attempting to remove jammed paper.

Common causes of paper jams are:

- Paper is not loaded properly.
- And some changes are made to the topics.
- Paper is the wrong type for the printer.
- Too much paper is loaded in paper tray.



1. Is Error Code 202 displayed on the LCD?

- If Yes, then go to the [next step](#).

- If No, then go to search.
- 2. Is there paper sticking out of your printer?
 - If Yes, then go to the [next step](#).
 - If No, then go to [step 5](#).
- 3. Release the paper by opening the printer at panel A and lifting the lever.
[Continue](#).
- 4. Check for remaining paper behind panel B.
[Continue](#).
- 5. Insert new paper in the paper tray.
[Continue](#).
- 6. Check the secondary paper tray.
The is the external paper tray on the bottom of the main paper tray.
- 7. Press the **OK** button.
Did the diagnostic page print correctly?
 - If Yes, then you have successfully cleared the paper jam.
 - If No, then go to [Unable to Print Diagnostic Page](#).

Related reference

[Printer Error Codes](#) on page 5

Error codes are displayed on the LCD when a diagnosable error occurs.

Install Ink Cartridges

There are four ink cartridges to install.

Use the illustrations as a guide for this procedure.



1. Turn the printer on and open the top of the printer to expose the ink cartridge tray. The ink tray automatically moves to the center of the printer.

2. Open the gate to the ink cartridge tray.

Notice that the ink cartridge tray indicates the proper ink color to install.

3. Unwrap the black ink cartridge and remove the protective tape.

Note: Do not remove or touch the copper contacts on the ink cartridge. Touching these parts may adversely affect the performance of the printer.

4. Gently insert the black ink cartridge into the proper position until it snaps into place.

5. Repeat the steps for each of the ink cartridge positions.

The cartridge tray contains the appropriate ink cartridges for each position.

Index

C

copying
improving quality [4](#)

D

diagnostic pages
unable to print [3](#)

E

error codes [5](#)

I

ink cartridges
installing [6](#)

P

paper jams
clearing [5](#)
printing
improving quality [3](#)

Q

quality
improving copy [4](#)
improving print [3](#)

S

setting up
installing ink cartridges [6](#)

T

troubleshooting [3](#)

U

user assistance
troubleshooting [3](#)