



AIO User Guide

Contents

[CHANGED] 1. Introduction.....	3
2. QuickStart.....	5
2.1. Whats in the Box.....	5
2.2. Unpack the Box and Assemble Printer.....	6
2.3. Printer Components.....	6
2.3.1. Operation Panel.....	7
2.4. Install Ink Cartridges.....	8
2.5. Load the Paper.....	9
2.5.1. Paper Loading Guidelines.....	10
2.6. Connect the Printer to the Computer.....	10
3. Printing.....	11
3.1. Print from the Computer.....	11
3.1.1. Print with QuickPrint.....	11
3.1.2. Set Printing Preferences.....	11
3.1.3. Print Documents.....	11
3.2. Print from a Memory Card.....	12
4. Copying.....	13
4.1. Copy a Single Page.....	13
4.2. Copy Multiple Pages.....	13
4.3. Copy Both Sides of a Document.....	13
[NEW] 5. Your Photo Printer.....	14
[NEW] 5.1. View and Select Photos.....	14
[NEW] 5.2. Print Photos.....	14
[NEW] 5.3. Photo Printing from Media Card.....	15
6. Troubleshooting.....	16
6.1. Unable to Print Diagnostic Page.....	16
6.2. Improve Print Quality.....	16
6.3. Improve Copy Quality.....	17
6.4. Printer Error Codes.....	17
6.5. Clear Paper Jams.....	17
6.6. Install Ink Cartridges.....	18
7. Support.....	20
8. Specifications.....	21

1. Introduction

The BestTech AIO printer is great choice for home offices and small businesses. It is a true All-In-One printer.

Printer

Print color or black and white documents quickly and easily from your computer. The AIO printer has settings to properly print stapled documents, booklets, brochures, and posters.

You can print photos from your computer or memory cards. In addition to controlling the picture print quality, you can enlarge or reduce photos, print them without borders, and manipulate the color settings.

Copier

You can copy and collate large documents using the automatic document feeder (ADF) and copy double-sided documents onto single or double-sided pages. If you have multiple small items, such as receipts, that you need to copy onto a single page, you can use the Document Glass instead of the ADF.

Scanner

If you want to create a digital file of a document or photo, scan it in and select which format in which you want to store it. You can scan single or multiple page documents in one or more files.

Fax Machine

You can quickly send or receive faxes using efficiency features, such as storing commonly dialed phone numbers.

Photo Printing





You can easily print photos with the color printing features of the AIO printer.

2. QuickStart

It's easy to start using your new AIO series printer!

2.1. Whats in the Box

All the components you need to get started are in one box.

The AIO includes the following items:

	paper tray, and secondary external paper tray
	Telephone cord
	Power cord
	Ink — 4 PERMAInk ^(R) Ink cartridges (ABC-10 standard-capacity Black, Cyan, Magenta, and Yellow ink cartridges)

	CD-ROMs — Software / drivers
	Paper — Sample pack
	User Assistance — <i>QuickStart Guide</i> and <i>User Guide</i>

2.2. Unpack the Box and Assemble Printer

The first step is to unpack the items in the box.

Prepare a clean place where you have space to layout all the items in the box.

You must provide a USB cable to connect the printer to your computer. If you are connecting the printer to a network, you need a LAN cable.

1. Lay out all the items from the box and group like items together. For example, keep all ink cartridges together.
2. Verify that you have all the items that should be in the box.
3. Place the printer in the location where you intend to use it. The printer must be close enough to your computer for the USB cable to connect it to the computer.
4. Remove the packaging materials from the paper tray and insert the tray in the front of the printer.
5. Remove the packaging materials from the secondary paper tray and insert the tray in the back of the printer.
6. Remove the packaging materials from the automatic document feeder tray and insert the tray on the top of the printer.
7. Connect the power cord to the printer and plug the power cord into the wall.

2.3. Printer Components

Take a moment to become familiar with the printer.

External View

Click on the numbers to find out more about the printer components.



2.3.1. Operation Panel

The operation panel of the printer is described.



The Operation Panel is used to operate the printer and to configure the settings.

Operation Panel Descriptions

Function	Description
Address Button	The address button of the printer.
Redial Button	Redials the last fax number called.
Dialtone Button	Toggles the dialtone between speaker mode and silent mode.
Numeric Keypad	Enter phone numbers using the numeric keypad.

Function	Description
LCD Display Panel	Errors and progress messages will be displayed within the LCD Display Panel.
Setup Button	Use the Setup Button to access the printer configuration menus.
Eco Mode Button	The Eco Mode Button allows the printer to enter standby mode.
Back Button	Go back to previous settings.
Copy Button	Use the Copy function of the printer.
Scan Button	Use the Scan function of the printer.
Fax Button	Use the Fax function of the printer.
Photo Button	Use the Photo Printing features of the printer.
OK Button	Press the OK button to start a printer function.
Color Buttons	Print in color.

2.4. Install Ink Cartridges

There are four ink cartridges to install.

Use the illustrations as a guide for this procedure.



1. Turn the printer on and open the top of the printer to expose the ink cartridge tray. The ink tray automatically moves to the center of the printer.
2. Open the gate to the ink cartridge tray. Notice that the ink cartridge tray indicates the proper ink color to install.
3. Unwrap the black ink cartridge and remove the protective tape.



Do not remove or touch the copper contacts on the ink cartridge. Touching these parts may adversely affect the performance of the printer.
4. Gently insert the black ink cartridge into the proper position until it snaps into place.
5. Repeat the steps for each of the ink cartridge positions.

The cartridge tray contains the appropriate ink cartridges for each position.

2.5. Load the Paper

The paper tray can accommodate different paper sizes.

1. Raise the top of the paper tray and fully extend the paper width and length adjusters.
2. Place the paper into the tray and gently press the paper guides to the edges of the paper. For paper larger than 8.5" x 11", pull the paper length guide beyond the edge of the paper tray to accommodate the page length. For papers that have a right side and a wrong side, such as photo paper, you must load the right or print side down in the paper tray.



Be careful not to cut your fingers on the sharp paper edges.

3. Close the paper tray lid and slide the paper tray into place.
4. Press the **Power** button to turn on the printer. When you install new ink cartridges, the printer will automatically print a diagnostic page.

2.5.1. Paper Loading Guidelines

To avoid paper jams, it is important that you load the paper properly in the paper tray.

- When loading more than two sheets of paper, align the edges of the sheets before loading.
- Regardless of the print orientation, always load the paper in portrait orientation.
- Load paper print side down in the paper tray.
- Do not load paper past the Maximum Paper line in the paper tray.
- Do not load pages of different sizes in the paper tray at the same time.



Be careful not to cut your fingers on the sharp paper edges.

2.6. Connect the Printer to the Computer

You connect the printer to the computer using a USB cable.

1. Turn on your computer and insert the *Printer Software* CD-ROM.
2. Install the printer software following the set up wizard instructions.
3. Plug the USB cable into the printer and the computer.



To have improved performance, plug the USB cable directly into the computer. Do not plug it into a USB hub.

3. Printing

You can print single- or double-sided documents in black-and-white or in color.

3.1. Print from the Computer

*When you print a document from an application on the computer, you can select the **BestTech AIO** printer.*

You can specify printing settings each time you print or use the default settings.

3.1.1. Print with QuickPrint

The QuickPrint feature automatically sets paper source, print quality, and color.

The default QuickPrint settings are:

- Paper source — paper tray.
- Print quality — standard.
- Color — auto.

1. From the application that contains the document, select the print command. The Print dialog box opens.
2. Select the **BestTech AIO** printer from the printer list.
3. Select Print. The currently open document prints using the QuickPrint settings.

3.1.2. Set Printing Preferences

You can control how you print by setting preferences for default printing.

The Printer Preferences dialog box organizes the available controls on tabbed pages by function.

1. From the application that contains the document, select the print command. The Print dialog box opens.
2. Click Preferences. The Printer Preferences dialog box opens.
3. Specify the settings that you want to be the default settings when you print, then click OK.

3.1.3. Print Documents

There are common settings that you need to consider when printing documents.

Common document choices:

- Print on both sides of the paper (duplex printing).
- Adjust margins for stapling.
- Collate pages for multiple copies.



Do not print with the document cover open. The bright light is dangerous to your eyes.

1. Open the document in the appropriate application on the computer.
2. Select the print command to print the photo. The Print dialog box opens.
3. Click Preferences. The Printer Preferences dialog box opens.
4. If you want to print on both sides of the paper, then select the Duplex checkbox on the Page Setup tab.
5. If you want to staple the document pages, select the staple location in the Staple Placement list on the Page Setup tab.
6. To print multiple copies and have the pages properly organized:
 - a. Select the Collate checkbox on the Page Setup tab.
 - b. Specify the number of copies to make in the Copies field on the Main tab.
7. Select Print.

3.2. Print from a Memory Card

You can print directly from a memory card.

Verify that the memory card is supported for the printer.

Photos print best on photo paper; if you print a photo on non-photo paper, the image quality may be poor.

1. Turn the printer on.
2. Insert the memory card in the card slot. Your memory card may require an adapter.
3. Verify that the **Data** light has turned on.
4. Press the **Print** button.
5. On the LCD, select Show Photo option. The most recently stored graphic file is displayed on the LCD.
6. Select the photo to print.
7. Press the **GO** button. The printer prints the selected photo on the paper in the paper tray.

4. Copying

You can copy one or more pages of a document.

4.1. Copy a Single Page

Use the document glass to copy a single page document.

1. Turn the printer on.
2. Press the **Copy** button.
3. Open the document cover.
4. Place the original document print side down on the glass.



Do not place heavy objects on the glass.

5. Align the document with the guides on the glass.
6. Carefully close the document cover.
7. Use the number buttons to specify the number of copies to make. The default is one copy.
8. Specify to make black-and-white or color copies.
9. Press the **GO** button. The printer delivers the copies through the Document Output Feeder.

4.2. Copy Multiple Pages

Use the automatic document feeder (ADF) to copy multiple page documents.

1. Turn the printer on.
2. Press the **Copy** button.
3. Load the original document in the ADF with the print side down. The maximum number of pages you can load in the ADF is 30 pages.
4. Use the number buttons to specify the number of copies to make. The default is one copy.
5. Specify to make black-and-white or color copies.
6. Press the **GO** button. The printer delivers the copies through the Document Output Feeder.

4.3. Copy Both Sides of a Document

Use the Automatic Document Feeder (ADF) to copy both sides of an original document.

You can copy double-sided documents and generate copies the following:

- Two sides to two sides (1 double-sided page to 1 double-sided page)
- Two sides to one side (1 double-sided page to 2 single-sided pages)
- Two single page documents onto the a double-sided page (2 single-sided pages to 1 double-sided page)

1. Turn the printer on.
2. Press the **Copy** button.
3. Load the original document in the ADF with the print side down. The maximum number of pages you can load in the ADF is 30 pages.
4. Press the **Two-sided copy** button, then select the copying method with the number buttons.
 - To copy 1 double-sided page to 1 double-sided page, press the **1** button.
 - To copy 1 double-sided page to 2 single-sided pages, press the **2** button.
 - To copy 2 single-sided pages to 1 double-sided page, press the **3** button.
5. Use the number buttons to specify the number of copies to make. The default is one copy.
6. Specify to make black-and-white or color copies.
7. Press the **GO** button. The printer delivers the copies through the Document Output Feeder.

5. Your Photo Printer

Your Photo-powered Printer provides all the capabilities to print from your computer or camera.

With Photo-powered capabilities, print all of your favorite photos.

You can print from your computer, a Memory Stick, a Compact Flash (CF) or directly from your camera using a cable.

You can also use wi-fi to print photos from a Bluetooth enabled camera or phone.

5.1. View and Select Photos

How to view and select photos with a media card.

View and select photos.

1. Insert a media card into the appropriate slot on the All-in-One.
2. Load up to 13 x 18 cm photo paper in the photo tray or full size photo
3. Press the arrow until View is highlighted, and then press **OK**.
4. Press the arrows to scroll through the thumbnails of your photos.
5. When the thumbnail of the photo you want to view is highlighted, press **OK**.
6. As soon as the photo appears by itself on the display, press **OK** again.
The **Photo Options** screen appears
7. With **Print Preview** highlighted, press **OK**. The Print Preview screen displays, showing how your photo looks when printed.
8. If you want to print multiple versions of your photo, press and highlight **Print Many** and then enter the number of versions that you want to print.
9. If you want to select additional photos to view and print, press to highlight **AddMore**, press **OK**, and repeat steps 4–6.
10. To print the photo(s), press to highlight Print Now (or press the Print Photos button on the control panel.)
A print status screen displays the number of pages to print and the estimated time to complete.

5.2. Print Photos

There are common settings that you need to consider when printing photos.

Common photo choices:

- Print in color.
- Print on photo paper.
- Print without a border.
- Print with higher quality.

1. If you want high quality photo printing results, use photo paper and load print side down in the paper tray.
2. Open the photo in the appropriate application on the computer.
3. Select the print command to print the photo. The Print dialog box opens.
4. Click Preferences. The Printer Preferences dialog box opens.
5. Select the paper type.
 - If you are printing on photo paper, then select the proper photo paper type in the Media Type list on the Main tab.
 - If you are printing on regular paper, then verify that the proper paper type is selected in the Media Type list.
6. Specify if you want to print a border around the photo.
 - If you want a border, then check the Print Border checkbox on the Page Setup tab.
 - If you do not want a border, then uncheck the Print Border checkbox on the Page Setup tab.
7. Specify the print quality.

- If you want to print quickly with standard quality, then select the Standard radio button on the Page Setup tab.
- If you want higher print quality and are not concerned about printing speed, then select the High radio button on the Page Setup tab.

8. Select Print.

5.3. Photo Printing from Media Card

Printing photos from media cards or USB drives.

1. Insert a media card or USB key. The printer automatically switches to Photo Mode.
2. Press **Select** to access the **Photo Mode** menu.
3. From the **Photo Mode** menu, use the up or down Arrow buttons to scroll to **Print all photos**, and then press **Select**. The **Print All Photos** menu opens.
4. Specify the number of photos you want to print on each page, and press **Select**.
5. Press **Start**



Only photos stored in the JPG format can be printed directly from the memory card. If you want to print photos stored on the memory card in a different file format, e.g. PNG, the photos must be transferred to your computer before printing.

6. Troubleshooting

Follow these instructions to correct common issues.

6.1. Unable to Print Diagnostic Page

The diagnostic page prints when you install new ink cartridges or reset the printer after clearing a paper jam.

The common causes for not being able to print the diagnostic page are:

- Paper jam inhibits printing.
- Ink cartridges are low or empty.
- Paper tray is empty.

1. Have you cleared any jammed paper from the printer?
 - If Yes, then go to the [next step](#).
 - If No, then [clear paper jam](#).
2. Is displayed on the LCD or are any of the ink cartridges empty?
 - If Yes, then replace the empty ink cartridge.
 - If No, then go to the [next step](#).
3. Is displayed on the LCD?
 - If Yes, then properly install ink cartridges.
 - If No, then go to the [next step](#).
4. Is displayed on the LCD? The paper tray must have at least 1 piece of paper.
 - If Yes, then load paper.
 - If No, then go to the [next step](#).
5. Press the **GO** button to print the diagnostic page.

6.2. Improve Print Quality

If the quality of your printed documents does not meet your expectations, there are common causes to address.

Common causes of poor print quality are:

- Paper loaded improperly.
- Paper type needs to be appropriate for document type.
- Print quality setting is too low for the type of document.
- Ink cartridges are low or empty.

1. Identify the specific issues with the print quality.
 - If the colors are wrong, then go to [step 2](#).
 - If the print output is fuzzy or blurry, then go to [step 3](#).
2. Is displayed on the LCD or are any of the ink cartridges empty?
 - If Yes, then [replace the empty ink cartridge](#).
 - In No, then go to [step 3](#).
3. Is the paper loaded with the right or print side down? For papers that have a right side and a wrong side, such as photo paper, you must load the right or print side down in the paper tray.
 - If Yes, then go to the [next step](#).
 - In No, place the paper in the tray with the print side down.
4. If you are printing a photograph or an illustration, do you have proper paper in the paper tray?
 - If Yes, then go to the [next step](#).
 - If No, place the appropriate paper in the tray right side down.
For example, if you want to print a photograph with good quality, you must use photo paper.
5. Is the print quality set to High? When you print a document from the computer, the document application allows you to specify the settings, including the quality, for the printer.
 - In Yes, then go to the BestTech, Inc. web site(<http://www.besttechoffice.com><http://www.besttechoffice.de>).
 - If No, then you need to change the print quality setting.

6.3. Improve Copy Quality

If the quality of your copies does not meet your expectations, there are common causes to address.

Perform the [Improve Print Quality](#) steps.

Common causes of poor copy quality are:

- Mismatched paper size with the size of the original document.
- Original document is not properly loaded.
- Original document is loaded with the wrong side facing up.
- There is dirt on the original document or in the printer.

1. Is the copy missing content at the bottom of the page?
 - If Yes, then the paper is shorter than your original document and you must replace the paper with paper of the proper size.
 - If No, then go to [step 2](#).
2. Is copy crooked?
 - If Yes, then adjust the original in the ADF or on the Document Glass.
 - In No, then go to [step 3](#).
3. Is the copy blank?
 - If Yes, then the original is facing the way and you must load it with the right side facing down.
 - In No, then go to [step 4](#).
4. Does the copy have marks or smudges on it?
 - If Yes, then there is dirt on the original document, in the ADF or on the Document Glass, which you need to remove.
 - In No, then go to the [BestTech, Inc. web site](http://www.besttechoffice.com)(<http://www.besttechoffice.com><http://www.besttechoffice.de>).

6.4. Printer Error Codes

Error codes are displayed on the LCD when a diagnosable error occurs.

Error Code	Description
Error Code 202	Paper jam. Refer to Clear Paper Jams to resolve.
Error Code 203	Paper tray is empty
Error Code 205	Ink is low in cartridge
Error Code 206	Ink cartridge is empty
Error Code 207	Ink cartridge is not properly installed
Error Code 310	No dial tone
Error Code 312	Cannot connect to number

6.5. Clear Paper Jams

Paper jams occur when the paper from the paper tray misfeeds in the printer.



Cancel print jobs and turn off the printer before attempting to remove jammed paper.

Common causes of paper jams are:

- Paper is not loaded properly.
- And some changes are made to the topics.
- Paper is the wrong type for the printer.
- Too much paper is loaded in paper tray.



1. Is Error Code 202 displayed on the LCD?
 - If Yes, then go to the [next step](#).
 - If No, then go to search.
2. Is there paper sticking out of your printer?
 - If Yes, then go to the [next step](#).
 - If No, then go to [step 5](#).
3. Release the paper by opening the printer at panel A and lifting the lever. [Continue](#).
4. Check for remaining paper behind panel B. [Continue](#).
5. Insert new paper in the paper tray. [Continue](#). [Continue](#).
6. Check the secondary paper tray. This is the external paper tray on the bottom of the main paper tray.
7. Press the **OK** button. Did the diagnostic page print correctly?
 - If Yes, then you have successfully cleared the paper jam.
 - If No, then go to [Unable to Print Diagnostic Page](#).

6.6. Install Ink Cartridges

There are four ink cartridges to install.

Use the illustrations as a guide for this procedure.



1. Turn the printer on and open the top of the printer to expose the ink cartridge tray. The ink tray automatically moves to the center of the printer.
2. Open the gate to the ink cartridge tray. Notice that the ink cartridge tray indicates the proper ink color to install.
3. Unwrap the black ink cartridge and remove the protective tape.
 -  Do not remove or touch the copper contacts on the ink cartridge. Touching these parts may adversely affect the performance of the printer.
4. Gently insert the black ink cartridge into the proper position until it snaps into place.
5. Repeat the steps for each of the ink cartridge positions.

The cartridge tray contains the appropriate ink cartridges for each position.

7. Support

You can get assistance any time - day or night.

Online Support

When you go to the BestTech, Inc. web site(<http://www.besttechoffice.com><http://www.besttechoffice.de>), you simply type in your question and available answers are listed for your selection. The answers could be from any of the following resources:

- Frequently Asked Questions (FAQ) for your product
- Forums for you to ask questions and get answers from other customers
- Knowledgebase maintained and updated regularly by the BestTech technical support staff

Email

You can send questions to the support team from the web site or your email account to besttech_help@besttech.com. The expected response time is 2 days.

Phone

You can call the support team to ask them your question.

Hours:	Monday-Friday 10:00 a.m. - 10:00 p.m. EST, excluding holidays
Phone:	1-888-555-1234 (toll free)
TTD:	1-866-555-1234 (toll free)

Hours:	Monday-Friday 10:00 a.m. - 10:00 p.m. +1 GMT, excluding holidays
Phone:	+49-66 3512 495
TTD:	+49-66 3512 495

Hours:	Monday-Friday 10:00 a.m. - 10:00 p.m. +16 GMT, excluding holidays
Phone:	+65-663512495
TTD:	+65-663512495

8. Specifications

All-In-One functions: Color print, color copy, color scan, color fax

Feature	Description
Print	
Printing Technology	4-color (CMYK) ink jet
Ink Palette	Cyan, Magenta, Yellow, and Black
Ink Cartridge Configuration	4 individual ink cartridges
Ink Type	PERMAInk ^(R) Ultra pigment ink (smudge, fade and water resistant, highlighter friendly)
Fade Resistance / Print Longevity	Up to 105 years
Minimum Ink Droplet Size	3 droplet sizes, as small as 2 picoliters3 picoliters
Maximum Print Resolution	5760 x 1440 optimized dpi
Print Speed	Black text up to 31 ppm35 ppm
	Color text up to 31 ppm35 ppm
PC-free Printing	Print all photos, photo index sheet and color photo restoration
Copy	
Copy Speed	Black up to 31 cpm35 ppm
	Color up to 31 cpm35 ppm
Copy Quality	Color: Black/White, Draft: Normal
Copy Quantity	1 – 90 (PC-free)
Maximum Copy Size	8.5" x 11" (PC-free)A4
Copy Features	Fit to page, automatic reduction and enlargement (25 - 400%)
Fax	
Fax Specifications	Black-and-white and color
	Modem: 33.6 Kbps — as fast as 3 sec per page
	Memory: Up to 150 pages
	Speed dials: 50 (max.)
Scanner	
Scanner Type	Color flatbed
Photoelectric Device	Color CIS line sensor
Optical Resolution	1200 dpi2400 dpi
Hardware Resolution	1200 x 2400 dpi2400 x 2400 dpi
Maximum Resolution	9600 x 9600 dpi interpolated
Scanner Bit Depth	48-bit color / 24-bit output
Photo	
Color Display	2.5" LCD63.5mm LCD
Built-in Memory Card Slots Compatibility	CompactFlash ^(R) , Microdrive ^(R) , Memory Stick ^(R) , Memory Stick Duo ^(TM) , MagicGate ^(TM) Memory Stick, MagicGate Memory Stick Duo ^(TM) , Memory Stick PRO ^(TM) , Memory Stick Pro Duo ^(TM) , Secure Digital (SD ^(TM)), SDHC ^(TM) , mini SD ^(TM) , Memory Stick Micro ^(TM) , micro SD ^(TM) , micro SDHC ^(TM) , MultiMediaCard ^(TM) , xD-Picture Card ^(TM) , xD-Picture Card Type-M, xD-Picture Card Type-M+, xD-Picture Card Type-H
Supported Digital Camera Technologies	Exif Print, DPOF
PC-free Printing	Print all photos, photo index sheet and color photo restoration
PC-free Filters and Image Enhancements	ABC Auto Photo Correction
Paper and Ink	
Maximum Paper Size	8.5" x 44"215.9 mm x 1.1176m

Feature	Description
Paper Sizes	3.5" x 5", 4" x 6", 5" x 7", 8" x 10", 8.5" x 11", 8.5" x 14", A4, B5, A5, A6, half letter, executive, user definable (3.5" – 44" in length)(88.9mm x 1.1176m)
Borderless Photo Sizes	3.5" x 5", 4" x 6", 5" x 7", 8" x 10", 8.5" x 11"A4
Paper Types	Supports plain paper, ABC Bright White Paper, Photo Paper Glossy, Premium Photo Paper Glossy, Ultra Premium Photo Paper Glossy, Premium Photo Paper Semi-gloss, Presentation Paper Matte, Premium Presentation Paper Matte, Premium Presentation Paper Matte Double-sided, and Matte Scrapbook Photo Paper (letter)
Envelope Types	No. 10, DL, C6; plain paper, bond paper, air mail
Input Paper Capacity	100 sheets plain paper, 10 envelopes
Automatic Document Feeder	30 sheets
Recommended Ink Cartridges††	ABC-10 High-capacity Black, Cyan, Magenta and Yellow or ABC-20 Black, Cyan, Magenta, and Yellow
Operation	
Weight and Dimensions (W x D x H)	Printing: 18.5" x 19" x 10.5"469 x 482.6 x 266.7mm
	Storage: 18.5" x 16" x 9.5"469 x 406.4 x 241.3mm
	Weight: 19.5 lbs.8.85 kgs
Connectivity	Hi-Speed USB 2.0
Operating Systems	Windows Vista ^(R) , XP, XP Professional x64, 2000 Mac OS ^(R) X 10.3.9, 10.4.x, and 10.5.x
Software Included	ABC printer driver, ABC Web to Page, ABC Scan, ABC DocuMAX, ABC PhotoCorrector, GB and ICM
Acoustics	Normal mode: 42 dB(A)
	Idle mode: 16 dB(A)
Temperature	Recommend Operating: 60 ° to 95 °F16 ° to 35 °C
	Recommended Storage:-4 ° to 140 °F-20 ° to 40 °C
Relative Humidity	Recommended Operating: 20 – 80% (RH)
	Recommended Storage: 15 – 75% (RH) with no condensation
Safety Approvals	Safety standards UL60950, CSA C22.2 No. 60950 EMI FCC Part 15 subpart B class B, CAN/CSA-CEI/IEC CISPR 22 class B Telecom Regulations FCC Part 68 (USA), IC/CS03 (Canada)
Power Requirements	Rated voltage: 100–120 VAC
	Rated frequency: 50–60 Hz
	Rated current: 0.6 Amp
Power Consumption	Printing: minimum 16 W / maximum 40 W
	Standby: 4.3 W
Warranty	1 year
In the Box	
Printer	AIO color all-in-one printer
	automatic document feed tray
	paper tray, and secondary external paper tray
Cords	Power cord
	Telephone cord
Ink	4 PERMAInk ^(R) Ink cartridges (ABC-10 standard-capacity Black, Cyan, Magenta, and Yellow ink cartridges)
CD-ROMs	Software / drivers
Paper	Sample pack
User Assistance	QuickStart Guide
	User Guide

Index

- A**
 - automatic document feeder tray, 6
- B**
 - BestTech Web site, 20
 - borderless printing, 14
- C**
 - cables
 - USB, 10
 - CD-ROMs
 - in box, 5
 - Printer Software, 10
 - collating pages, 11
 - copying
 - double-sided documents, 13
 - improving quality, 17
 - multiple pages, 13
 - single page, 13
 - cords
 - power, 5,6
 - telephone, 5
- D**
 - diagnostic pages, 9
 - unable to print, 16
 - documentation, 5
 - documents
 - copying both sides, 13
 - copying multiple pages, 13
 - copying single page, 13
 - printing, 11
 - duplex printing, 11
- E**
 - error codes, 17
- I**
 - ink cartridges, 5
 - installing, 8,18
- L**
 - loading paper, 9
 - guidelines, 10
- M**
 - mediacard, 15
 - memory card
 - printing from, 12
- O**
 - operation panel, 6
- P**
 - paper, 5
 - loading, 9
 - loading guidelines, 10
 - paper jams
 - clearing, 17
 - paper trays, 5,6
 - photo printing, 14
 - photos
 - printing, 14
 - power cord, 5,6
 - preferences
 - printing, 11
 - printer components, 6
 - printing, 11
 - documents, 11
 - from computer, 11
 - from memory card, 12
 - improving quality, 16
 - photos, 14
 - quality, 14
 - QuickPrint, 11
 - setting preferences, 11
- Q**
 - quality
 - improving copy, 17
 - improving print, 16
 - QuickPrint, 11
- S**
 - setting up
 - installing ink cartridges, 8,18
 - loading paper, 9
 - software
 - Printer Software CD-ROM, 10
 - specifications, 21
 - stapling documents, 11
 - support, 20
- T**
 - technical support, 20
 - telephone cord, 5
 - troubleshooting, 16
- U**
 - USB cable, 10
 - user assistance, 5,20
 - troubleshooting, 16

