

Generated: 20260620213946

Legend: Yellow highlight = AI changes

Clear Paper Jams

Paper jams occur when paper misfeeds during printing. Follow these steps to clear the jam without damaging the feed rollers.

Before you begin:

Note: Cancel print jobs and turn off the printer before attempting to remove jammed paper.

Common causes of paper jams are:

- Paper is not loaded properly.
- And some changes are made to the topics.
- Paper is the wrong type for the printer.
- Too much paper is loaded in paper tray.

Press the Power button to turn off the printer and wait 30 seconds before opening the rear access door.

Is there paper sticking out of your printer?

- If Yes, then go to the [next step](#).
- If No, then go to [step 5](#).

Release the paper by opening the printer at panel A and lifting the lever.

[Continue](#).

Carefully remove the paper from the back of the printer.

[Image: GUID-2FE168C1-2D43-4178-95EF-425061E86CF1]

Insert new paper in the paper tray.

[Image: GUID-4DA0F690-D4E8-48BA-A857-33D19B764733]

Check the secondary paper tray.

The is the external paper tray below the main paper tray.

Print a Diagnostic Page Report.

[Image: GUID-40AEA97D-E1C4-4D1A-9C7A-89A8DCD0398F]

Did the diagnostic page print correctly?

- If Yes, then you have successfully cleared the paper jam.
- If No, then go to [Unable to Print Diagnostic Page](#).