

Appendix I - Error Message Index

The printable errors a running Intuition Engine produces. Grouped by source. Each entry has the exact text the machine prints, the numeric code the runtime uses internally, and a one-line explanation.

I.1 IE64 BASIC runtime errors

The format on the screen is the message text, a space, the literal word `ERROR`, then (when raised from a running program rather than from direct mode) `IN` followed by the line number.

Code	Printed text	Meaning
1	SYNTAX	The tokeniser or parser cannot make sense of the statement.
2	DIVISION BY ZERO	A <code>/</code> , <code>\</code> , or <code>MOD</code> operator saw a zero denominator.
3	UNDEFINED LINE	<code>GOTO</code> , <code>GOSUB</code> , <code>THEN</code> , or <code>RESTORE</code> referenced a line that does not exist.
4	NEXT WITHOUT FOR	<code>NEXT</code> did not match a pending <code>FOR</code> .
5	RETURN WITHOUT GOSUB	<code>RETURN</code> did not match a pending <code>GOSUB</code> .
6	OUT OF MEMORY	The program, variable, array, or string area is full.
7	ILLEGAL QUANTITY	A function received an argument outside its domain (negative <code>SQR</code> , non-positive <code>LOG</code> , out-of-range <code>CHR\$</code>).
8	OVERFLOW	An arithmetic operation overflowed the double-precision numeric range.
9	TYPE MISMATCH	A numeric expression saw a string, or vice versa.
10	FC	Illegal function call. Raised by <code>POKE16</code> , <code>POKE32</code> , or <code>POKE64</code> to an unaligned address, by a failed <code>HOST</code> action, and by other built-in helpers when they reject their argument shape.
11	REDIM	<code>DIM</code> named an array that already exists.

Additional message strings produced by specific verbs:

Verb context	Printed text
LOAD	?FILE NOT FOUND.
SAVE	?FILE ERROR (printed as a soft error; <code>SAVE</code> does not raise into the runtime).
RUN AOT	Compiling to native code... before compilation begins.
RUN AOT / COMPILE / TRANSPILE	?COMPILE ERROR IN <line>: <reason> when a stored line cannot become native IE64 code.
RUN AOT / COMPILE / TRANSPILE / ASSEMBLE	?OUT OF MEMORY ERROR IN <line-or-0>: <reason> when the native-code arena, generated source, or output image is too large.
COMPILE / TRANSPILE / ASSEMBLE	?FC ERROR IN 0 for a bad output name.

Verb context	Printed text
COMPILE / TRANSPILE	?FILE ERROR IN 0 when the output image or generated source cannot be written.
ASSEMBLE	?FILE ERROR IN 0 when the matching assembly source is missing, unreadable, or too large.
ASSEMBLE	?COMPILE ERROR IN 0 when the IE64 source cannot be assembled.
TYPE	?SYNTAX ERROR IN 0 when the quoted filename is missing or malformed.
TYPE	?FILE NOT FOUND, ?FILE TOO LARGE, or ?FILE ERROR when the text file cannot be read.
TYPE	?NOT A TEXT FILE when the file contains binary control bytes.
RUN AOT / COMPILE / TRANSPILE	?COMPILE ERROR IN <line>: TYPE is direct-only when a stored line tries to compile TYPE.

I.2 Machine monitor (IE Mon)

The monitor prints short, lowercase-prefixed messages. Every unrecognised command prints `unknown command`. The common ones:

Printed text	Meaning
?	Generic syntax error in a monitor command line.
unknown command	The first token did not name a command.
bad address	An address argument was outside the addressable range.
bad range	An end address was lower than its start address.
bad value	A value argument did not parse as a number.
no breakpoint at <addr>	bc was given an address with no breakpoint.
breakpoint list full	The breakpoint table cannot hold another entry.
cpu frozen	An operation tried to step a frozen CPU; thaw it first.
file error	A save or load sidecar command failed.

The monitor's `h` (hunt) and `c` (compare) commands print addresses of matches rather than diagnostic messages. The disassembler prints `???` for an unknown opcode.

I.3 File I/O block

When the File I/O block (Chapter 35) fails, `FILE_STATUS` reads 1 and `FILE_ERROR_CODE` is one of:

Code	Meaning
0	OK (paired with <code>FILE_STATUS = 0</code>).
1	Not found.
2	Permission.
3	Path traversal.
4	Range error: the staged data span would reach <code>\$FFFF0000</code> , wrap the 32-bit pointer, or exceed active RAM.

For a read whose name passes path validation but whose file cannot be opened, `FILE_RESULT_LEN` is cleared to 0. A program should still test `FILE_STATUS` first and then read `FILE_ERROR_CODE`. The same 0 length is reported when a read or directory listing is refused with range error 4.

I.4 HOST appliance block

The status byte at `$F1408` (Chapter 36) reads one of:

Code	Meaning
0	Running.
1	OK (terminal).
2	Error (terminal).
3	Cancelled by user (terminal).
4	Disabled (the system-action bridge is off).
5	Idle (no command has been fired).

A non-zero exit code at `$F140C` after a terminal status of 2 gives the underlying action's exit value; the meaning is action-specific and is not normalised across subverbs.

I.5 RUN loader block

The RUN loader block (RUN "`<name>`", Chapter 35) reports status:

Code	Meaning
0	Idle.
1	Loading.
2	Running.
3	Error.

On error, the error register reports:

Code	Meaning
0	OK.
1	Not found.
2	Unsupported type.
3	Path invalid.
4	Load failed.

RUN translates a non-zero result into `?FILE ERROR` for the file-error cases and `?FC ERROR` for the unsupported cases. For .ie64 images, load failed includes an image too large to fit at `PROG_START`; the image is rejected before it can partially overwrite memory.

I.6 Media loader

The media loader (`SOUND PLAY`, Chapter 23) reports status:

Code	Meaning
0	Idle.
1	Loading.
2	Playing.
3	Error.

On error, `MEDIA_ERROR` reports:

Code	Meaning
0	OK.
1	File not found.
2	Bad format or read failure.
3	Unsupported extension.
4	Invalid filename.
5	File too large for the staging buffer.

For MIDI/MUS, bad SMF headers, unsupported SMF type 2, SMPTE timing, bad MUS score ranges, and unsupported MUS event types all report as bad format.

I.7 Coprocessor

`COSTATUS` (Chapter 32) reports:

Code	Constant	Meaning
0	<code>COPROC_TICKET_PENDING</code>	Queued, not yet started.
1	<code>COPROC_TICKET_RUNNING</code>	Worker is processing.
2	<code>COPROC_TICKET_OK</code>	Completed successfully.
3	<code>COPROC_TICKET_ERROR</code>	Worker returned an error.
4	<code>COPROC_TICKET_TIMEOUT</code>	Wait deadline expired.
5	<code>COPROC_TICKET_WORKER_DOWN</code>	Worker is no longer running.

`COWAIT` blocks until the ticket reaches a terminal state or the timeout expires; call `COSTATUS(ticket)` afterwards to read the final code.

I.8 Raised by the CPU itself

Per CPU, the chapter (Ch 25-30) lists the trap and exception vectors and their meanings. The monitor's `r` command displays the current trap source when a CPU has stopped at one. Common cross-CPU shapes:

- Division by zero raises the CPU's divide-by-zero exception on M68K (vector 5) and x86 (INT 0). IE32 stops with a division-by-zero error. IE64 integer divide and modulo by zero write 0 and do not trap; IE64 floating-point divide-by-zero is reported in the FPU status register.
- An unaligned 32-bit access on the IE64 raises an alignment fault; the address that caused it is in CR_FAULT_ADDR.
- An undefined opcode raises the CPU's illegal-instruction vector (M68K vector 4, x86 INT 6, Z80 silently re-executes on most undocumented prefixes, 6502 documents the undocumented opcodes - see Chapter 27).
- On IE64, MTCR to the read-only CR_RAM_SIZE_BYTES control register raises FAULT_ILLEGAL_INSTRUCTION (cause 11).