

SOP · Pump P-102A Isolation

Close the suction and discharge valves, apply lockout-tagout, and depressurise the casing before opening the pump.