

AG35-CET QuecOpen(SDK) AT Commands Manual

LTE Standard Module Series

Version: 1.0.0

Date: 2023-09-13

Status: Preliminary



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2023. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2023-09-13	Lyndsay XIE	Creation of the document
1.0.0	2023-09-13	Lyndsay XIE	Preliminary

Contents

About the Document.....	3
Contents	4
Table Index.....	6
1 Introduction	7
1.1. Definitions	7
1.2. AT Command Syntax	7
1.3. Supported Character Sets	9
1.4. AT Command Port.....	9
1.5. Declaration of AT Command Examples	9
2 General Commands	10
2.1. ATI Display MT Identification Information	10
2.2. AT+GSN Request International Mobile Equipment Identity (IMEI).....	11
2.3. AT+CGSN Request International Mobile Equipment Identity (IMEI)	11
2.4. ATE Set Command Echo Mode	12
2.5. AT+CFUN Set MT Functionality	12
3 (U)SIM Related Commands	15
3.1. AT+CIMI Request International Mobile Subscriber Identity (IMSI)	15
3.2. AT+CLCK Facility Lock.....	16
3.3. AT+CPIN Enter PIN.....	17
3.4. AT+CPWD Change Password	19
3.5. AT+CSIM Generic (U)SIM Access	21
3.6. AT+CRSM Restricted (U)SIM Access.....	21
4 Network Service Commands	23
4.1. AT+COPS PLMN Selection.....	23
4.2. AT+CREG Network Registration Status.....	25
4.3. AT+CSQ Signal Quality.....	26
4.4. AT+CPOL Preferred PLMN List	27
4.5. AT+COPN Read Operator Names	29
4.6. AT+CTZU Automatic Time Zone Update	29
4.7. AT+CTZR Time Zone Reporting	30
4.8. AT+QNWINFO Query Network Information	31
5 Call Control Commands	34
5.1. ATA Answer an Incoming Call.....	34
5.2. ATD Originate a Call.....	35
5.3. ATH Disconnect Existing Connection	36
5.4. AT+CVHU Voice Hangup Control	36
5.5. AT+CHUP Hang up Call	37
5.6. ATO Switch from Command Mode to Data Mode.....	38
5.7. ATSO Set Number of Rings Before Automatic Answering	38

5.8.	ATS7 Connection Completion Timeout.....	39
5.9.	AT+CBST Select Bearer Service Type	40
5.10.	AT+CSTA Select Type of Address.....	42
5.11.	AT+CLCC List Current Calls	42
5.12.	AT+CRC Set Extended Format for Incoming Call Indication	44
5.13.	AT+CRLP Select Radio Link Protocol Parameter	45
6	Short Message Service Commands.....	47
6.1.	AT+CSMS Select Message Service.....	47
6.2.	AT+CMGF Message Format	48
6.3.	AT+CSCA Service Center Address.....	49
6.4.	AT+CPMS Preferred Message Storage	50
6.5.	AT+CMGD Delete Message	51
6.6.	AT+CMGL List Messages	52
6.7.	AT+CMGR Read Message.....	55
6.8.	AT+CMGS Send Message	59
6.9.	AT+CMMS Send More Messages.....	60
6.10.	AT+CMGW Write Message to Memory	61
6.11.	AT+CMSS Send Message from Storage	63
6.12.	AT+CNMI New Message Indications to TE.....	64
6.13.	AT+CSCB Select Cell Broadcast Message Types.....	66
6.14.	AT+CSDH Show Text Mode Parameters.....	67
6.15.	AT+CSMP Set Text Mode Parameters (Non-CDMA Network).....	68
7	Packet Domain Commands	70
7.1.	AT+CGATT PS Attach or Detach	70
7.2.	AT+CGDCONT Define PDP Context	71
7.3.	AT+CGACT Activate or Deactivate PDP Contexts	73
7.4.	AT+CGPADDR Show PDP Address(es).....	74
7.5.	AT+CGCLASS GPRS Mobile Station Class	75
7.6.	AT+CGREG GPRS Network Registration Status	76
7.7.	AT+CGEREP Packet Domain Event Reporting	77
7.8.	AT+CGSMS Select Service for MO SMS Messages	79
7.9.	AT+CEREG EPS Network Registration Status	79
8	Audio Commands	81
8.1.	AT+CLVL Loudspeaker Volume Level	81
8.2.	AT+VTS DTMF and Tone Generation.....	82
8.3.	AT+VTD Tone Duration.....	83
9	Hardware Related Commands.....	84
9.1.	AT+QADC Read ADC Value	84
10	Appendix References	85
10.1.	References	85
10.2.	Mobile Termination Error Result Code +CME ERROR.....	88
10.3.	Summary of URC.....	90

Table Index

Table 1: Types of AT Commands	8
Table 2: Terms and Abbreviations	85
Table 3: Summary of General +CME ERROR Codes	88
Table 4: Summary of URC	90

Preliminary Document
Not Checked

1 Introduction

Quectel AG35-CET module supports QuecOpen® solution. QuecOpen is an embedded development platform based on Linux system. It is intended to simplify the design and development of IoV applications.

This document is applicable to QuecOpen® solution based on SDK build environment. It presents the AT command set supported by Quectel AG35-CET module in QuecOpen® solution.

1.1. Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on the command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals to its previous value or the default settings, unless otherwise specified.
- **Underline** Default setting of a parameter.

1.2. AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately omitted.

The AT command set supported by the modules is a combination of international standards such as *3GPP TS 27.007*, *3GPP TS 27.005* and *ITU-T recommendation V.25ter*, as well as the AT commands developed by Quectel.

AT commands implemented by the modules fall into three categories syntactically: “Basic”, “S Parameter” and “Extended”, as listed below:

- **Basic**

Basic command format is **AT<x><n>**, or **AT&<x><n>**, where **<x>** is the command, and **<n>** is/are the argument(s) of the command. For example, **ATE<n>** tells the DCE (Data Circuit-terminating Equipment) whether received characters should be echoed back to the DTE (Data Terminal Equipment) according to the value of **<n>**. **<n>** is optional and a default will be used if it is omitted.

- **S Parameter**

S Parameter command format is **ATS<n>=<m>**, where **<n>** is the index of the **S** register to be set, and **<m>** is the value to be assigned to it.

- **Extended**

Extended commands can be executed in several modes, as shown in the following table:

Table 1: Types of AT Commands

Command Type	Syntax	Description
Test Command	AT+<cmd>=?	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	AT+<cmd>?	Check the current parameter value of the corresponding command.
Write Command	AT+<cmd>=<p1>[,<p2>[,<p3>[...]]]	Set user-definable parameter value.
Execution Command	AT+<cmd>	Return a specific information parameter or perform a specific action.

Multiple commands can be placed on a single line using a semi-colon (;) between commands. In such cases, only the first command should have **AT** prefix. Commands can be in upper or lower case.

Spaces should be ignored when you enter AT commands, except in the following cases:

- Within quoted strings, where spaces are preserved;
- Within an unquoted string or numeric parameter;
- Within an IP address;
- Within the AT command name up to and including a =, ? or =?.

On input, at least a carriage return is required. A newline character is ignored so it is permissible to use carriage return/line feed pairs on the input.

If no command is entered after the **AT** token, **OK** will be returned. If an invalid command is entered, **ERROR** will be returned.

Optional parameters, unless explicitly stated, need to be provided up to the last entered parameter.

1.3. Supported Character Sets

The AT command interface of the module uses the GSM character set by default and supports the following character sets:

- GSM
- UCS-2
- IRA

These character sets are defined in *3GPP TS 27.005*. The character sets affect transmission and reception of SMS and SMS Cell Broadcast Messages, as well as the entry and display of phonebook entries text field.

1.4. AT Command Port

The two USB ports (USB modem port and USB AT port) support AT command communication and data transfer.

1.5. Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about the use of the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendations or suggestions about how to design a program flow or what status to set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there is a correlation among these examples, or that they should be executed in a given sequence.

2 General Commands

2.1. ATI Display MT Identification Information

This command delivers the MT identification information text.

ATI Display MT Identification Information	
Execution Command ATI	Response Quectel <objectID> Revision: <revision> OK
Maximum Response Time	300 ms
Characteristics	/
Reference	V.25ter

Parameter

<objectID>	String type. Identifier of device type.
<revision>	String type. Identification text of MT firmware version.

Example

```

ATI
Quectel
AG35-CET
Revision: AG35CETCAR02A01M2G_OCPU

OK
```

2.2. AT+GSN Request International Mobile Equipment Identity (IMEI)

This command requests the International Mobile Equipment Identity (IMEI) number of the ME which permits the user to identify individual ME device. It is identical with **AT+CGSN** in *Chapter 2.3*.

AT+GSN Request International Mobile Equipment Identity (IMEI)	
Test Command AT+GSN=?	Response OK
Execution Command AT+GSN	Response <IMEI> OK
Maximum Response Time	300 ms
Characteristics	/
Reference	V.25ter

Parameter

<IMEI>	String type. IMEI number of the ME.
---------------------	-------------------------------------

NOTE

The IMEI is unique to each ME, so it can be used to identify an ME.

2.3. AT+CGSN Request International Mobile Equipment Identity (IMEI)

This command requests International Mobile Equipment Identity (IMEI) number of the ME. It is identical with **AT+GSN** above.

AT+CGSN Request International Mobile Equipment Identity (IMEI)	
Test Command AT+CGSN=?	Response OK
Execution Command AT+CGSN	Response <IMEI> OK
Maximum Response Time	300 ms
Characteristics	/

Reference	3GPP TS 27.007
-----------	----------------

Parameter

<IMEI>	String type. IMEI number of the ME.
--------	-------------------------------------

NOTE

The IMEI is unique to each ME, so it can be used to identify an ME.

2.4. ATE Set Command Echo Mode

This command controls whether TA echoes characters received from TE or not during AT command mode.

ATE Set Command Echo Mode

Execution Command ATE<value>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	V.25ter

Parameter

<value>	Integer type. Whether to echo the characters received from TE.
0	OFF
<u>1</u>	ON

2.5. AT+CFUN Set MT Functionality

This command selects the level of functionality <fun> in the MT. It can also reset the MT.

AT+CFUN Set MT Functionality

Test Command AT+CFUN=?	Response +CFUN: (list of supported <fun>s),(list of supported <rst>s)
----------------------------------	---

	OK
Read Command AT+CFUN?	Response +CFUN: <fun>
	OK
Write Command AT+CFUN=<fun>[,<rst>]	Response OK If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR
Maximum Response Time	15 s, determined by the network.
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<fun>	Integer type. 0 Minimum functionality <u>1</u> Full functionality 3 Disable MT from receiving RF signals 4 Disable MT from both transmitting and receiving RF signals 5 Disable (U)SIM 6 Second RX off
<rst>	Integer type. <u>0</u> Do not reset the MT before setting it to <fun> power level. 1 Reset the MT before setting it to <fun> power level. The device is fully functional after the reset. This value is available only for <fun>=1 .
<err>	MT error result code. See Chapter 10.2 for details.

Example

```

AT+CFUN=0 //Switch the UE to minimum functionality.
OK
AT+CPIN?
+CME ERROR: 13 //(U)SIM failure.
AT+CFUN=1 //Switch UE to full functionality.
OK
AT+CPIN?
+CPIN: READY

OK
AT+COPS?
+COPS: 0,2,"46000",7 //Operator is registered.

```

OK

Preliminary Document
Not Checked

3 (U)SIM Related Commands

3.1. AT+CIMI Request International Mobile Subscriber Identity (IMSI)

This command requests the International Mobile Subscriber Identity (IMSI) which is intended to permit the TE to identify the individual SIM card or active application in the UICC (GSM or SIM) that is attached to MT.

AT+CIMI Request International Mobile Subscriber Identity (IMSI)	
Test Command AT+CIMI=?	Response OK
Execution Command AT+CIMI	Response <IMSI> OK If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<IMSI>	International Mobile Subscriber Identity (string without double quotes).
<err>	MT error result code. See Chapter 10.2 for details.

Example

AT+CIMI	//Query IMSI number of the (U)SIM attached to MT.
460023210226023	//The IMSI number of (U)SIM attached to MT.
OK	

3.2. AT+CLCK Facility Lock

This command locks, unlocks or interrogates an MT or a network facility **<fac>**. It can be aborted when network facilities are being set or queried. Password is normally needed to do such actions. The factory default password of PF, PN, PU, PP and PC lock is "12341234". When querying the status of a network service (**<mode>**=2), the response line for 'not active' case (**<status>**=0) should be returned only if service is not active for any **<class>**.

AT+CLCK Facility Lock	
Test Command AT+CLCK=?	Response +CLCK: (list of supported <fac> s) OK
Write Command AT+CLCK=<fac>,<mode>[,<passwd>[,<class>]]	Response If <mode> does not equal 2 and the command is set successfully: OK If <mode> =2 and the command is set successfully: +CLCK: <status>[,<class>] [+CLCK: <status>[,<class>] [...]] OK
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<fac>	String type. Facility lock type. "SC" (U)SIM (lock SIM/UICC card inserted in the currently selected card slot) (SIM/UICC asks password in MT power-up and when this lock command is issued). "AO" BAOC (Bar All Outgoing Calls) (see 3GPP TS 22.088 clause 1) "OI" BOIC (Bar Outgoing International Calls) (see 3GPP TS 22.088 clause 1) "OX" BOIC-exHC (Bar Outgoing International Calls except to Home Country) (see 3GPP TS 22.088 clause 1) "AI" BAIC (Bar All Incoming Calls) (see 3GPP TS 22.088 clause 2) "IR" BIC-Roam (Bar Incoming Calls when Roaming outside the home country) (see 3GPP TS 22.088 clause 2) "AB" All Barring services (see 3GPP TS 22.030) (applicable only for <mode> =0) "AG" All outgoing barring services (see 3GPP TS 22.030) (applicable only for <mode> =0) "AC" All incoming barring services (see 3GPP TS 22.030) (applicable only for <mode> =0) "FD" SIM card or active application in the UICC (GSM or USIM) fixed dialing memory feature (if PIN2 authentication has not been done during the current session,
--------------------	--

	PIN2 is required as <passwd>)
"PF"	Lock Phone to the very First inserted SIM/UICC card (also referred in the present document as PH-FSIM) (MT asks password when other SIM/UICC cards are inserted).
"PN"	Network Personalization (see 3GPP TS 22.022)
"PU"	Network Subset Personalization (see 3GPP TS 22.022)
"PP"	Service Provider Personalization (see 3GPP TS 22.022)
"PC"	Corporate Personalization (see 3GPP TS 22.022)
<mode>	Integer type. Operation mode.
0	Unlock
1	Lock
2	Query status
<passwd>	String type. Password.
<class>	Integer type. A sum of integers each representing a class of information.
1	Voice
2	Data
4	Fax
7	All telephony except SMS
8	Short message service
16	Data circuit synchronization
32	Data circuit asynchronization
<status>	Integer type. Current status of the specified <class> .
0	Not active
1	Active

Example

```

AT+CLCK="SC",2           //Query the status of (U)SIM card.
+CLCK: 0                 //The (U)SIM card is not active.

OK
AT+CLCK="SC",1,"1234"    //Lock (U)SIM card, and the password is 1234.
OK
AT+CLCK="SC",2           //Query the status of (U)SIM card.
+CLCK: 1                 //The (U)SIM card is active.

OK
AT+CLCK="SC",0,"1234"    //Unlock (U)SIM card, and the password is 1234.
OK

```

3.3. AT+CPIN Enter PIN

This command sends to the MT a password which is necessary before it can be operated ((U)SIM PIN, (U)SIM PUK, PH-SIM PIN, etc.), or queries whether the MT requires a password or not before it can be operated.

If the PIN is to be entered twice, the MT automatically repeats the PIN. If no PIN request is pending, no

action is taken towards MT and an error message **+CME ERROR** is returned to TE.

If the PIN required is (U)SIM PUK or (U)SIM PUK2, the second parameter is required. This second PIN, **<newpin>**, is used to replace the old PIN in the (U)SIM.

AT+CPIN Enter PIN	
Test Command AT+CPIN=?	Response OK
Read Command AT+CPIN?	Response MT returns an alphanumeric string indicating whether or not a password is required. +CPIN: <code> OK If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR
Write Command AT+CPIN=<pin>[,<newpin>]	Response OK
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<code>	String without double quotes. READY MT is not pending for any password SIM PIN MT is waiting for (U)SIM PIN to be given SIM PUK MT is waiting for (U)SIM PUK to be given SIM PIN2 MT is waiting for (U)SIM PIN2 to be given SIM PUK2 MT is waiting for (U)SIM PUK2 to be given PH-NET PIN MT is waiting for network personalization password to be given PH-NET PUK MT is waiting for network personalization unlocking password to be given PH-NETSUB PIN MT is waiting for network subset personalization password to be given PH-NETSUB PUK MT is waiting for network subset personalization unlocking password to be given PH-SP PIN MT is waiting for service provider personalization password to be given PH-SP PUK MT is waiting for service provider personalization unlocking password to be given PH-CORP PIN MT is waiting for corporate personalization password to be given PH-CORP PUK MT is waiting for corporate personalization unlocking password to be given
<pin>	String type. Password. If the requested password was a PUK, such as (U)SIM PUK1, PH-FSIM PUK or another password, then <pin> must be followed by <newpin> .
<newpin>	String type. New password required if the requested code was a PUK.

<err> MT error result code. See **Chapter 10.2** for details.

Example

```
//Enter PIN.
AT+CPIN?
+CPIN: SIM PIN //Waiting (U)SIM PIN to be given.

OK
AT+CPIN="1234" //Enter PIN.
OK

+CPIN: READY
AT+CPIN?
+CPIN: READY //PIN has already been entered.

OK
//Enter PUK and PIN.
AT+CPIN?
+CPIN: SIM PUK //Waiting (U)SIM PUK to be given.

OK
AT+CPIN="26601934","1234" //Enter PUK and the new PIN password.
OK

+CPIN: READY
AT+CPIN?
+CPIN: READY //PUK has already been entered.

OK
```

3.4. AT+CPWD Change Password

The Write Command sets a new password for the facility lock function defined by **AT+CLCK**. The Test Command returns a list of pairs which present the available facilities and the maximum length of their passwords.

AT+CPWD Change Password

Test Command	Response
AT+CPWD=?	+CPWD: list of supported (<fac>,<pwdlength>)s
	OK

Write Command AT+CPWD=<fac>,<oldpwd>,<newpwd>	Response OK
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<fac>	String type. Facility lock type. "SC" (U)SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command is issued) "AO" BAOC (Bar All Outgoing Calls, see 3GPP TS 22.088 clause 1) "OI" BOIC (Bar Outgoing International Calls, see 3GPP TS 22.088 clause 1) "OX" BOIC-exHC (Bar Outgoing International Calls except to Home Country, see 3GPP TS 22.088 clause 1) "AI" BAIC (Bar All Incoming Calls, see 3GPP TS 22.088 clause 2) "IR" BIC-Roam (Bar Incoming Calls when Roaming outside the home country, see 3GPP TS 22.088 clause 2) "AB" All barring services (see 3GPP TS 22.030, applicable only for <mode>=0) "AG" All outgoing barring services (see 3GPP TS 22.030, applicable only for <mode>=0) "AC" All incoming barring services (see 3GPP TS 22.030, applicable only for <mode>=0) "P2" (U)SIM PIN2
<pwdlength>	Integer type. Maximum length of password.
<oldpwd>	String type. Password specified for the facility from the user interface or with command.
<newpwd>	String type. New password.

Example

```

AT+CPIN?
+CPIN: READY

OK
AT+CPWD="SC","1234","4321"           //Change (U)SIM card password from "1234" to "4321".
OK
//Restart MT or re-activate the (U)SIM card.
AT+CPIN?                             //Waiting (U)SIM PIN to be given.
+CPIN: SIM PIN

OK
AT+CPIN="4321"                       //PIN must be entered to define a new password "4321".
OK

+CPIN: READY

```

3.5. AT+CSIM Generic (U)SIM Access

This command allows a direct control of the (U)SIM that is inserted in the currently selected card slot by a distant application on TE. TE should then keep the processing of (U)SIM information within the frame specified by GSM/UMTS.

AT+CSIM Generic (U)SIM Access	
Test Command AT+CSIM=?	Response OK
Write Command AT+CSIM=<length>,<command>	Response +CSIM: <length>,<response> OK Or ERROR If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<length>	Length of the characters that are sent to TE in <command> or <response> (two times the actual length of the command or response).
<command>	Command passed on by the MT to the (U)SIM in the format as described in 3GPP TS 51.011 (hexadecimal character format).
<response>	Response to the command passed on by the (U)SIM to the MT in the format as described in 3GPP TS 51.011 (hexadecimal character format).
<err>	MT error result code. See Chapter 10.2 for details.

3.6. AT+CRSM Restricted (U)SIM Access

This command offers easier but more limited access to the (U)SIM database. It transmits to the MT the (U)SIM **<command>** and its required parameters.

AT+CRSM Restricted (U)SIM Access	
Test Command AT+CRSM=?	Response OK
Write Command AT+CRSM=<command>[,<fileid>[,<P1>,<P2>,<P3>[,<data>[,<pathid>]]]]	Response +CRSM: <sw1>,<sw2>[,<response>] OK

	Or ERROR If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<command>	Integer type. (U)SIM command passed on by the MT to the (U)SIM. 176 READ BINARY 178 READ RECORD 192 GET RESPONSE 214 UPDATE BINARY 220 UPDATE RECORD 242 STATUS
<fileid>	Integer type. Identifier for an elementary data file on (U)SIM. Mandatory for every command except STATUS.
<P1>, <P2>, <P3>	Parameters transferred by the MT to the (U)SIM. These parameters are mandatory for every command, except GET RESPONSE and STATUS. The values are described in <i>3GPP TS 51.011</i> .
<data>	Information which should be written to the (U)SIM (hexadecimal character format).
<pathid>	The directory path of an elementary file on the SIM/UICC in hexadecimal format as defined in <i>ETSI TS 102 221</i> .
<sw1>, <sw2>	Integer type. Information from the (U)SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command.
<response>	Response of a successful completion of the command previously issued (hexadecimal character format). STATUS and GET RESPONSE return data, which gives information about the current elementary data field. The information includes the type of file and its size (see <i>3GPP TS 51.011</i>). After READ BINARY or READ RECORD command, the requested data is returned. <response> is not returned after a successful UPDATE BINARY or UPDATE RECORD command.
<err>	Error codes. For more details, see Chapter 10.2 .

4 Network Service Commands

4.1. AT+COPS PLMN Selection

This command returns the current operators and their status, and allows automatic or manual network selection.

The Test Command returns a set of five parameters, each representing an operator presenting in the network. The set consists of an integer indicating the availability of the operator **<stat>**, long and short alphanumeric format of the name of the operator, numeric format representation of the operator and access technology. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in the order of: home network, networks referenced in (U)SIM and other networks.

The Read Command returns the current mode and the currently selected operator. If no operator is selected, **<format>**, **<oper>** and **<AcT>** are omitted.

The Write Command forces an attempt to select and register to the GSM/UMTS network operator. If the selected operator is not available, no other operator shall be selected (except **<mode>=4**). The format of selected operator name shall apply to further Read Commands (**AT+COPS?**).

AT+COPS PLMN Selection	
Test Command AT+COPS=?	Response +COPS: [range of supported (<stat>,long alphanumeric <oper>,short alphanumeric <oper>,numeric <oper>],[<AcT>)]s[,,(range of supported <mode>s),(range of supported <format>s)] OK If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR
Read Command AT+COPS?	Response +COPS: <mode>[,<format>],[<oper>],[<AcT>]] OK If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR

Write Command AT+COPS=<mode>[,<format>,<oper>[,<AcT>]]]	Response OK If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR
Maximum Response Time	180 s, determined by the network.
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<stat>	Integer type. 0 Unknown 1 Operator available 2 Current operator 3 Operator forbidden
<oper>	String type. Operator in format as per <format> .
<mode>	Integer type. 0 Automatic (<oper> field is ignored) 1 Manual (<oper> field shall be present and <AcT> optionally) 2 Deregister from network 3 Set only <format> (for AT+COPS? Read Command), and do not attempt registration/deregistration (<oper> and <AcT> fields are ignored). This value is not applicable in the Read Command response. 4 Manual/automatic (<oper> field shall be presented). If manual selection fails, automatic mode (<mode> =0) is entered
<format>	Integer type. 0 Long format alphanumeric <oper> which can be up to 16 characters long 1 Short format alphanumeric <oper> 2 Numeric <oper> . GSM location area identification number
<AcT>	Integer type. Access technology selected. Values 3, 4, 5 and 6 occur only in the response of Read Command while MS is in data service state and is not intended for the AT+COPS Write Command. 0 GSM 2 UTRAN 3 GSM w/EGPRS 4 UTRAN w/HSDPA 5 UTRAN w/HSUPA 6 UTRAN w/HSDPA and HSUPA 7 E-UTRAN
<err>	MT error result code. See Chapter 10.2 for details.

Example

```
AT+COPS=? //List all current network operators.
+COPS: (1,"CHN-UNICOM","UNICOM","46001",2),(1,"CHN-UNICOM","UNICOM","46001",0),(2,"CHN-UNICOM","UNICOM","46001",7),(1,"CHN-CT","CT","46011",7),(3,"CHINA MOBILE","CMCC","46000",0),,(0-4),(0-2)
```

```
OK
AT+COPS?                                     //Query the currently selected network operator.
+COPS: 0,0,"46000",7
OK
```

4.2. AT+CREG Network Registration Status

The Write Command controls the presentation of an unsolicited result code **+CREG: <stat>** when **<n>=1** and there is a change in the MT's circuit mode network registration status in GERAN/UTRAN/E-UTRAN, or unsolicited result code **+CREG: <stat>[,<lac>],<ci>[,<AcT>]]** when **<n>=2** and there is a change of the network cell in GERAN/UTRAN/E-UTRAN.

The Read Command returns the status of result code presentation and an integer **<stat>** which shows whether the network has currently indicated the registration of the MT. Location information elements **<lac>**, **<ci>** and **<AcT>**, if available, are returned only when **<n>=2** and MT is registered in the network.

AT+CREG Network Registration Status	
Test Command AT+CREG=?	Response +CREG: (range of supported <n>s) OK
Read Command AT+CREG?	Response +CREG: <n>,<stat>[,<lac>,<ci>[,<AcT>]] OK If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR
Write Command AT+CREG=[<n>]	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.007

Parameter

<n>	Integer type. Whether to enable network registration URC.
0	Disable network registration unsolicited result code
1	Enable network registration unsolicited result code: +CREG: <stat>
2	Enable network registration unsolicited result code with location information:

	+CREG: <stat>[,<lac>],[<ci>],[<AcT>]]
<stat>	Integer type. Circuit mode registration status. 0 Not registered. MT is not currently searching a new operator to register to 1 Registered, home network 2 Not registered, but MT is currently searching a new operator to register to 3 Registration denied 4 Unknown (e.g. out of GERAN/UTRAN/E-UTRAN coverage) 5 Registered, roaming
<lac>	String type. Two bytes location area code in hexadecimal format.
<ci>	String type. Four byte GERAN/UTRAN/E-UTRAN cell ID in hexadecimal format.
<AcT>	Integer type. Access technology of the serving cell. 0 GSM 2 UTRAN 3 GSM w/EGPRS 4 UTRAN w/HSDPA 5 UTRAN w/HSUPA 6 UTRAN w/HSDPA and HSUPA 7 E-UTRAN
<err>	MT error result code. See Chapter 10.2 for details.

Example

```

AT+CREG=2                                //Activate extended URC mode.
OK
AT+CREG?
+CREG: 2,1,"550c","5a29c0b",7           //URC reporting MT has registered on an E-UTRAN network.
OK

```

4.3. AT+CSQ Signal Quality

The Execution Command returns received signal strength indication **<rssi>** and channel bit error rate **<ber>** from the MT.

AT+CSQ Signal Quality	
Test Command AT+CSQ=?	Response +CSQ: (list of supported <rssi>s),(list of supported <ber>s) OK
Execution Command AT+CSQ	Response +CSQ: <rssi>,<ber> OK If there is error related to MT functionality: +CME ERROR: <err> Or ERROR

Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<rss>	Integer type. Received signal strength indication. 0 -113 dBm or less 1 -111 dBm 2–30 -109 dBm. to -53 dBm 31 -51 dBm or greater 99 Not known or not detectable
<ber>	Integer type. Channel bit error rate (in percent). 0–7 As RxQual values in the table in 3GPP TS 45.008 subclause 8.2.4 99 Not known or not detectable
<err>	MT error result code. See Chapter 10.2 for details.

Example

```

AT+CSQ=?
+CSQ: (0-31,99),(0-7,99)

OK
AT+CSQ
+CSQ: 28,99      //The received signal strength indicator is 28 and the channel bit error rate is 99.

OK

```

4.4. AT+CPOL Preferred PLMN List

This command edits the PLMN selector with Access Technology lists in the SIM card or active application in the UICC (GSM or USIM).

AT+CPOL Preferred PLMN List	
Test Command AT+CPOL=?	Response +CPOL: (list of supported <index>s),(range of supported <format>s) OK
Read Command AT+CPOL?	Response Query the list of preferred operators: +CPOL: <index1>,<format>,<oper1>[,<GSM_Act1>,<GSM_Act2>,<UTRAN_Act1>,<E-UTRAN_Act1>] [+CPOL: <index2>,<format>,<oper2>[,<GSM_Act2>,<GSM_Act3>,<UTRAN_Act2>,<E-UTRAN_Act2>]

	M_Compact_Act2>,<UTRAN_Act2>,<E-UTRAN_Act2>] [...]]
	OK
Write Command AT+CPOL=<index>[,<format>[,<oper>[,<GSM_Act>,<GSM_Compact_Act>,<UTRAN_Act>,<E-UTRAN_Act>]]]	Response If the optional parameters are omitted, delete the operator with specified <index>: OK If any of the optional parameters is specified, edit the list of preferred operators: OK Or ERROR If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<indexn>	Integer type. The order number of operator in the (U)SIM preferred operator list.
<format>	Integer type. 0 Long format alphanumeric <oper> 1 Short format alphanumeric <oper> 2 Numeric <oper>
<opern>	String type. <format> indicates the format is alphanumeric or numeric (see AT+COPS).
<GSM_Actn>	Integer type. GSM access technology. 0 Access technology is not selected 1 Access technology is selected
<GSM_Compact_Actn>	Integer type. GSM compact access technology. 0 Access technology is not selected 1 Access technology is selected
<UTRAN_Actn>	Integer type. UTRAN access technology. 0 Access technology is not selected 1 Access technology is selected
<E-UTRAN_Actn>	Integer type. E-UTRAN access technology. 0 Access technology is not selected 1 Access technology is selected
<err>	MT error result code. See Chapter 10.2 for details.

NOTE

The access technology selection parameters <GSM_Act>, <GSM_Compact_Act>, <UTRAN_Act> and <E-UTRAN_Act> are required for SIM cards or UICCs containing PLMN selector with access technology.

4.5. AT+COPN Read Operator Names

This command returns the list of operator names from the MT. Each operator code **<numericn>** that has an alphanumeric equivalent **<alphan>** in the MT memory is returned.

AT+COPN Read Operator Names	
Test Command AT+COPN=?	Response OK
Execution Command AT+COPN	Response +COPN: <numeric1>,<alpha1> [+COPN: <numeric2>,<alpha2> [...]] OK If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	Depends on the number of operator names.
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<numericn>	String type. Operator names in numeric format (see AT+COPS).
<alphan>	String type. Operator names in long alphanumeric format (see AT+COPS).
<err>	MT error result code. See Chapter 10.2 for details.

4.6. AT+CTZU Automatic Time Zone Update

This command enables and disables automatic time zone update via NITZ.

AT+CTZU Automatic Time Zone Update	
Test Command AT+CTZU=?	Response +CTZU: (list of supported <onoff>s) OK
Read Command AT+CTZU?	Response +CTZU: <onoff> OK
Write Command AT+CTZU=<onoff>	Response OK Or ERROR

Maximum Response Time	300 ms
Characteristic	/
Reference	3GPP TS 27.007

Parameter

<onoff>	Integer type. The mode of automatic time zone update.
0	Disable automatic time zone update via NITZ
<u>1</u>	Enable automatic time zone update via NITZ and update GMT time to URC

Example

AT+CTZU?

+CTZU: 1

OK

AT+CTZU=?

+CTZU: (0,1)

OK

AT+CTZU=0

OK

AT+CTZU?

+CTZU: 0

OK

4.7. AT+CTZR Time Zone Reporting

This command controls the time zone change event reporting. If reporting is enabled, the MT returns the unsolicited result code **+CTZV: <tz>** or **+CTZE: <tz>,<dst>,<time>** whenever the time zone is changed. The configuration is stored to flash automatically.

AT+CTZR Time Zone Reporting

Test Command AT+CTZR=?	Response +CTZR: (list of supported <reporting>s) OK
Read Command AT+CTZR?	Response +CTZR: <reporting> OK

Write Command AT+CTZR=<reporting>	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristic	This command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<reporting>	Integer type. The mode of time zone reporting. 0 Disable time zone change event reporting 1 Enable time zone change event reporting by URC +CTZV: <tz> 2 Enable extended time zone and local time reporting by URC +CTZE: <tz>,<dst>,<time>
<tz>	String type. The sum of the local time zone (difference between the local time and GMT expressed in quarters of an hour) plus daylight saving time. The format is "±zz", expressed as a fixed-width, two-digit integer from -48 to +56. To maintain a fixed width, numbers in the range -9 to +9 are expressed with a leading zero, e.g. "-09", "+00" and "+09".
<dst>	Integer type. Indicate whether <tz> includes daylight savings adjustment. 0 <tz> includes no adjustment for daylight saving time 1 <tz> includes +1 hour (i.e. 4 quarters in <tz>) adjustment for daylight saving time 2 <tz> includes +2 hours (i.e. 8 quarters in <tz>) adjustment for daylight saving time
<time>	String type. Local time. The format is "YYYY/MM/DD,hh:mm:ss", expressed as integers representing year (YYYY), month (MM), date (DD), hour (hh), minute (mm) and second (ss). This parameter can be provided by the network when delivering time zone information and be presented in the URC of extended time zone reporting if provided by the network.

4.8. AT+QNWINFO Query Network Information

This command queries network information such as the access technology selected, the operator, and the band selected.

AT+QNWINFO Query Network Information	
Test Command AT+QNWINFO=?	Response OK
Execution Command AT+QNWINFO	Response +QNWINFO: <AcT>,<oper>,<band>,<channel> [+QNWINFO: <AcT>,<oper>,<band>,<channel>] OK
Maximum Response Time	300 ms
Characteristics	/

Parameter

<AcT>	String type. The access technology selected. "NONE" "CDMA1X" "CDMA1X AND HDR" "CDMA1X AND EHRPD" "HDR" "HDR-EHRPD" "GSM" "GPRS" "EDGE" "WCDMA" "HSDPA" "HSUPA" "HSPA+" "TDSCDMA" "TDD LTE" "FDD LTE"
<oper>	String type. Operator in numeric format.
<band>	String type. Selected band. "GSM 450" "GSM 480" "GSM 750" "GSM 850" "GSM 900" "GSM 1800" "GSM 1900" "WCDMA 2100" "WCDMA 1900" "WCDMA 1800" "WCDMA 1700 US" "WCDMA 850" "WCDMA 800" "WCDMA 2600" "WCDMA 900" "WCDMA 1700 JAPAN" "WCDMA 1500" "WCDMA 850 JAPAN" "LTE BAND 1" – "LTE BAND 43" "TDSCDMA BAND A" "TDSCDMA BAND B" "TDSCDMA BAND C" "TDSCDMA BAND D" "TDSCDMA BAND E" "TDSCDMA BAND F"
<channel>	Integer type. Channel ID.

Example

```

AT+QNWINFO=?
OK
AT+QNWINFO
+QNWINFO: "FDD LTE","46001","LTE BAND 3",1650

```

OK

AT+QNWINFO

+QNWINFO: "CDMA1X","46003",283

+QNWINFO: "FDD LTE","46011","LTE BAND 1",75

OK

Preliminary Document
Not Checked

5 Call Control Commands

5.1. ATA Answer an Incoming Call

This command connects the module to an incoming voice or data call indicated by a **RING** URC.

ATA Answer an Incoming Call	
Execution Command ATA	Response TA sends off-hook to the remote station. 1) If a data call connection is successfully established: CONNECT [<text>] Then TA switches to data mode. <text> is outputted only when <value> of ATX is greater than 0. When TA returns to command mode after call release: OK 2) If a voice call connection is successfully established: OK 3) If a connection cannot be established, or was aborted by reception of an additional character from the TE: NO CARRIER
Maximum Response Time	90 s, determined by network.
Characteristics	/
Reference	V.25ter

Parameter

<text>	Integer type. Data rate. See <speed> of AT+CBST .
---------------------	---

NOTE

- Any additional commands that appear after **ATA** on the same command line are ignored.
- This command may be aborted when the module receives a character during command execution, but aborting may not be possible during some states of connection establishments, such as handshaking.

Example

```

RING                                     //Incoming call.
AT+CLCC
+CLCC: 1,1,0,1,0,"",128                //PS call in LTE mode.
+CLCC: 2,1,4,0,0,"02154450290",129    //Incoming call

OK
ATA                                     //Accept the voice call with ATA
OK

```

5.2. ATD Originate a Call

This command sets up an outgoing voice, data or fax call. Supplementary services can also be controlled with this command.

ATD Originate a Call	
Execution Command ATD<n>[<mgs>][;:]	Response If no dial tone is detected: NO DIALTONE If a busy signal is detected: BUSY If a connection cannot be established: NO CARRIER If connection is successful and there is a voice call: OK
Maximum Response Time	5s, determined by network (AT+COLP=0).
Characteristics	/
Reference	V.25ter

Parameter

<n>	String of dialing digits and optionally V.25ter modifiers. Dialing digits: 0-9, *, #, +, A, B, C Following V.25ter modifiers are ignored: ,(comma), T, P, !, W, @
<mgs>	String of GSM modifiers: I Activates CLIR (Disable presentation of own number to the called party) i Deactivates CLIR (Enable presentation of own number to the called party) G Activates closed user group invocation for this call only g Deactivates closed user group invocation for this call only
<;>	It is required when setting up voice call, and will return to command state after call.

NOTE

1. The command may be aborted when the module receives **ATH** or a character, but aborting may not be possible during some states of connection establishments such as handshaking.
2. Using **ATD** during an active voice call:
 - When a user originates a second voice call while there is already an active voice call, the first call will be automatically put on hold.
 - The current states of all calls can be easily checked at any time with **AT+CLCC**.

Example

```
ATD10086;           //Dialing out the other party's number
OK
```

5.3. ATH Disconnect Existing Connection

This command disconnects circuit switched data calls or voice calls. **AT+CHUP** is also used to disconnect a voice call.

ATH Disconnect Existing Connection

Execution Command ATH[n]	Response OK
Maximum Response Time	90 s, determined by network.
Characteristics	/
Reference	V.25ter

Parameter

<n>	Integer type. <u>0</u> Disconnect existing call from command line and terminate the call
------------------	---

5.4. AT+CVHU Voice Hangup Control

This command controls whether **ATH** can be used to disconnect a voice call.

AT+CVHU Voice Hangup Control

Test Command AT+CVHU=?	Response +CVHU: (list of supported<mode>s) OK
----------------------------------	---

Read Command AT+CVHU?	Response +CVHU: <mode> OK
Write Command AT+CVHU=<mode>	Response OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<mode>	Integer type. <u>0</u> ATH can be used to disconnect the voice call 1 ATH ignored but OK response given
---------------------	--

5.5. AT+CHUP Hang up Call

This command cancels all voice calls in the state of Active, Waiting and Held. For disconnection of data calls, use **ATH**.

AT+CHUP Hang up Call	
Test Command AT+CHUP=?	Response OK
Execution Command AT+CHUP	Response OK If there is any error: ERROR
Maximum Response Time	90s, determined by network.
Characteristics	/
Reference	3GPP 27.007

Example

```

RING           //Incoming call
AT+CHUP       //Hangup the call
OK

```

5.6. ATO Switch from Command Mode to Data Mode

This command resumes the connection and returns to data mode from command mode.

ATO Switch from Command Mode to Data Mode	
Execution Command ATO[n]	Response If connection is not successfully resumed: NO CARRIER If connection is successfully resumed, TA returns to data mode from command mode CONNECT [<text>] If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	/
Reference	V.25ter

Parameter

<n>	Integer type. 0 Switch from command mode to data mode
<text>	Integer type. Data rate. See <speed> of AT+CBST .

5.7. ATS0 Set Number of Rings Before Automatic Answering

This command controls the automatic answering mode for the incoming calls.

ATS0 Set Number of Rings Before Automatic Answering	
Read Command ATS0?	Response <n> OK
Write Command ATS0=<n>	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately.
Reference	V.25ter

Parameter

<n>	Integer type.	
	0	Automatic answering is disabled
	1–255	Enable automatic answering on the ring number specified

NOTE

If <n> is set too large, the calling party may hang up before the call is answered automatically.

Example

```

ATS0=3 //Set three rings before automatically answering a call
OK
RING //A call is incoming
RING
RING //Automatically answer the call after the three rings

```

5.8. ATS7 Connection Completion Timeout

This command specifies the amount of time, in seconds, that the module allows between either answering or originating a call, and establishment of a connection. If no connection is established during the time, the module disconnects from the line.

ATS7 Connection Completion Timeout

Read Command ATS7?	Response <n>
	OK
Write Command ATS7=<n>	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately.
Reference	V.25ter

Parameter

<n>	Integer type.
0	Disabled
1–255	Number of seconds in which connection must be established or call will be disconnected

5.9. AT+CBST Select Bearer Service Type

This command selects the bearer service **<name>** with data rate **<speed>**, and the connection element **<ce>** to be used when data calls are originated.

AT+CBST Select Bearer Service Type	
Test Command AT+CBST=?	Response +CBST: (list of supported <speed>s),(list of supported <name>s),(list of supported <ce>s) OK
Read Command AT+CBST?	Response +CBST: <speed> , <name> , <ce> OK
Write Command AT+CBST=[<speed>[,<name>[,<ce>]]]	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations is not saved.
Reference	3GPP TS 27.007

Parameter

<speed>	Integer type. Data rate.
0	autobauding (automatic selection of the speed; this setting is possible in case of 3.1 kHz modem and non-transparent service)
1	300 bps (V.21)
2	1200 bps (V.22)
3	1200/75 bps (V.23)
4	2400 bps (V.22bis)
5	2400 bps (V.26ter)
6	4800 bps (V.32)
7	9600 bps (V.32)
12	9600 bps (V.34)
14	14400 bps (V.34)
15	19200 bps (V.34)
16	28800 bps (V.34)
17	33600 bps (V.34)

34	1200 bps (V.120)
36	2400 bps (V.120)
38	4800 bps (V.120)
39	9600 bps (V.120)
43	14400 bps (V.120)
47	19200 bps (V.120)
48	28800 bps (V.120)
49	38400 bps (V.120)
50	48000 bps (V.120)
51	56000 bps (V.120)
65	300 bps (V.110)
66	1200 bps (V.110)
68	2400 bps (V.110 or X.31 flag stuffing)
70	4800 bps (V.110 or X.31 flag stuffing)
71	9600 bps (V.110 or X.31 flag stuffing)
75	14400 bps (V.110 or X.31 flag stuffing)
79	19200 bps (V.110 or X.31 flag stuffing)
80	28800 bps (V.110 or X.31 flag stuffing)
81	38400 bps (V.110 or X.31 flag stuffing)
82	48000 bps (V.110 or X.31 flag stuffing)
83	56000 bps (V.110 or X.31 flag stuffing;
84	64000 bps (X.31 flag stuffing;
115	56000 bps (bit transparent)
116	64000 bps (bit transparent)
120	32000 bps (PIAFS32k)
121	64000 bps (PIAFS64k)
130	28800 bps (multimedia)
131	32000 bps (multimedia)
132	33600 bps (multimedia)
133	56000 bps (multimedia)
134	64000 bps (multimedia)
<name>	Integer type. Bearer service.
0	data circuit asynchronous (UDI or 3.1 kHz modem)
1	data circuit synchronous (UDI or 3.1 kHz modem)
2	PAD Access (asynchronous) (UDI)
3	Packet Access (synchronous) (UDI)
4	data circuit asynchronous (RDI)
5	data circuit synchronous (RDI)
6	PAD Access (asynchronous) (RDI)
7	Packet Access (synchronous) (RDI)
<ce>	Integer type. Connection element.
0	transparent
1	non-transparent
2	both, transparent preferred
3	both, non-transparent preferred

5.10. AT+CSTA Select Type of Address

This command selects the type of number for further dialing commands **ATD** according to 3GPP TS 24.008.

AT+CSTA Select Type of Address	
Test Command AT+CSTA=?	Response +CSTA: (list of supported <type>s) OK
Read Command AT+CSTA?	Response +CSTA: <type> OK
Write Command AT+CSTA=[<type>]	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.007

Parameter

<type>	Type of address octet in integer format. 129 Unknown type 145 International type (contains the character "+")
---------------------	---

5.11. AT+CLCC List Current Calls

This command returns the list of all current calls. If the command succeeds but no calls are available, no information response but **OK** is sent to TE.

AT+CLCC List Current Calls	
Test Command AT+CLCC=?	Response OK
Execution Command AT+CLCC	Response [+CLCC: <ccid1>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]] [+CLCC: <ccid2>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]] [...] OK If there is any error related to ME functionality:

	+CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	/

Parameter

<ccidx>	Integer type. Call identification number as described in 3GPP TS 22.030 subclause 4.5.5.1.
<dir>	Integer type. 0 Mobile originated (MO) call 1 Mobile terminated (MT) call
<stat>	Integer type. State of the call. 0 Active 1 Held 2 Dialing (MO call) 3 Alerting (MO call) 4 Incoming (MT call) 5 Waiting (MT call)
<mode>	Integer type. Bearer/teleservice. 0 Voice 1 Data 2 Fax
<mpty>	Integer type. 0 Call is not one of multiparty (conference) call parties 1 Call is one of multiparty (conference) call parties
<number>	String type phone number in format specified by <type>.
<type>	Type of address octet in integer format (refer to 3GPP TS 24.008, subclause 10.5.4.7 for details). Usually, it has three kinds of values: 129 Unknown type 145 International type (contains the character "+") 161 National type
<alpha>	String type alphanumeric representation of <number> corresponding to the entry found in phonebook.
<err>	Error codes. For more details, see Chapter 10.2 错误! 未找到引用源。.

Example

```

ATD10086; //Establish a call
OK
AT+CLCC
+CLCC: 1,1,0,1,0,"",128 //PS call in LTE mode
+CLCC: 2,0,0,0,0,"10086",129 //The MO call has been established and is active, and it has
                                been answered
OK

```

5.12. AT+CRC Set Extended Format for Incoming Call Indication

This command controls whether or not the extended format of incoming call indication is used. When enabled, an incoming call is indicated to the TE with unsolicited result code **+CRING: <type>** instead of the normal **RING**.

AT+CRC Set Extended Format for Incoming Call Indication	
Test Command AT+CRC=?	Response +CRC: (list of supported <mode>s) OK
Read Command AT+CRC?	Response +CRC: <mode> OK
Write Command AT+CRC=[<mode>]	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.007

Parameter

<mode>	Integer type. 0 Disable extended format 1 Enable extended format
<type>	String type. ASYNC Asynchronous transparent SYNC Synchronous transparent REL ASYNC Asynchronous non-transparent REL SYNC Synchronous non-transparent FAX Facsimile VOICE Voice VOICE/ASYNC Voice / Asynchronous transparent VOICE/SYNC Voice / Synchronous transparent VOICE/REL ASYNC Voice / Asynchronous non-transparent VOICE/REL SYNC Voice / Synchronous non-transparent ALT VOICE/ASYNC ALT Voice / Asynchronous transparent ALT VOICE/SYNC ALT Voice / Synchronous transparent ALT ASYNC/VOICE ALT Asynchronous transparent / Voice ALT SYNC/VOICE ALT ALT Synchronous transparent / Voice ALT ALT REL ASYNC/VOICE ALT Asynchronous non-transparent / Voice ALT REL SYNC/VOICE ALT Synchronous non-transparent / Voice ALT VOICE/FAX ALT Voice / Facsimile ALT ALT FAX/VOICE ALT Facsimile / Voice

Example

```

AT+CRC=1                                     //Enable extended format.
OK

+CRING: VOICE                                //Indicate incoming call of voice type to TE.
ATH
OK
AT+CRC=0                                     //Disable extended format.
OK

RING                                          //Indicate incoming call to TE.
ATH
OK

```

5.13. AT+CRLP Select Radio Link Protocol Parameter

This command selects radio link protocol (RLP) parameters used when non-transparent data calls are originated.

RLP versions 0 and 1 share the same parameter set. Read and Test Commands return only one line for this set (where **<ver>** may not be presented).

AT+CRLP Select Radio Link Protocol Parameter	
Test Command AT+CRLP=?	Response +CRLP: (range of supported <iws>s),(range of supported <mws>s),(range of supported <T1>s),(range of supported <N2>s),<ver> +CRLP: (range of supported <iws>s),(range of supported <mws>s),(range of supported <T1>s),(range of supported <N2>s),<ver> +CRLP: (range of supported <iws>s),(range of supported <mws>s),(range of supported <T1>s),(range of supported <N2>s),<ver> OK
Read Command AT+CRLP?	Response +CRLP: <iws>,<mws>,<T1>,<N2>[,<ver>[,<T4>]] +CRLP: <iws>,<mws>,<T1>,<N2>[,<ver>[,<T4>]] +CRLP: <iws>,<mws>,<T1>,<N2>[,<ver>[,<T4>]] OK
Write Command AT+CRLP=[<iws>[,<mws>[,<T1>[,<N2>[,<ver>][,<T4>]]]]]	Response OK
Maximum Response Time	300 ms

Characteristics	The command takes effect immediately. The configurations are not saved.
Reference	3GPP TS27.007

Parameter

<iws>	Integer type. IWF to MS window size. Range: 0– <u>61</u> .
<mws>	Integer type. MS to IWF window size. Range: 0– <u>61</u> .
<T1>	Integer type. Acknowledgment timer T1 in a unit of 10 ms. Range: 39–255.
<N2>	Integer type. Retransmission attempts. Range: 1–255.
<ver>	Integer type. RLP version number. Range: 0–1.
<T4>	Integer type. Re-sequencing period. Range: 3–255.

6 Short Message Service Commands

6.1. AT+CSMS Select Message Service

This command selects message service **<service>** and returns the type of messages supported by the ME.

AT+CSMS Select Message Service	
Test Command AT+CSMS=?	Response +CSMS: (list of supported <service>s) OK
Read Command AT+CSMS?	Response +CSMS: <service>,<mt>,<mo>,<bm> OK
Write Command AT+CSMS=<service>	Response +CSMS: <mt>,<mo>,<bm> OK If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<service>	Integer type. Type of message service.
	<u>0</u> 3GPP TS 23.040 and 3GPP TS 23.041 (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 Phase 2 version 4.7.0; Phase 2+ features which do not require new command syntax may be supported, e.g. correct routing of messages with new Phase 2+ data coding schemes).
	1 3GPP TS 23.040 and 3GPP TS 23.041 (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command descriptions).
<mt>	Integer type. Mobile terminated messages.
	0 Type not supported
	<u>1</u> Type supported

<mo>	Integer type. Mobile originated messages. 0 Type not supported 1 Type supported
<bm>	Integer type. Broadcast type messages. 0 Type not supported 1 Type supported
<err>	Error codes. For more details, see Chapter 10.2 .

Example

```

AT+CSMS=?                                //Test command
+CSMS: (0,1)

OK
AT+CSMS=1                                //Set type of message service to 1
+CSMS: 1,1,1

OK
AT+CSMS?                                //Read command
+CSMS: 1,1,1,1

OK

```

6.2. AT+CMGF Message Format

This command specifies the input and output formats of short messages. **<mode>** indicates the format of messages used with send, list, read and write commands and unsolicited result codes resulting from received messages.

The format of messages can be either PDU mode (entire TP data units used) or text mode (headers and body of the messages given as separate parameters). Text mode uses the value of **<chset>** specified by **AT+CSCS** to inform the character set to be used in the message body in the TA-TE interface.

AT+CMGF Message Format	
Test Command AT+CMGF=?	Response +CMGF: (list of supported <mode> s) OK
Read Command AT+CMGF?	Response +CMGF: <mode> OK
Write Command AT+CMGF[=<mode>]	Response OK
Maximum Response Time	300 ms

Characteristics	/
Reference	3GPP TS 27.005

Parameter

<mode>	Integer type.
0	PDU mode
1	Text mode

6.3. AT+CSCA Service Center Address

The Write Command updates the SMSC address when mobile originated SMS are transmitted. In text mode, the setting is used by Write Command. In PDU mode, the setting is used by the same command, but only when the length of the SMSC address is coded into the **<pdu>** which equals zero.

AT+CSCA Service Center Address	
Test Command AT+CSCA=?	Response OK
Read Command AT+CSCA?	Response +CSCA: <sca>,<tosca> OK
Write Command AT+CSCA=<sca>[,<tosca>]	Response OK Or ERROR If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<sca>	Service center address. 3GPP TS 24.011 RP SC address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007); the type of address is given by <tosca> .
<tosca>	Type of service center address. 3GPP TS 24.011 RP SC address Type-of-Address octet in integer format (default see <toda>).
<err>	Error codes. For more details, see Chapter 10.2

Example

```
AT+CSCA="+8613800210500",145 //Set SMSC address
OK
AT+CSCA? //Query SMSC address
+CSCA: "+8613800210500",145
OK
```

6.4. AT+CPMS Preferred Message Storage

This command selects memory storages <mem1>, <mem2> and <mem3> to be used for reading, writing, etc.

AT+CPMS Preferred Message Storage	
Test Command AT+CPMS=?	Response +CPMS: (list of supported <mem1>s),(list of supported <mem2>s),(list of supported <mem3>s) OK
Read Command AT+CPMS?	Response +CPMS: <mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>,<mem3>,<used3>,<total3> OK
Write Command AT+CPMS=<mem1>[,<mem2>[,<mem3>]]	Response +CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3> OK If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<mem1>	String type. Messages to be read and deleted from this memory storage. "SM" (U)SIM message storage "SR" Status report storage "ME" Mobile equipment message storage
<mem2>	String type. Messages will be written and sent to this memory storage. "SM" (U)SIM message storage "SR" Status report storage

<mem3>	"ME" String type. Received messages will be placed in this memory storage if routing to PC is not set (AT+CNMI). "SM" (U)SIM message storage "SR" Status report storage "ME" Mobile equipment message storage
<usedx>	Integer type. The number of current messages in <memx> .
<totalx>	Integer type. The total number of messages which can be stored in <memx>
<err>	Error codes. For more details, see Chapter 10.2 .

Example

```

AT+CPMS? //Query the current SMS message storage
+CPMS: "ME",0,200,"ME",0,200,"ME",0,200

OK
AT+CPMS="SM","SM","SM" //Set SMS message storage as "SM"
+CPMS: 0,50,0,50,0,50

OK
AT+CPMS? //Query the current SMS message storage
+CPMS: "SM",0,50,"SM",0,50,"SM",0,50

OK

```

6.5. AT+CMGD Delete Message

This command deletes short messages from preferred message storage **<mem1>** (see **AT+CPMS**) location **<index>**. If **<delflag>** is presented and not set to 0, the ME should ignore **<index>** and follow the rules of **<delflag>** shown below.

AT+CMGD Delete Message	
Test Command AT+CMGD=?	Response +CMGD: (range of supported <index>s),(range of supported <delflag>s) OK
Write Command AT+CMGD=<index>[,<delflag>]	Response OK If there is any error related to ME functionality: +CMS ERROR:<err>
Maximum Response Time	300 ms. Operation of <delflag> depends on the storage of deleted messages.
Characteristics	/

Reference	3GPP TS 27.005
-----------	----------------

Parameter

<index>	Integer type. A value in the range of location numbers supported by the associated memory.
<delflag>	Integer type. Flag indicating message deletion request.
0	Delete the message specified in <index>
1	Delete all read messages from <mem1>, leaving unread messages and stored mobile originated messages (whether sent or not) untouched
2	Delete all read messages from <mem1> and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched
3	Delete all read messages, sent and unsent mobile originated messages from <mem1>, leaving unread messages untouched
4	Delete all messages from <mem1> including unread messages
<err>	Error codes. For more details, see Chapter 10.2 .

Example

```

AT+CMGD=1 //Delete the message specified in <index>=1
OK
AT+CMGD=1,4 //Delete all messages from <mem1>
OK

```

6.6. AT+CMGL List Messages

This command returns messages with status value <stat> from preferred message storage <mem1> (see **AT+CPMS**) to the TE. If the status of the message is "REC UNREAD", the status in the storage changes to "REC READ". When executing **AT+CMGL** without status value <stat>, it reports the list of SMS with "REC UNREAD" status.

AT+CMGL List Messages

Test Command AT+CMGL=?	Response +CMGL: (list of supported <stat>s) OK
Write Command AT+CMGL[=<stat>]	Response If in text mode (AT+CMGF=1) and the command is executed successfully: For SMS-SUBMITs and/or SMS-DELIVERs: +CMGL: <index>,<stat>,<oa/da>,<[alpha]>,<[scts]>,<[too a/toda>,<length>><CR><LF><data> [+CMGL: <index>,<stat>,<da/oa>,<[alpha]>,<[scts]>,<[to oa/toda>,<length>><CR><LF><data> [...]

	For SMS-STATUS-REPORTs: +CMGL: <index>,<stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> [+CMGL: <index>,<stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> [...]] For SMS-COMMANDs: +CMGL: <index>,<stat>,<fo>,<ct> [+CMGL: <index>,<stat>,<fo>,<ct> [...]] For CBM storage: +CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages><CR><LF><data> [+CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages><CR><LF><data> [...]] OK If in PDU mode (AT+CMGF=0) and the command is executed successfully: +CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu> [+CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu> [...]] OK If there is any error related to ME functionality: +CMS ERROR: <err>
Execution Command AT+CMGL	Response List all messages with "REC UNREAD" status from message storage <mem1>, and then the status in the storage changes to "REC READ".
Maximum Response Time	300 ms Operation of <stat> depends on the storage of listed messages.
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<stat>	Integer type in PDU mode, or string type in text mode. The status of message in memory. Defined values:		
	PDU mode	Text mode	Explanation
0		"REC UNREAD"	Received unread messages
1		"REC READ"	Received read messages
2		"STO UNSENT"	Stored unsent messages
3		"STO SENT"	Stored sent messages
4		"ALL"	All messages

<index>	Integer type. A value in the range of location numbers supported by the associated memory.
<da>	String type. Destination Address. <i>3GPP TS 23.040</i> TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in <i>3GPP TS 27.007</i>). The type of address is given by <toda> .
<oa>	String type. Originating address. <i>3GPP TS 23.040</i> TP-Originating-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in <i>3GPP TS 27.007</i>). The type of address is given by <tooa> .
<alpha>	String type. Alphanumeric representation of <da> or <oa> corresponding to the entry found in MT phonebook; implementation of this feature is manufacturer specified. The used character set should be the one selected with AT+CSCS (see AT+CSCS in <i>3GPP TS 27.007</i>).
<scts>	String type. Service center time stamp. <i>3GPP TS 23.040</i> TP-Service-Centre-Time-Stamp in time-string format (see <dt> in AT+CMGR).
<toda>	Integer type. Type of destination address. <i>3GPP TS 24.011</i> TP-Destination-Address Type-of-Address octet.
<tooa>	Integer type. Type of originating address. <i>3GPP TS 24.011</i> TP-Originating-Address Type-of-Address octet (default see <toda>).
<length>	Message length. Integer type value indicating in text mode (AT+CMGF=1) the length of the message body <data> in characters; or in PDU mode (AT+CMGF=0) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<data>	In the case of SMS: <i>3GPP TS 23.040</i> TP-User-Data in text mode responses; format: - If <dcs> indicates that <i>3GPP TS 23.038</i> GSM 7-bit default alphabet is used and <fo> indicates that <i>3GPP TS 23.040</i> TP-User-Data-Header-Indication is not set: If TE character set other than "HEX" (see AT+CSCS in <i>3GPP TS 27.007</i>): ME/TA converts GSM alphabet into current TE character set according to rules in <i>3GPP TS 27.005 Annex A</i>. If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal number (e.g. character Π (GSM 7 bit default alphabet 23) is presented as 17 (IRA 49 and 55)). - If <dcs> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that <i>3GPP TS 23.040</i> TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: <i>3GPP TS 23.041</i> CBM Content of Message in text mode responses; format: - If <dcs> indicates that <i>3GPP TS 23.038</i> GSM 7-bit default alphabet is used: If TE character set other than "HEX" (see AT+CSCS in <i>3GPP TS 27.007</i>): ME/TA converts GSM alphabet into current TE character set according to rules in <i>3GPP TS 27.005 Annex A</i>. If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7-bit default alphabet into two IRA character long hexadecimal number. - If <dcs> indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.
<pdu>	In the case of SMS: <i>3GPP TS 24.011</i> SC address followed by <i>3GPP TS 23.040</i> TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<fo>	Integer type. First octet. Depending on the command or result code: first octet of <i>3GPP TS 23.040</i> SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2).

<mr>	Integer type. Message reference used to identify a message. 3GPP TS 23.040 TP-Message-Reference.
<ra>	String type. Recipient address. 3GPP TS 23.040 TP-Recipient-Address Address-Value field; BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007); type of address given by <tora>.
<tora>	Integer type. Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet (default see <toda>).
<scts>	String type. Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (see <dt>).
<dt>	String type. 3GPP TS 23.040 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. E.g., 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08".
<st>	Integer type. 3GPP TS 23.040 TP-Status.
<ct>	Integer type. 3GPP TS 23.040 TP-Command-Type (default 0).
<sn>	Integer type. 3GPP TS 23.041 CBM Serial Number.
<mid>	Integer type. 3GPP TS 23.041 CBM Message Identifier.
<page>	Integer type. 3GPP TS 23.041 CBM Page Parameter bits 4–7.
<pages>	Integer type. 3GPP TS 23.041 CBM Page Parameter bits 0–3.
<err>	Error codes. For more details, see Chapter 10.2 .

Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CMGL="ALL" //List all messages from message storage
+CMGL: 1,"STO UNSENT","",,
<This is a test from Quectel>
+CMGL: 2,"STO UNSENT","",,
<This is a test from Quectel>
OK

```

6.7. AT+CMGR Read Message

This command returns SM with location value <index> from message storage <mem1> (see **AT+CPMS**) to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".

AT+CMGR Read Message	
Test Command AT+CMGR=?	Response OK
Write Command AT+CMGR=<index>	Response If in text mode (AT+CMGF=1) and the command is executed successfully: For SMS-DELIVER: +CMGR: <stat>,<oa>,<alpha>,<scts>,<tooa>,<fo>,<pid>,<

	dc<index>,<sca>,<tosca>,<length>]<CR><LF><data> OK For SMS-SUBMIT: +CMGR: <stat>,<da>,<[alpha]>,<[toda>,<fo>,<pid>,<dc>,<[vp>,<sca>,<tosca>,<length>]<CR><LF><data> OK For SMS-STATUS-REPORTs: +CMGR: <stat>,<fo>,<mr>,<[ra>,<[tora>,<scts>,<dt>,<st> OK For SMS-COMMANDs: +CMGR: <stat>,<fo>,<ct>,<[pid>,<[mn>,<[da>,<[toda>,<length>]<CR><LF><cdata> OK For CBM storage: +CMGR: <stat>,<sn>,<mid>,<dc>,<page>,<pages><CR><LF><data> OK If in PDU mode (AT+CMGF=0) and the command is executed successfully: +CMGR: <stat>,<[alpha>,<length>]<CR><LF><pdu> OK If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	Depends on the length of message content.
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<index>	Integer type. A value in the range of location numbers supported by the associated memory.		
<stat>	Integer type in PDU mode, or string type in text mode. The status of message in memory. Defined values:		
	PDU mode	Text mode	Explanation
	0	"REC UNREAD"	Received unread messages
	1	"REC READ"	Received read messages
	2	"STO UNSENT"	Stored unsent messages
	3	"STO SENT"	Stored sent messages
	4	"ALL"	All messages
<alpha>	String type. Alphanumeric representation of <da> or <oa> corresponding to the entry		

	found in MT phonebook; implementation of this feature is manufacturer specified. The used character set should be the one selected with AT+CSCS (see definition of AT+CSCS in 3GPP TS 27.007).
<da>	String type. Destination Address. 3GPP TS 23.040 TP-Destination-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007). The type of address is given by <toda>.
<oa>	String type. Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007). The type of address is given by <tooa>.
<scts>	String type. Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (see <dt> in AT+CMGR).
<fo>	Integer format. First octet. Depending on the command or result code: first octet of 3GPP TS 23.040 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2). If a valid value has been entered once, the parameter can be omitted.
<pid>	Integer type. Protocol identifier. 3GPP TS 23.040 TP-Protocol-Identifier. Default: 0.
<dc>	Integer type. Data coding scheme. Depending on the command or result code: 3GPP TS 23.038 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme.
<vp>	Depending on SMS-SUBMIT <fo> setting: 3GPP TS 23.040 TP-Validity-Period either in integer format or in time-string format (see <dt>).
<mn>	Integer type. Message number. 3GPP TS 23.040 TP-Message-Number.
<mr>	Integer type. Message reference used to identify a message. 3GPP TS 23.040 TP-Message-Reference.
<ra>	String type. Recipient address. 3GPP TS 23.040 TP-Recipient-Address Address-Value field. BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS). The type of address is given by <tora>.
<tora>	Integer type. Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet (default see <toda>).
<toda>	Integer type. Type of destination address. 3GPP TS 24.011 TP-Destination-Address Type-of-Address octet.
<tooa>	Integer type. Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet (default see <toda>).
<sca>	String type. 3GPP TS 24.011 RP SC address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007). The type of address is given by <tosca>.
<tosca>	Integer type. Type of service center address. 3GPP TS 24.011 RP SC address Type-of-Address octet (default see <toda>).
<length>	Message length. Integer type value indicating in the text mode (AT+CMGF=1) the length of the message body <data> (or <cdata>) in characters; or in PDU mode (AT+CMGF=0) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<data>	In the case of SMS: 3GPP TS 23.040 TP-User-Data in text mode responses; format: - If <dc> indicates that 3GPP TS 23.038 GSM 7-bit default alphabet is used and <fo> indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set: If TE character set other than "HEX" (see AT+CSCS in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules in 3GPP TS 27.005 Annex A. If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal number (e.g. character Π (GSM 7 bit default alphabet 23) is presented as 17 (IRA 49 and 55)). - If <dc> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates

that 3GPP TS 23.040 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

In the case of CBS: 3GPP TS 23.041 CBM Content of Message in text mode responses; format:

- If **<dcs>** indicates that 3GPP TS 23.038 GSM 7-bit default alphabet is used:
If TE character set other than "HEX" (see **AT+CSCS** in 3GPP TS27.007): ME/TA converts GSM alphabet into current TE character set according to rules in 3GPP TS 27.005 Annex A.
If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7-bit default alphabet into two IRA character long hexadecimal number.
- If **<dcs>** indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.

<pdu> In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.040 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

<dt> 3GPP TS 23.040 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss zz", during which characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. E.g. 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08".

<st> Integer type. 3GPP TS 23.040 TP-Status.

<ct> The TP-Command-Type is an 8-bit field specifying the type of operation that the SC is to perform. See 3GPP 23.040 for details.

<cdata> The TP-Command-Data field contains data relating to the operation requested by the MS which is to be performed at the SC. The maximum length of this field is 157 octets. The usage and provision of the optional TP Command Data field shall be determined by the function selected by the TP Command Type field. See 3GPP 23.040 for details.

<sn> Integer type. 3GPP TS 23.041 CBM Serial Number.

<mid> Integer type. 3GPP TS 23.041 CBM Message Identifier.

<page> Integer type. 3GPP TS 23.041 CBM Page Parameter bits 4–7.

<pages> Integer type. 3GPP TS 23.041 CBM Page Parameter bits 0–3.

<prt> Integer type. Priority.

- 0 Normal
- 1 Interactive
- 2 Urgent
- 3 Emergency

<fmt> Integer type. Format.

- 0 GSM 7 bit
- 1 ASCII
- 6 Unicode

<prv> Integer type. Privacy.

- 0 Normal
- 1 Restricted
- 2 Confidential
- 3 Secret

<lang> Integer type. Language.

- 0 Unspecified
- 1 English
- 2 French
- 3 Spanish
- 4 Japanese
- 5 Korean
- 6 Chinese
- 7 Hebrew

<type>	Integer type. 0 Normal 1 CPT 2 Voice Mail 3 SMS Report
<err>	Error codes. For more details, see Chapter 10.2 .

Example

```
+CMTI: "SM",3           //A new message has been received and saved to <index>=3 of "SM".
AT+CSDH=1
OK
AT+CMGR=3               //Read message
+CMGR: "REC UNREAD", "+8615021012496", "17/08/30,15:06:37+32",145,4,0,0, "+861380021050 0",
145,27
<This is a test from Quectel>

OK
```

6.8. AT+CMGS Send Message

This command sends a short message from TE to the network (SMS-SUBMIT). After executing the Write Command, wait for the prompt **>** and then start to write the message. After that, press Ctrl + Z to send the message. Sending can be cancelled by pressing Esc. Abortion is acknowledged with **OK**, though the message is not sent. The message reference **<mr>** is returned to the TE on successful message delivery. The value can be used to identify message upon unsolicited delivery status report result code.

AT+CMGS Send Message	
Test Command AT+CMGS=?	Response OK
Write Command 1) If in text mode (AT+CMGF=1): AT+CMGS=<da>[,<tda>] 2) If in PDU mode (AT+CMGF=0): AT+CMGS=<length>	Response > After > is responded, input the text to be sent. Press Ctrl + Z to send the message or Esc to cancel the sending. If in text mode (AT+CMGF=1) and the message is sent successfully: +CMGS: <mr> OK If in PDU mode (AT+CMGF=0) and the message is sent successfully: +CMGS: <mr> OK

	If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	120 s, determined by network.
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<da>	String type. Destination address. <i>3GPP TS 23.040</i> TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in <i>3GPP TS 27.007</i>). The type of address is given by <tda>.
<tda>	Integer type. Type of destination address. <i>3GPP TS 24.011</i> TP-Destination-Address Type-of-Address octet.
<length>	Integer type value indicating in the text mode (AT+CMGF=1) the length of the message body <data> (or <cdata>) in AT+CMGR in characters; or in PDU mode (AT+CMGF=0) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<mr>	Integer type. Message reference used to identify a message. <i>3GPP TS 23.040</i> TP-Message-Reference. <i>3GPP TS 23.040</i> TP-Message-Reference.
<err>	Error codes. For more details, see Chapter 10.2 .

Example

```

AT+CMGF=1                //Set SMS message format to text mode
OK
AT+CSCS="GSM"            //Set character set to "GSM" which is used by the TE
OK
AT+CMGS="15021012496"
><This is a test from Quectel> //Enter the text and press Ctrl + Z to send the message.
+CMGS: 247
OK

```

6.9. AT+CMMS Send More Messages

This command controls the continuity of SMS relay protocol link. When the feature is enabled (and supported by network) multiple messages can be sent much faster as the link is kept open.

AT+CMMS Send More Messages	
Test Command AT+CMMS=?	Response +CMMS: (range of supported<n>s)
	OK

Read Command AT+CMMS?	Response +CMMS: <n> OK
Write Command AT+CMMS[=<n>]	Response OK Or ERROR If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	120 s, determined by network.
Characteristics	This command takes effect immediately. The configuration is not saved
Reference	3GPP TS 27.005

Parameter

<n>	Integer type. 0 Feature disabled 1 Keep enabled until the time between the response of the latest message send command (AT+CMGS , AT+CMSS , etc.) and the next send command exceeds 1–5 seconds (the exact value is up to ME implementation), and then ME closes the link and TA switches <n> automatically back to 0. 2 Feature enabled. If the time between the response of the latest message send command and the next send command exceeds 1–5 seconds (the exact value is up to ME implementation), ME closes the link but TA will not switch <n> automatically back to 0.
<err>	Error codes. For more details, see Chapter 10.2 .

6.10. AT+CMGW Write Message to Memory

This command stores a short message (either SMS-DELIVER or SMS-SUBMIT) to memory storage **<mem2>** (see **AT+CPMS**), and then the memory location **<index>** of the stored message is returned. Message status is set to "STO UNSENT" by default, but **<stat>** also allows other status values to be given.

The entering of text is done similarly as specified in **AT+CMGS**.

AT+CMGW Write Message to Memory	
Test Command AT+CMGW=?	Response OK
Write Command 1) If in text mode (AT+CMGF=1): AT+CMGW=<oa/da>[,<toa/toda>[,<stat>]]<CR>	Response > After > is responded, input the text to be sent. Press Ctrl + Z to send the message or Esc to cancel the sending. If writing is successful:

2) If in PDU mode (AT+CMGF=0): AT+CMGW=<length>[,<stat>]<CR>	+CMGW: <index> OK If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<da>	String type. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007). The type of address is given by <toda> .		
<oa>	String type. Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007). The type of address is given by <tooa> .		
<tooa>	Integer type. Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet (default see <toda>).		
<stat>	PDU mode	Text mode	Explanation
	0	"REC UNREAD"	Received unread messages
	1	"REC READ"	Received read messages
	2	"STO UNSENT"	Stored unsent messages
	3	"STO SENT"	Stored sent messages
	4	"ALL"	All messages
<toda>	Integer type. Type of destination address. 3GPP TS 24.011 TP-Destination-Address Type-of-Address octet.		
<length>	Message length. Integer type value indicating in the text mode (AT+CMGF=1) the length of the message body <data> (or <cdata>) in AT+CMGR in characters; or in PDU mode (AT+CMGF=0) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).		
<pdu>	In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.04 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).		
<index>	Integer type. Index of message in selected storage <mem2> .		
<err>	Error codes. For more details, see Chapter 10.2 .		

Example

```

AT+CMGF=1 //Set SMS message format to text mode
OK
AT+CSCS="GSM" //Set character set as "GSM" which is used by the TE
OK
AT+CMGW="15021012496"
><This is a test from Quectel> //Enter the text and press Ctrl + Z to write message

```

```
+CMGW: 4

OK
AT+CMGF=0           //Set SMS message format to PDU mode
OK
AT+CMGW=18
>0051FF00000008000A0500030002016D4B8BD5
+CMGW: 5

OK
```

6.11. AT+CMSS Send Message from Storage

This command sends a message with location value **<index>** from message storage **<mem2>** (see **AT+CPMS**) to the network (SMS-SUBMIT). If a new destination address **<da>** is given for SMS-SUBMIT, it should be used instead of the one stored with the message. Reference value **<mr>** is returned to the TE on successful message delivery. Values can be used to identify message upon unsolicited delivery status report result code.

AT+CMSS Send Message from Storage	
Test Command AT+CMSS=?	Response OK
Write Command AT+CMSS=<index>[,<da>[,<toda>]]	Response If in text mode (AT+CMGF=1) and the message is sent successfully: +CMSS: <mr>[,<scts>] OK If in PDU mode (AT+CMGF=0) and the message is sent successfully: +CMSS: <mr>[,<ackpdu>] OK If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	120 s, determined by network.
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<index>	Integer type. A value in the range of location numbers supported by the associated
----------------------	--

	memory.
<da>	String type. Destination Address. 3GPP TS 23.040 TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see AT+CSCS in 3GPP TS 27.007). The type of address is given by <tda>.
<tda>	Integer type. Type of destination address. 3GPP TS 24.011 TP-Destination-Address Type-of-Address octet.
<mr>	Integer type. Message reference used to identify a message. 3GPP TS 23.040 TP-Message-Reference.
<scts>	String type. Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (see <dt> in AT+CMGR).
<ackpdu>	3GPP TS 23.040 RP-User-Data element of RP-ACK PDU; format is same for <pdu> in case of SMS, but without 3GPP TS 24.011 SC address field and parameter shall be bounded by double quote characters like a normal string type parameter.
<err>	Error codes. For more details, see Chapter 10.2 .

Example

```

AT+CMGF=1                //Set SMS message format to text mode
OK
AT+CSCS="GSM"            //Set character set as "GSM" which is used by the TE
OK
AT+CMGW="15021012496"
>Hello                    //Enter the text and press Ctrl + Z to send message
+CMGW: 4

OK
AT+CMSS=4                //Send the message of index 4 from memory storage.
+CMSS: 54

OK

```

6.12. AT+CNMI New Message Indications to TE

The Write Command selects the procedure on how receiving of new messages from the network is indicated to the TE when TE is active, e.g. UART1_DTR signal is at low level (ON). If TE is inactive (e.g. UART1_DTR is at high level (OFF)), message receiving should be done as specified in 3GPP TS 23.038.

AT+CNMI New Message Indications to TE	
Test Command AT+CNMI=?	Response +CNMI: (range of supported <mode>s),(range of supported <mt>s),(list of supported <bm>s),(range of supported <ds>s),(list of supported <bfr>s) OK
Read Command	Response

AT+CNMI?	+CNMI: <mode>,<mt>,<bm>,<ds>,<bfr>
	OK
Write Command AT+CNMI=[<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]]	Response OK Or ERROR If there is any error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<mode>	Integer type. 0 Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications. 1 Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in data mode). Otherwise forward them directly to the TE. <u>2</u> Buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE.
<mt>	Integer type. The rules for storing received SMSs depend on its data coding scheme (see 3GPP TS 23.038), preferred memory storage (AT+CPMS) setting, and this value. 0 No SMS-DELIVER indications are routed to the TE. <u>1</u> If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CMTI: <mem>,<index> 2 SMS-DELIVERs (except class 2 messages) are routed directly to the TE using unsolicited result code: +CMT: [<alpha>],<length><CR><LF><pdu> (PDU mode enabled) or +CMT: <oa>,<alpha>,<scts>,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>] <CR><LF><data> (text mode enabled; about the parameters in italics, see AT+CSDH) or Class 2 messages result in indication as defined in <mt>=1 . 3 Class 3 SMS-DELIVERs are routed directly to TE using unsolicited result codes defined in <mt>=2 . Messages of other data coding schemes result in indication as defined in <mt>=1 .
<bm>	Integer type. The rules for storing received CBMs depend on its data coding scheme (see 3GPP TS 23.038) and the setting of Select CBM Types (AT+CSCB) and this value. <u>0</u> No CBM indications are routed to the TE. 2 New CBMs are routed directly to the TE using unsolicited result code: +CBM: <length><CR><LF><pdu> (PDU mode); or +CBM: <sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data> (text mode)
<ds>	Integer type. <u>0</u> No SMS-STATUS-REPORTs are routed to the TE. 1 SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS: <length><CR><LF><pdu> (PDU mode) +CDS: <fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> (text mode)

	2	If SMS-STATUS-REPORT is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CDSI:<mem>,<index>
<bfr>		Integer type.
	0	TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode>=1/2 (OK response shall be given before flushing the codes).
	1	TA buffer of unsolicited result codes defined within this command is cleared when <mode>=1/2 .
<err>		Error codes. For more details, see Chapter 10.2 .

NOTE

Unsolicited result code:

+CMTI: <mem>,<index>

A new message has been received

+CMT: [<alpha>],<length><CR><LF><pdu>

A short message is output directly

+CBM: <length><CR><LF><pdu>

Cell broadcast message is output directly

Example

```

AT+CMGF=1           //Set SMS message format to text mode
OK
AT+CSCS="GSM"       //Set character set to "GSM" which is used by the TE
OK
AT+CNMI=1,2,0,1,0   //Set SMS-DELIVERs are routed directly to the TE
OK

+CMT: "+8615021012496","17/08/30,17:07:21+32",145,4,0,0,"+8613800551500",145,28
This is a test from Quectel.    //Short message is output directly when SMS is incoming.

```

6.13. AT+CSCB Select Cell Broadcast Message Types

This command selects which types of CBMs are to be received by the ME.

AT+CSCB Select Cell Broadcast Message Types	
Test Command AT+CSCB=?	Response +CSCB: (list of supported <mode>s) OK
Read Command AT+CSCB?	Response +CSCB: <mode>,<mids>,<dcss> OK
Write Command AT+CSCB=<mode>[,<mids>[,<dcss>]]	Response OK If there is any error related to ME functionality: +CMS ERROR: <err>

Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.005

Parameter

<mode>	Integer type. 0 Message types specified in <mids> and <dcss> are accepted 1 Message types specified in <mids> and <dcss> are not accepted
<mids>	String type. All different possible combinations of CBM message identifiers (see <mid> in AT+CMGR) (default is empty string), e.g. "0,1,5,320–478,922"
<dcss>	String type. All different possible combinations of CBM data coding schemes (see <dc> in AT+CMGR) (default is empty string), e.g. "0–3,5"
<err>	Error codes. For more details, see Chapter 10.2 .

6.14. AT+CSDH Show Text Mode Parameters

This command controls whether detailed header information is shown in text mode result codes.

AT+CSDH Show Text Mode Parameters	
Test Command AT+CSDH=?	Response +CSDH: (list of supported <show> s) OK
Read Command AT+CSDH?	Response +CSDH: <show> OK
Write Command AT+CSDH=[<show>]	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.005

Parameter

<show>	Integer type. 0 Do not show header values defined in commands AT+CSCA and AT+CSMP (<sca> , <tosca> , <fo> , <vp> , <pid> and <dc>) nor <length> , <toda> or <tooa> in +CMT , +CMGL , +CMGR result codes for SMS-DELIVERs and SMS-
---------------------	--

-
- 1 SUBMITs in text mode.
Show the values in result codes.
-

Example

```

AT+CSDH=0
OK
AT+CMGR=2
+CMGR: "STO UNSENT","",
<This is a test from Quectel>

OK
AT+CSDH=1
OK
AT+CMGR=2
+CMGR: "STO UNSENT","",128,17,0,0,143,"+8613800551500",145,18
<This is a test from Quectel>

OK

```

6.15. AT+CSMP Set Text Mode Parameters (Non-CDMA Network)

This command selects values for additional parameters needed when SM is sent to the network or placed in a storage when text mode is selected (**AT+CMGF=1**). It is possible to set the validity period starting from when the SM is received by the SMSC (**<vp>** is in range 0 to 255) or define the absolute time of the validity period termination (**<vp>** is a string).

AT+CSMP Set Text Mode Parameters (Non-CDMA Network)	
Test Command AT+CSMP=?	Response OK
Read Command AT+CSMP?	Response +CSMP: <fo>,<vp>,<pid>,<dcs> OK
Write Command AT+CSMP=[<fo>,<vp>,<pid>,<dcs>]]]	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.005

Parameter

<fo>	Integer type. First octet. Depending on the command or result code: First octet of <i>3GPP TS 23.040</i> SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, SMS-COMMAND in integer format. If a valid value has been entered once, the parameter can be omitted.
<vp>	Validity period. Depending on SMS-SUBMIT <fo> setting: <i>3GPP TS 23.040</i> TP-Validity-Period either in integer format or in time-string format (see <dt> in AT+CMGR).
<pid>	Integer type. Protocol identifier. <i>3GPP TS 23.040</i> TP-Protocol-Identifier (default 0).
<dc>	Integer type. Data coding scheme. Depending on the command or result code: <i>3GPP TS 23.038</i> SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme.

Preliminary Document
Not Checked

7 Packet Domain Commands

7.1. AT+CGATT PS Attach or Detach

This command attaches the MT to, or detaches the MT from, the Packet Domain service. After the command has completed, the MT remains in V.250 command state. If MT is already in the requested state, the command is ignored and the **OK** response is returned. If the requested state cannot be achieved, an **ERROR** or **+CME ERROR** response is returned.

AT+CGATT PS Attach or Detach	
Test Command AT+CGATT=?	Response +CGATT: (list of supported <state>s) OK
Read Command AT+CGATT?	Response +CGATT: <state> OK
Write Command AT+CGATT=<state>	Response OK Or ERROR If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	140 s, determined by the network.
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<state>	Integer type. The state of PS attachment. 0 Detached 1 Attached Other values are reserved and will result in an ERROR to the Write Command.
<err>	MT error result code. See Chapter 10.2 for details.

Example

```
AT+CGATT=1 //Attach to PS service.
```

```

OK
AT+CGATT=0                                     //Detach from PS service.
OK
AT+CGATT?                                       //Query the current PS service state.
+CGATT: 0
OK

```

7.2. AT+CGDCONT Define PDP Context

This command specifies PDP context parameters for a specific context **<cid>**. A special form of the Write Command (**AT+CGDCONT=<cid>**) causes the values for context **<cid>** to become undefined. It is not allowed to change the definition of an already activated context.

This Read Command returns the current settings for each defined PDP context.

AT+CGDCONT Define PDP Context	
Test Command AT+CGDCONT=?	Response +CGDCONT: (range of supported <cid>s),(<PDP_type>),(<APN>),(<PDP_addr>),(range of supported <d_comp>s),(range of supported <h_comp>s),(list of supported <IPv4AddrAlloc>s),(list of supported <request_type>s),(range of supported <P-CSCF_discovery>s),(list of supported <IM_CN_Signalling_Flag_Ind>s) OK
Read Command AT+CGDCONT?	Response +CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>,<IPv4AddrAlloc>,<request_type>,<P-CSCF_discovery>,<IM_CN_Signalling_Flag_Ind> [...] OK
Write Command AT+CGDCONT=<cid>[,<PDP_type>[,<APN>[,<PDP_addr>[,<d_comp>[,<h_comp>[,<IPv4AddrAlloc>[,<request_type>[,<P-CSCF_discovery>[,<IM_CN_Signalling_Flag_Ind>]]]]]]]]]	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<cid>	Integer type. PDP context identifier. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value=1) is returned by the Test Command. Range: 1–15.
<PDP_type>	String type. Packet data protocol type, a string parameter which specifies the type of packet data protocol. Only "IP", "IPv6" and "IPV4V6" are supported for EPS services. "IP" IPv4. Internet protocol (<i>IETF STD 5</i>) "PPP" Point to Point Protocol (<i>IETF STD 51</i>) "IPv6" Internet Protocol, version 6 (see <i>RFC 2460</i>) "IPV4V6" Virtual <PDP_type> introduced to handle dual IP stack UE capability (See <i>3GPP TS 24.301</i>)
<APN>	String type. Access point name, a logical name used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested.
<PDP_addr>	String type. Identifies the MT in the address space applicable to the PDP. If the value is null or omitted, then a value may be provided by the TE during the PDP startup procedure or, failing that, a dynamic address will be requested. The allocated address may be read using AT+CGPADDR .
<d_comp>	Integer type. Controls PDP data compression (applicable for SNDCP only) (see <i>3GPP TS 44.065</i>). 0 Off 1 On (Manufacturer preferred compression) 2 V.42bis 3 V.44 (Not supported currently)
<h_comp>	Integer type. Controls PDP header compression (see <i>3GPP TS 44.065</i> and <i>3GPP TS 25.323</i>). 0 Off 1 On 2 RFC1144 [105] (applicable for SNDCP only) 3 RFC2507 [107] 4 RFC3095 [108] (applicable for PDCP only)
<IPv4AddrAlloc>	Integer type. Controls how the MT/TA requests to get the IPv4 address information. 0 IPv4 address allocated through NAS signaling 1 IPv4 address allocated through DHCP
<request_type>	Integer type. Type of PDP context activation request for the PDP context. Refer to <i>3GPP TS 24.301 (subclause 6.5.1.2)</i> and <i>3GPP TS 24.008 (subclause 10.5.6.17)</i> . According to <i>3GPP TS 24.008 (subclause 4.2.4.2.2 and 4.2.5.1.4)</i> and <i>3GPP TS 24.301 (subclause 5.2.2.3.3 and 5.2.3.2.2)</i> , a separate PDP context must be established for emergency bearer services.
<P-CSCF_discovery>	Integer type. Influences how the MT/TA requests to get the P-CSCF address, (see <i>3GPP TS 24.229 annex B and L</i>). 0 Preference of P-CSCF address discovery not influenced by AT+CGDCONT 1 Preference of P-CSCF address discovery through NAS signaling 2 Preference of P-CSCF address discovery through DHCP
<IM_CN_Signalling_Flag_Ind>	Integer type. Indicates to the network whether the PDP context is for IM CN subsystem-related signaling only or not. 0 UE indicates that the PDP context is not for IM CN subsystem-related signaling only

1	UE indicates that the PDP context is for IM CN subsystem-related signaling only
---	---

7.3. AT+CGACT Activate or Deactivate PDP Contexts

This command activates or deactivates the specified PDP context(s). After the command has completed, the MT remains in V.250 command state. If any PDP context is already in the requested state, the state for that context remains unchanged. If MT is not PS attached when the activation form of the command is executed, MT first performs a PS attach and then attempts to activate the specified contexts. If no **<cid>**s specify the activation/deactivation form of the command, the command activates or deactivates all defined PDP contexts.

AT+CGACT Activate or Deactivate PDP Contexts	
Test Command AT+CGACT=?	Response +CGACT: (list of supported <state>s) OK
Read Command AT+CGACT?	Response +CGACT: <cid>,<state> [...] OK
Write Command AT+CGACT=<state>,<cid>	Response OK Or NO CARRIER If there is any error related to MT functionality: +CME ERROR: <err> Or ERROR
Maximum Response Time	150 s, determined by the network.
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<state>	Integer type. State of PDP context activation. 0 Deactivated 1 Activated Other values are reserved and result in an ERROR to the Write Command.
<cid>	Integer type. Specifies a particular PDP context definition (see AT+CGDCONT).
<err>	MT error result code. See Chapter 10.2 for details.

Example

```

AT+CGDCONT=2,"IP","UNINET"           //Define PDP context.
OK
AT+CGACT=1,2                           //Activate PDP context
OK
AT+CGACT?                               //Query the current PDP context state.
+CGACT: 1,1
+CGACT: 2,1

OK
AT+CGACT=0,2                           //Deactivate the PDP.context
OK

```

7.4. AT+CGPADDR Show PDP Address(es)

This command returns a list of PDP addresses for the specified context identifiers. If no **<cid>** is specified, the addresses for all defined contexts are returned.

AT+CGPADDR Show PDP Address(es)	
Test Command AT+CGPADDR=?	Response +CGPADDR: (list of defined <cid>s) OK
Write Command AT+CGPADDR[=<cid>[,<cid>[,...]]]	Response +CGPADDR: <cid>,<PDP_addr> [...] OK Or ERROR
Maximum Response Time	300 ms
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<cid>	Integer type. A particular PDP context definition (see AT+CGDCONT).
<PDP_addr>	String type. Identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it is the one set by AT+CGDCONT when the context is defined. For a dynamic address, it is the one assigned during the last PDP context activation that used the context definition referred to by <cid> . <PDP_addr> is omitted if no address is available.

Example

```

AT+CGDCONT=1,"IP","UNINET" //Define a PDP context.
OK
AT+CGACT=1,1 //Activated the PDP.
OK
AT+CGPADDR=1 //Show the PDP address.
+CGPADDR: 1,"10.76.51.180"
OK
    
```

7.5. AT+CGCLASS GPRS Mobile Station Class

This command sets the MT to operate according to the specified mode of operation. For details, see 3GPP TS 23.060.

AT+CGCLASS GPRS Mobile Station Class	
Test Command AT+CGCLASS=?	Response +CGCLASS: (list of supported <class>s) OK
Read Command AT+CGCLASS?	Response +CGCLASS: <class> OK
Write Command AT+CGCLASS=<class>	Response OK If there is any error: +CME ERROR: <err> Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<class>	String type. GPRS mobile class (Functionality in descending order).
A	Class-A mode of operation (A/Gb mode), or CS/PS mode of operation (highest mode of operation)
B	Class-B mode of operation (A/Gb mode), or CS/PS mode of operation
CG	Class-C mode of operation in PS only mode (A/Gb mode), or PS mode of operation
CC	Class-C mode of operation in CS only mode (A/Gb mode), or CS (lowest mode of

operation)
<err> Error codes. For more details, see **Chapter 10.2**.

7.6. AT+CGREG GPRS Network Registration Status

This command queries the network registration status and controls the presentation of an unsolicited result code **+CGREG: <stat>** when **<n>=1** and there is a change in the MT's GPRS network registration status in GERAN/UTRAN, or unsolicited result code **+CGREG: <stat>[,<lac>],[<ci>],[<AcT>],[<rac>]]** when **<n>=2** and there is a change of the network cell in GERAN/UTRAN.

AT+CGREG GPRS Network Registration Status	
Test Command AT+CGREG=?	Response +CGREG: (range of supported <n>s) OK
Read Command AT+CGREG?	Response +CGREG: <n>,<stat>[,<lac>],[<ci>],[<AcT>],[<rac>]] OK
Write Command AT+CGREG=<n>	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.007

Parameter

<n>	Integer type. 0 Disable network registration unsolicited result code 1 Enable network registration unsolicited result code +CGREG: <stat> 2 Enable network registration and location information unsolicited result code +CGREG: <stat>[,<lac>],[<ci>],[<AcT>],[<rac>]]
<stat>	Integer type. GPRS registration status. 0 Not registered. MT is not currently searching an operator to register to. The UE is in GMM state GMM-NULL or GMM-DEREGISTERED-INITIATED. The GPRS service is disabled, but the UE is allowed to attach for GPRS if requested by the user. 1 Registered, home network. The UE is in GMM state GMM-REGISTERED or GMM-ROUTING-AREA-UPDATING-INITIATED INITIATED on the home PLMN. 2 Not registered, but MT is trying to attach or searching an operator to register to. UE is in GMM state GMM-DEREGISTERED or GMM-REGISTERED-INITIATED. The GPRS service is enabled, but an allowable PLMN is currently not available. The UE will start a GPRS attach as soon as an allowable PLMN is available. 3 Registration denied. The UE is in GMM state GMM-NULL. The GPRS service is disabled, and the UE is not allowed to attach for GPRS if requested by the user.

	4	Unknown (e.g. out of GERAN/UTRAN coverage)
	5	Registered, roaming
<lac>	String type. Two-byte location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal).	
<ci>	String type. Four byte GERAN/UTRAN cell ID in hexadecimal format.	
<AcT>	Integer type. Access technology selected.	
	0	GSM
	2	UTRAN
	3	GSM w/EGPRS
	4	UTRAN w/HSDPA
	5	UTRAN w/HSUPA
	6	UTRAN w/HSDPA and HSUPA
	7	E-UTRAN
<rac>	String type; one byte routing area code in hexadecimal format.	

7.7. AT+CGEREP Packet Domain Event Reporting

This command enables or disables sending of unsolicited result codes **+CGEV: XXX** from MT to TE in the case of certain events occurring in the Packet Domain MT or the network. **<mode>** controls the processing of unsolicited result codes specified within this command. **<bfr>** controls the effect on buffered codes when **<mode>=1** or **2** is entered.

AT+CGEREP Packet Domain Event Reporting	
Test Command AT+CGEREP=?	Response +CGEREP: (range of supported <mode>s),(list of supported <bfr>s) OK
Read Command AT+CGEREP?	Response +CGEREP: <mode>,<bfr> OK Or ERROR
Write Command AT+CGEREP=<mode>[,<bfr>]	Response OK Or ERROR
Execution Command AT+CGEREP	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<mode>	Integer type. 0 Buffer unsolicited result codes in the MT; if MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to the TE. 1 Discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode), otherwise forward them directly to the TE. 2 Buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available. Otherwise forward them directly to the TE.
<bfr>	Integer type. 0 MT buffer of unsolicited result codes defined within this command is cleared when <mode> 1 or 2 is specified. 1 MT buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1 or 2 is specified (OK response shall be given before flushing the codes).

NOTE

The unsolicited result codes and the corresponding events are defined as follows:

1. **+CGEV: REJECT <PDP_type>,<PDP_addr>**: A network request for PDP context activation occurred when the MT was unable to report it to the TE with a **+CRING** unsolicited result code and was automatically rejected. (See **AT+CGDCONT**)
 Note: This event is not applicable for EPS.
2. **+CGEV: NW REACT <PDP_type>,<PDP_addr>,<cid>**: The network has requested a context reactivation. The **<cid>** used to reactivate the context is provided if known to the MT. (See **AT+CGDCONT**)
 Note: This event is not applicable for EPS.
3. **+CGEV: NW DEACT <PDP_type>,<PDP_addr>,<cid>**: The network has forced a context deactivation. The **<cid>** used to activate the context is provided if known to the MT. (See **AT+CGDCONT**)
4. **+CGEV: ME DEACT <PDP_type>,<PDP_addr>,<cid>**: The mobile equipment has forced a context deactivation. The **<cid>** used to activate the context is provided if known to the MT. (See **AT+CGDCONT**)
5. **+CGEV: NW DETACH**: The network has forced a Packet Domain detach. This implies that all active contexts have been deactivated. These are not reported separately.
6. **+CGEV: ME DETACH**: The mobile equipment has forced a Packet Domain detach. This implies that all active contexts have been deactivated. These are not reported separately.
7. **+CGEV: NW CLASS <class>**: The network has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS**).
8. **+CGEV: ME CLASS <class>**: The mobile equipment has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS**).
9. **+CGEV: PDN ACT <cid>**: Activated a context. The context represents a PDN connection in LTE or a Primary PDP context in GSM/UMTS. (See **AT+CGDCONT**)
10. **+CGEV: PDN DEACT <cid>**: Deactivated a context. The context represents a PDN connection in LTE or a Primary PDP context in GSM/UMTS. (See **AT+CGDCONT**)

7.8. AT+CGSMS Select Service for MO SMS Messages

This command specifies the service or service preference that the MT will use to send MO (mobile originated) SMS messages.

AT+CGSMS Select Service for MO SMS Messages	
Test Command AT+CGSMS=?	Response +CGSMS: (range of currently available <service>s) OK
Read Command AT+CGSMS?	Response +CGSMS: <service> OK
Write Command AT+CGSMS=<service>	Response OK If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	3GPP TS 27.007

Parameter

<service>	Integer type. Service or service preference to be used. 0 Packet domain <u>1</u> Circuit switched 2 Packet domain preferred (use circuit switched if GPRS not available) 3 Circuit switch preferred (use Packet domain if circuit switched not available)
<err>	MT error result code. See Chapter 10.2 for details.

7.9. AT+CEREG EPS Network Registration Status

This command queries the network registration status and controls the presentation of an unsolicited result code **+CEREG: <stat>** when <n>=1 and there is a change in the MT's EPS network registration status in E-UTRAN, or unsolicited result code **+CEREG: <stat>[,<tac>],[<ci>],[<AcT>]]** when <n>=2 and there is a change of the network cell in E-UTRAN.

AT+CEREG EPS Network Registration Status	
Test Command AT+CEREG=?	Response +CEREG: (range of supported <n>s)

	OK
Read Command AT+CEREG?	Response +CEREG: <n>,<stat>[,<tac>,<ci>[,<AcT>]]
Write Command AT+CEREG=<n>	OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.007

Parameter

<n>	Integer type. 0 Disable network registration unsolicited result code 1 Enable network registration unsolicited result code +CEREG: <stat> 2 Enable network registration and location information unsolicited result code +CEREG: <stat>[,<tac>],[<ci>],[<AcT>]]
<stat>	Integer type. EPS registration status. 0 Not registered. MT is not currently searching an operator to register to 1 Registered, home network 2 Not registered, but MT is currently trying to attach or searching an operator to register to 3 Registration denied 4 Unknown (e.g. out of E-UTRAN coverage) 5 Registered, roaming
<tac>	String type. Two-byte tracking area code in hexadecimal format.
<ci>	String type. Four byte E-UTRAN cell ID in hexadecimal format.
<AcT>	Integer type. Access technology selected. 0 GSM 2 UTRAN 3 GSM w/EGPRS 4 UTRAN w/HSDPA 5 UTRAN w/HSUPA 6 UTRAN w/HSDPA and HSUPA 7 E-UTRAN

8 Audio Commands

8.1. AT+CLVL Loudspeaker Volume Level

This command selects the volume level of the internal loudspeaker of the MT.

AT+CLVL Loudspeaker Volume Level	
Test Command AT+CLVL=?	Response +CLVL: (list of supported<level>s) OK
Read Command AT+CLVL?	Response +CLVL: <level> OK Or ERROR
Write Command AT+CLVL=<level>	Response OK Or ERROR If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	Reference 3GPP TS 27.007

Parameter

<level>	Integer type. Volume level with manufacturer specific range (Smallest value represents the lowest sound level). Range: 0–5; Default: 3.
<err>	MT error result code. See Chapter 10.2 for details.

8.2. AT+VTS DTMF and Tone Generation

This command sends ASCII characters which cause MSC to transmit DTMF tones to a remote subscriber. This command can only be operated in a voice call.

AT+VTS DTMF and Tone Generation	
Test Command AT+VTS=?	Response +VTS: (list of supported <DTMF_string>s),(range of supported <duration>s) OK
Write Command AT+VTS=<DTMF_string>[,<duration>]	Response OK Or ERROR If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	Depends on the length of <DTMF_string> and <duration> .
Characteristics	/
Reference	3GPP TS 27.007

Parameter

<DTMF_string>	String type. ASCII characters in the set 0...9,#,*, A, B, C, D. The string should be enclosed in quotation marks ("..."). When sending multiple tones at a time, the time interval of two tones <interval> can be specified by AT+VTD . The maximal length of the string is 31 bytes.
<duration>	The duration of each tone in 10 ms with tolerance. Range: 300–600. Default: 300. If the duration is less than the minimum time specified by the network, the actual duration will be the network specified time.
<err>	If this parameter is omitted, <duration> can be specified by AT+VTD . MT error result code. See Chapter 10.2 for details.

Example

```

ATD12345678900;           //Dial.
OK
//Call connected.
AT+VTS="1"                 //The remote caller can hear the DTMF tone.
OK
AT+VTS="1234567890A"       //Send multiple tones at a time.
OK

```

8.3. AT+VTD Tone Duration

This command sets the duration of DTMF tones. It can also set time interval of two tones when sending multiple tones at a time.

AT+VTD Tone Duration	
Test Command AT+VTD=?	Response +VTD: (range of supported <duration>s),(range of supported <interval>s) OK
Read Command AT+VTD?	Response +VTD: <duration> , <interval> OK
Write Command AT+VTD=<duration>[,<interval>]	Response OK Or ERROR If there is any error related to MT functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.007

Parameter

<duration>	Integer type. The duration tone in 1/10 seconds with tolerance. Range: 300-600. Default value: 300. If the duration is less than the minimum time specified by the network, the actual duration will be network specified time.
<interval>	Integer type. The time interval of two tones when sending multiple tones at a time by AT+VTS . Range: 300-600. Default value: 300. Unit: 100 ms.
<err>	MT error result code. See Chapter 10.2 for details.

9 Hardware Related Commands

9.1. AT+QADC Read ADC Value

This command reads the voltage value of ADC channel.

AT+QADC Read ADC Value	
Test Command AT+QADC=?	Response +QADC: (list of supported <port>s) OK
Read Command AT+QADC=<port>	Response +QADC: <status>,<value> OK
Maximum Response Time	300 ms
Characteristics	/

Parameter

<port>	Integer type. Channel number of the ADC. 0 ADC channel 0 1 ADC channel 1
<status>	Integer type. Whether the ADC value read is successful. 0 Failed 1 Successful
<value>	Integer type. The voltage of specified ADC channel. Unit: mV.

10 Appendix References

10.1. References

Table 2: Terms and Abbreviations

Abbreviation	Description
3GPP	3rd Generation Partnership Project
ADC	Analog-to-Digital Converter
APN	Access Point Name
ASCII	American Standard Code for Information Interchange
BAIC	Bar All Incoming Calls
BAOC	Bar All Outgoing Calls
BCD	Binary-Coded Decimal
BOIC	Bar Outgoing International Calls
BOIC-exHC	Bar Outgoing International Calls except to Home Country
CS	Circuit Switching
DCE	Data Communication Equipment
DHCP	Dynamic Host Configuration Protocol
DTE	Data Terminal Equipment
DTMF	Dual-Tone Multifrequency
EGPRS	Enhanced General Packet Radio Service
EPS	Evolved Packet System

E-UTRAN	Evolved Universal Terrestrial Radio Access Network
GGSN	Gateway GPRS Support Node
GMM	GPRS Mobility Management
GMT	Greenwich Mean Time
GPRS	General Packet Radio Service
GSM	Global System for Mobile Communications
HSDPA	High Speed Downlink Packet Access
HSUPA	High Speed Uplink Packet Access
IMEI	International Mobile Equipment Identity
IMSI	International Mobile Subscriber Identity
IP	Internet Protocol
IPv4	Internet Protocol version 4
IPv6	Internet Protocol version 6
IRA	International Reference Alphabet
ME	Mobile Equipment
MO	Mobile Originated
MS	Mobile Station
MSC	Mobile Switching Center
MT	Mobile Terminal
NAS	Non-Access Stratum
NITZ	Network Identity and Time Zone/Network Informed Time Zone
P-CSCF	Proxy-Call Session Control Function
PDP	Packet Data Protocol
PDU	Packet Data Unit
PIN	Personal Identification Number

PLMN	Public Land Mobile Network
PPP	Point-to-Point Protocol
PS	Packet Switching
PUK	PIN Unlock Key
RAT	Radio Access Technology
RF	Radio Frequency
RX	Receive
RxQual	Receive Quality
SM	Session Management
SMS	Short Message Service
SMSC	Short Message Service Center
SNDCP	SubNetwork Dependent Convergence Protocol
TA	Terminal Adapter
TE	Terminal Equipment
TFT	Traffic Flow Template
TPDU	Transport Protocol Data Unit
UART	Universal Asynchronous Receiver/Transmitter
USC-2	Universal Character Set (UCS-2) Format
UE	User Equipment
UICC	Universal Integrated Circuit Card
UIM	User Identity Model
UMTS	Universal Mobile Telecommunications System
URC	Unsolicited Result Code
USB	Universal Serial Bus
(U)SIM	(Universal) Subscriber Identity Module

VLR

Visiting Location Register

10.2. Mobile Termination Error Result Code +CME ERROR

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation of **+CME ERROR: <err>** final result code is similar to the regular **ERROR** result code: if **+CME ERROR: <err>** is the result code for any of the commands in a command line, none of the following commands in the same command line is executed (neither **ERROR** nor **OK** result code shall be returned as a result of a completed command line execution). The format of **<err>** can be either numeric or verbose.

The following table lists some general errors. For some GSM protocol failure cause described in GSM specifications, the corresponding **ERROR** codes are not included.

Table 3: Summary of General +CME ERROR Codes

Numeric <err> Value	Verbose <err> Value
0	phone failure
1	no connection to phone
2	phone-adaptor link reserved
3	operation not allowed
4	operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy

15	SIM wrong
16	incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	memory full
21	invalid index
22	not found
23	memory failure
24	text string too long
25	invalid characters in text string
26	dial string too long
27	invalid characters in dial string
30	no network service
31	network timeout
32	network not allowed - emergency calls only
40	network personalization PIN required
41	network personalization PUK required
42	network subset personalization PIN required
43	network subset personalization PUK required
44	service provider personalization PIN required
45	service provider personalization PUK required
46	corporate personalization PIN required
47	corporate personalization PUK required
901	audio unknown error
902	audio invalid parameters

903	audio operation not supported
904	audio device busy

10.3. Summary of URC

Table 4: Summary of URC

Index	URC Display	Meaning	Condition
1	+CREG: <stat>	Registration status of the MT	AT+CREG=1
2	+CREG: <stat>[, [<lac>], [<ci>], [<AcT>]]	After cell neighborhood changing shows whether the network has currently indicated the registration of the MT, with location area code	AT+CREG=2
3	+CGREG: <stat>	Network registration status of the MT	AT+CGREG=1
4	+CGREG: <stat>[, [<lac>], [<ci>], [<AcT>], [<rac>]]	Network registration and location information of the MT	AT+CGREG=2
5	+CEREG: <stat>	EPS network registration status of the MT	AT+CEREG=1
6	+CEREG: <stat>[, [<tac>], [<ci>], [<AcT>]]	EPS network registration and location information of the MT	AT+CEREG=2
7	+CTZV: <tz>	Time zone reporting	AT+CTZR=1
8	+CTZE: <tz>, <dst>, <time>	Extended time zone reporting	AT+CTZR=2
9	RING	An incoming call	N/A
10	+CFUN: 1	All function of the MT is available	N/A
11	+CPIN: <state>	(U)SIM card pin state	N/A
12	+CGEV: REJECT <PDP_type>, <PDP_addr>	A network request for PDP activation, and was automatically rejected.	AT+CGEREP=2,1
13	+CGEV: NW REACT <PDP_type>, <PDP_addr>, [<cid>]	The network request PDP reactivation	AT+CGEREP=2,1
14	+CGEV: NW DEACT <PDP_type>, <PDP_addr>, [<cid>]	The network has forced a context deactivation	AT+CGEREP=2,1
15	+CGEV: ME DEACT <PDP_type>, <PDP_addr>, [<cid>]	The ME has forced a context deactivation.	AT+CGEREP=2,1
16	+CGEV: NW DETACH	The network has forced a Packet Domain detach.	AT+CGEREP=2,1

17	+CGEV: ME DETACH	The mobile equipment has forced a Packet Domain detach.	AT+CGEREP=2,1
18	+CGEV: NW CLASS <class>	The network has forced a change of MS class.	AT+CGEREP=2,1
19	+CGEV: ME CLASS <class>	The mobile equipment has forced a change of MS class.	AT+CGEREP=2,1
20	+CGEV: PDN ACT <cid>	Activated a context.	AT+CGEREP=2,1
21	+CGEV: PDN DEACT <cid>	Deactivated a context.	AT+CGEREP=2,1

Preliminary Document
Not Checked