## **RUL ANALYSIS**

## PRELIMINARY STEPS FOR RUL

6 Steps 🔼


- 1. Fill the Data in View Or Update Data / Add Sensor Data
- 2. Follow the below guide

STEP 2


Click on TIME TO FAILURE / RUL



STEP 3




## STEP 4 Select Parameter




STEP 5

## **Click on CALCULATE RUL**



STEP 6

It Shows P & F values of the selected Parameter



STEP 7

Click on Calculate Button it shows RUL for 0.8, 0.85, 0.9, 0.95 confidance levels

