Version 12
June 2003
Standard Enumeration Master List

LONMARK®
Standard Enumeration Master List

Copyright © 1991–2003 Echelon Corporation

Contents

Contents 2
Enumeration Master List Introduction 4
alarm_type_t (7) 4
boolean_t (41) 5
calendar_type_t (29) 5
cam_act_t (38) 5
cam_func_t (37) 6
chiller_t (25) 6
config_source_t (4) 6
control_resp_t (32) 7
currency_t (9) 7
days_of_month_t (54) 9
days_of_week_t (1) 10
defrost_mode_t (22) 10
defrost_state_t (24) 10
defrost_term_t (23) 11
device_c_mode_t (44) 11
device_select_t (50) 12
discrete_levels_t (2) 12
emerg_t (13) 12
ent_cmd_t (48) 13
ent_opmode_cmd_t (47) 13
evap_t (20) 14
event_mode_type_t (48) 14
ex_control_t (42) 15
fan_operation_t (52) 15
file_request_t (5) 15
file_status_t (6) 16
fire_indicator_t (28) 16
fire_initiator_t (27) 17
fire_test_t (26) 17
flow_direction_t (49) 17
gfci_status_t (39) 18
hvac_hvt_t (31) 18
hvac_overid_t (16) 18
hvac_t (14) 20
learn_mode_t (11) 20
master_slave_t (51) 21
months_t (55) 22
motor_state_t (40) 22
nv_type_category_t (46) 23
object_request_t (10) 23
occup_t (15) 24
override_t (12) 24
pan_dir_t (33) 25
priority_level_t (8) 25
privacyzone_t (36) 25
reg_val_unit_t (30) 26
scene_config_t (18) 27
scene_t (17) 27

setting_t (19) 28
telcom_states_t (3) 28
therm_mode_t (21) 29
tilt_dir_t (34) 29
unit_temp_t (43) 29
valve_mode_t (45) 30
zoom_t (35) 30

Enumeration Master List Introduction

Standard enumeration types facilitate interoperability by providing standard definitions for enumerated values used for communication between devices or for configuring a device..

This document provides information on all available standard enumeration types. A standard enumeration type index is defined for each standard enumeration type that is used when defining enumeration type references in SNVT and SCPT definitions. The enumeration type names are provided for use in network and development tools.

alarm_type_t (7)

Alarm Type

Defined in: snvt_al.h

Value	Identifier	Notes
-13 (0xF3)	AL_HEADER	Update sequence header
-12 (0xF4)	AL_FOOTER	Update sequence footer
-11 (0xF5)	AL_DEBUG	Debug information (not an alarm)
-10 (0xF6)	AL_INFO	Information update (not an alarm)
-6 (0xFA)	AL_SYSTEM_INFO	System information (not an alarm)
-5 (0xFB)	AL_VALUE_INVALID	The value is invalid
-4 (0xFC)	AL_CONSTANT	The value is a constant value (not an alarm)
-3 (0xFD)	AL_OFFLINE	The device is offline
-2 (0xFE)	AL_UNKNOWN	Alarm condition unknown (may be due to a communication failure or hardware failure)
-1 (0xFF)	AL_NUL	Invalid alarm type value (alarm condition not specified)
0	AL_NO_CONDITION	No alarm condition present
1	AL_ALM_CONDITION	Unspecified alarm condition present
2	AL_TOT_SVC_ALM_1	Total/service interval alarm 1 (component requires service or maintenance)
3	AL_TOT_SVC_ALM_2	Total/service interval alarm 2
4	AL_TOT_SVC_ALM_3	Total/service interval alarm 3
5	AL_LOW_LMT_CLR_1	Alarm low limit alarm clear 1
6	AL_LOW_LMT_CLR_2	Alarm low limit alarm clear 2
7	AL_HIGH_LMT_CLR_1	Alarm high limit alarm clear 1
8	AL_HIGH_LMT_CLR_2	Alarm high limit alarm clear 2
9	AL_LOW_LMT_ALM_1	Alarm low limit alarm 1
10	AL_LOW_LMT_ALM_2	Alarm low limit alarm 2
11	AL_HIGH_LMT_ALM_1	Alarm high limit alarm 1
12	AL_HIGH_LMT_ALM_2	Alarm high limit alarm 2
13	AL_FIR_ALM	Fire alarm condition
14	AL_FIR_PRE_ALM	Fire pre-alarm condition
15	AL_FIR_TRBL	Fire-related trouble (fault) condition

16	AL_FIR_SUPV	Fire-related supervisory condition (e.g., sprinkler pressure)
17	AL_FIR_TEST_ALM	Fire-related test-mode alarm condition
18	AL_FIR_TEST_PRE_ALM	Fire-related test-mode pre-alarm condition
19	AL_FIR_ENVCOMP_MAX	Fire-related maximum environmental compensation level reached
20	AL_FIR_MONITOR_COND	Fire-related abnormal input condition
21	AL_FIR_MAINT_ALERT	Fire-related maintenance alert
30	AL_FATAL_ERROR	Fatal application error
31	AL_ERROR	Other error condition
32	AL_WARNING	Other warning condition

boolean_t (41)

Boolean Type

Defined in: snvt_bln.h

Value	Identifier	Notes
-1 (0xFF)	BOOL_NUL	Invalid Value
0	BOOL_FALSE	False
1	BOOL_TRUE	True

calendar_type_t (29)

Calender Type

Defined in: snvt_cal.h

Value	Identifier	Notes
-1 (0xFF)	CAL_NUL	Invalid Value
0	CAL_GREG	Gregorian calendar
1	CAL_JUL	Julian calendar
2	CAL_MEU	Calendar Method European/US "MEU"

cam_act_t (38)

Camera Action

Defined in: snvt_cma.h

Value	Identifier	Notes
-1 (0xFF)	CMA_NUL	Invalid action call response.

0	CMA_SAVE	Save the values defined by the function.
1	CMA_CALL	Preposition tour tables.
2	CMA_READ	Absolute positions.

cam_func_t (37)

Camera Function

Defined in snvt_cmf.h

Value	Identifier	Notes
-1 (0xFF)	CMF_NUL	Invalid function call response.
0	CMF_REL	Relative positions, prepositions.
1	CMF_TOUR	Preposition tour tables.
2	CMF_ABS	Absolute positions.

chiller_t (25)

Chiller Run Mode

Defined in: snvt_chl.h

Value	Identifier	Notes
-1 (0xFF)	CHLR_NULL	Invalid Value
0	CHLR_OFF	Chiller off
1	CHLR_START	Chiller in start mode
2	CHLR_RUN	Chiller in run mode
3	CHLR_PRESHUTDN	Chiller in pre shutdown mode
4	CHLR_SERVICE	Chiller in service mode

config_source_t (4)

Configuration Source

Defined in: snvt_cfg.h

Value	Identifier	Notes
-1 (0xFF)	CFG_NUL	Invalid Value

0	CFG_LOCAL	Device will use self-installation functions to set its own network image
1	CFG_EXTERNAL	Device's network image will be set by an outside source

control_resp_t (32)

Control Response Type

Defined in: snvt_crs.h

Value	Identifier	Notes
-1 (0xFF)	CTRLR_NUL	Invalid value
0	CTRLR_NO	Number of current controller.
1	CTRLR_PEND	Request pending due to control query to current operator
2	CTRLR_REL	Current control released.
3	CTRLR_QUERY	Query to current controller.
4	CTRLR_RES	Controllable device has been reset.
5	CTRLR_ERR	Error in control.

currency_t (9)

Currency

Defined in: snvt_cu.h

Value	Identifier	Notes
-1 (0xFF)	CU_NUL	Invalid Value
0	CU_ARGENTINA_PESO	Argentine Peso
1	CU_AUSTRALIA_DOLLAR	Australian Dollar
2	CU_AUSTRIA_SCHILLING	Austrian Schilling
3	CU_BAHRAIN_DINAR	Bahraini Dinar
4	CU_BELGIUM_FRANC	Belgian Franc
5	CU_BRAZIL_CRUZEIRO_REAL	Brazilian Cruzeiro Real
6	CU_BRITAIN_POUND	British Pound
7	CU_CANADA_DOLLAR	Canadian Dollar
8	CU_CZECH_KORUNA	Czechoslovakian Koruna
9	CU_CHILE_PESO	Chilean Peso
10	CU_CHINA_RENMINBI	Chinese Renminbi Yuan
11	CU_COLOMBIA_PESO	Colombian Peso
12	CU_DENMARK_KRONE	Danish Krone
13	CU_ECUADOR_SUCRE	Ecuadorian Sucre
14	CU_EUROPEAN_CURRENCY_UNIT	European Euro
15	CU_FINLAND_MARKKA	Finnish Markka
16	CU_FRANCE_FRANC	French Franc
17	CU_GERMANY_MARK	German Mark
18	CU_GREECE_DRACHMA	Greek Drachma

19	CU_HONG_KONG_DOLLAR	Hong Kong Dollar
20	CU_HUNGARY_FORINT	Hungarian Forint
21	CU_INDIA_RUPEE	Indian Rupee
22	CU_INDONESIA_RUPIAH	Indonesian Rupiah
23	CU_IRELAND_PUNT	Irish Punt
24	CU_ISRAEL_SHEKEL	Israeli Shekel
25	CU_ITALY_LIRA	Italian Lira
26	CU_JAPAN_YEN	Japanese Yen
27	CU_JORDAN_DINAR	Jordanian Dinar
28	CU_KUWAIT_DINAR	Kuwaiti Dinar
29	CU_LEBANON_POUND	Lebanese Pound
30	CU_MALAYSIA_RINGGIT	Malaysian Ringgit
31	CU_MALTA_LIRA	Maltese Lira
32	CU_MEXICO_PESO	Mexican New Peso
33	CU_NETHERLANDS_GUILDER	Netherlands Guilder
34	CU_NEW_ZEALAND_DOLLAR	New Zealand Dollar
35	CU_NORWAY_KRONE	Norwegian Krone
36	CU_PAKISTAN_RUPEE	Pakistani Rupee
37	CU_PERU_NEW_SOL	Peruvian New Sol
38	CU_PHILIPPINES_PESO	Philippine Peso
39	CU_POLAND_ZLOTY	Polish Zloty
40	CU_PORTUGAL_ESCUDO	Portuguese Escudo
41	CU_SAUDI_ARABIA_RIYAL	Saudi Arabian Riyal
42	CU_SINGAPORE_DOLLAR	Singaporean Dollar
43	CU_SLOVAK_KORUNA	Slavic Koruna
44	CU_SOUTH_AFRICA_RAND	South African Rand
45	CU_SOUTH_KOREA_WON	South Korean Won
46	CU_SPAIN_PESETA	Spanish Peseta
47	CU_SPECIAL_DRAWING_RIGHTS	international governmental exchange
48	CU_SWEDEN_KRONA	Swedish Krona
49	CU_SWITZERLAND_FRANC	Swiss Franc
50	CU_TAIWAN_DOLLAR	Taiwanese Dollar
51	CU_THAILAND_BAHT	Thai Baht
52	CU_TURKEY_LIRA	Turkish Lira
53	CU_UNITED_ARAB_DIRHAM	United Arab Emirates Dirham
54	CU_UNITED_STATES_DOLLAR	United States Dollar
55	CU_URUGUAY_NEW_PESO	Uruguayan New Peso
56	CU_VENEZUELA_BOLIVAR	Venezuelan Bolivar

days_of_month_t (54)

Days of Month

Defined in: snvt_dm.h

Value	Identifier	Notes
-1 (0xFF)	DM_NUL	Invalid value
0	DM_EVERY_DAY	Every day of month
1	DM_DAY_1	First day of month
…	…	DM_DAY_2 through DM_DAY_30
31	DM_DAY_31	Thirty-first day of month
32	DM_LAST_DAY_OF_MONTH	Last day of month
33	DM_LAST_SECOND_DAY	Second to last day of month
34	DM_LAST_THIRD_DAY	Third to last day of month
35	DM_LAST_4TH_DAY	Fourth to last day of month
…	…	DM_LAST_4TH_DAY through DM_LAST_29TH_DAY
61	DM_LAST_30TH_DAY	Thirtieth to last day of month
62	DM_FIRST_SUN	First Sunday of month
63	DM_FIRST_MON	First Monday of month
64	DM_FIRST_TUE	First Tuesday of month
65	DM_FIRST_WED	First Wednesday of month
66	DM_FIRST_THU	First Thursday of month
67	DM_FIRST_FRI	First Friday of month
68	DM_FIRST_SAT	First Saturday of month
69	DM_SECOND_SUN	Second Sunday of month
…	…	DM_SECOND_MON through DM_SECOND_FRI
75	DM_SECOND_SAT	Second Saturday of month
…	…	DM_THIRD_SUN through DM_FOURTH_SAT
90	DM_FIFTH_SUN	Fifth Sunday of month
…	…	DM_FIFTH_MON through DM_FIFTH_FRI
96	DM_FIFTH_SAT	Fifth Saturday of month
97	DM_LAST_SUN	Last Sunday of month
…	…	DM_LAST_MON through DM_LAST_FRI
103	DM_LAST_SAT	Last Saturday of month
104	DM_EVERY_SUN	Every Sunday of the month
…	…	DM_EVERY_MON through DM_EVERY_FRI
110	DM_EVERY_SAT	Every Saturday of the month
111	DM_EVERY_SECOND_DAY	Every second day (i.e. every other day) of the date interval
112	DM_EVERY_THIRD_DAY	Every third day of the date interval
113	DM_EVERY_FOURTH_DAY	Every fourth day of the date interval
114	DM_EVERY_FIFTH_DAY	Every fifth day of the date interval
115	DM_EVERY_SIXTH_DAY	Every sixth day of the date interval
116	DM_EVERY_WEEKDAY	Every weekday (Monday – Friday)
117	DM_EVERY_WEEKEND_DAY	Every weekend day (Saturday – Sunday)

days_of_week_t (1)

Day of Week

Defined in: snvt_dt.h

Value	Identifier	Notes
-1 (0xFF)	DAY_NUL	Invalid Value
0	DAY_SUN	Sunday
1	DAY_MON	Monday
2	DAY_TUE	Tuesday
3	DAY_WED	Wednesday
4	DAY_THU	Thursday
5	DAY_FRI	Friday
6	DAY_SAT	Saturday

defrost_mode_t (22)

Defrost Mode

Defined in: snvt_dfm.h

Value	Identifier	Notes
-1 (0xFF)	DFM_MODE_NUL	Invalid Value
0	DFM_MODE_AMBIENT	No forced heating required
1	DFM_MODE_FORCED	Start-up after defrost ignored
2	DFM_MODE_SYNC	Synchronized

defrost_state_t (24)

Defrost State

Defined in: snvt_dfs.h

Value	Identifier	Notes
-1 (0xFF)	DFS_NUL	Invalid Value
0	DFS_STANDBY	Defrost in standby
1	DFS_PUMPDOWN	Defrost in pump-down mode
2	DFS_DEFROST	In defrost mode
3	DFS_DRAINDOWN	Defrost in drain-down
4	DFS_INJECT_DLY	Defrost in injection delay

defrost_term_t (23)

Defrost Termination

Defined in: snvt_dft.h

Value	Identifier	Notes
-1 (0xFF)	DFT_NUL	Invalid Value
0	DFT_TERM_TEMP	Terminate on temperature
1	DFT_TERM_TIME	Terminate on time
2	DFT_TERM_FIRST	Terminate on first occurring
3	DFT_TERM_LAST	Terminate on last occurring
4	DFT_TERM_SENSOR	Terminate on sensor
5	DFT_TERM_DISCHARGE	Terminate on discharge
6	DFT_TERM_RETURN	Terminate on return
7	DFT_TERM_SW_OPEN	Terminate on “Switch Open”
8	DFT_TERM_SW_CLOSE	Terminate on “Switch Closed”
100	DFT_TERM_MANUF	Manufacturer-Defined termination state

device_c_mode_t (44)

Device Characteristic Mode

Defined in: snvt_dcm.h

Value	Identifier	Notes
-1 (0xFF)	DCM_NUL	Invalid Value
0	DCM_SPEED_CONST	
1	DCM_PRESS_CONST	
2	DCM_PRESS_COMP	
3	DCM_FLOW_CONST	
4	DCM_FLOW_COMP	
5	DCM_TEMP_CONST	
6	DCM_TEMP_COMP	
7	DCM_PRESS_AUTO	
20	DCM_QUICK_OPEN	Valve works with Quick-Open flow characteristic
21	DCM_LINEAR	Valve works with Linear flow characteristic
22	DCM_EQUAL_PERCENT	Valve works with Equal Percent flow characteristic
23	DCM_QUADRATIC	Valve works with Quadratic flow characteristic
24	DCM_FREE_DEFINED	Valve works with free defined flow characteristic
27	DCM_2WAY_VALVE	
28	DCM_MIXING_VALVE	
29	DCM_DIVERING_VALVE	

device_select_t (50)

Device Select

Defined in: snvt_ds.h

Value	Identifier	Notes
-1 (0xFF)	DV_NUL	Invalid value
0	DV_PUMP_CTRL	Use union for SFPTpumpController values
1	DV_VALVE_POS	Use union for SFPTvalvePositioner values

discrete_levels_t (2)

Discrete Level

Defined in: snvt_lev.h

Value	Identifier	Notes		
		2-state device	**3-state device**	**4-state device**
-1 (0xFF)	ST_NUL	Invalid Value		
0	ST_OFF	off	off	off
1	ST_LOW	on	low	low
2	ST_MED	on	high	medium
3	ST_HIGH	on	high	high
4	ST_ON	on	high	high

emerg_t (13)

HVAC Emergency Mode

Defined in: snvt_em.h

Value	Identifier	Notes
-1 (0xFF)	EMERG_NUL	Invalid Value

0	EMERG_NORMAL	No emergency mode
1	EMERG_PRESSURIZE	Emergency pressurize mode
2	EMERG_DEPRESSURIZE	Emergency depressurize mode
3	EMERG_PURGE	Emergency purge mode
4	EMERG_SHUTDOWN	Emergency shutdown mode
5	EMERG_FIRE	Emergency fire mode

ent_cmd_t (48)

Entry State

Defined in: snvt_ens.h

Value	Identifier	Notes
-1 (0xFF)	ES_NUL	Invalid Value
0	ES_UNDEFINED	State is not yet defined
1	ES_OPEN_PULS	Open the device and close it when back in normal position
2	ES_OPEN	Open the device if not locked
3	ES_CLOSE	Close the device
4	ES_STOP	Stop the device
5	ES_STOP_RESUME	Continue after stop command
6	ES_ENTRY_REQ	Entry request, access in to the area
7	ES_EXIT_REQ	Exit request, access out from the area
8	ES_KEY_REQ	Key request, open the device if not in EM_BLOCKED or EM_MANUAL mode
9	ES_SAFETY_EXT_REQ	Safety request, the device will go to a pre defined safety position/mode
10	ES_EMERGENCY_REQ	Emergency request, the device will go to an pre defined emergency position/mode
11	ES_UPDATE_STATE	Update the current state and mode
12	ES_SAF_EXT_RESUME	Resume after Safety function
13	ES_EMERG_RESUME	Resume after Emergency function

ent_opmode_cmd_t (47)

Entry Operation Mode

Defined in: snvt_eno.h

Value	Identifier	Notes
-1 (0xFF)	EM_NUL	Invalid Value
0	EM_UNDEFINED	Operation mode is not defined
1	EM_AUTO	Operation mode is AUTOMATIC
2	EM_AUTO_RED	Operation mode is AUTOMATIC with reduced

		width
3	EM_CLOSE_LOCK	Operation mode is CLOSE AND LOCK
4	EM_CLOSE_UNLOCK	Operation mode is CLOSE AND UNLOCK
5	EM_EXIT_ONLY	Operation mode is EXIT ONLY
6	EM_OPEN	Operation mode is OPEN
7	EM_OPEN_ONCE	Operation mode is OPEN AND CLOSE ONCE
8	EM_MANUAL	Operation mode is MANUAL
9	EM_FIRE	Operation mode is FIRE
10	EM_EVAC	Operation mode is EVACUATION
11	EM_WEATHER	Operation mode is WEATHER MODE
12	EM_DAY_LOCKING	Operation mode is DAY_LOCKING, locking with reduced level of security
13	EM_NIGHT_LOCKING	Operation mode is NIGHT_LOCKING, locking with maximum level of security
14	EM_BLOCKED	Operation mode is BLOCKED, no operations is allowed
15	EM_SERVICE	Operation mode is SERVICE
16	EM_ENTRY_ONLY	Operation mode is ENTRY_ONLY

evap_t (20)

Evaporation State

Defined in: snvt_evp.h

Value	Identifier	Notes
-1 (0xFF)	EVAP _NUL	Invalid Value
0	EVAP_NO_COOLING	Object not performing cooling (off cycle or disabled)
1	EVAP_COOLING	Object currently cooling
2	EVAP_EMERG_COOLING	Object performing emergency cooling

event_mode_type_t (48)

Event Mode

Defined in: snvt_emt.h

Value	Identifier	Notes
-1 (0xFF)	EMT_NUL	Invalid Value

0	EMT_END_OF_LIST	End of list indicator
1	EMT_SCENE	Scene indicator
2	EMT_MODE	Mode indicator
3	EMT_LIGHTS_ON	
4	EMT_LIGHTS_OFF	

ex_control_t (42)

Control Status

Defined in: snvt_exc.h

Value	Identifier	Notes
-1 (0xFF)	EX_CONTROL_NUL	The control status of the item is unknown
0	EX_CONTROL_NONE	Nothing has control of the item.
1	EX_CONTROL_OTHER	Some unidentified entity has control of the item.
2	EX_CONTROL_THIS_ADDR	A device has control of the item. The network address of this device is specified in the control_device_addr structure.

fan_operation_t (52)

Fan Operation

Defined in: snvt_hvf.h

Value	Identifier	Notes
-1 (0xFF)	HVF_NUL	Invalid Value
0	HVF_CONTINUOUS	Fan runs continuously
1	HVF_CYCLE	Fan cycles with heating and cooling
2	HVF_CON_CYCLE	Continuous in occupied, cycles in occupied-standby
3	HVF_CYCLE_HEAT	Fan cycles with heating only
4	HVF_CYCLE_COOL	Fan cycles with cooling only

file_request_t (5)

Request

Defined in: snvt_fr.h

Value	Identifier	Notes
-1 (0xFF)	FR_NUL	Invalid Value
0	FR_OPEN_TO_SEND	Sequential access read
1	FR_OPEN_TO_RECEIVE	Sequential access write

2	FR_CLOSE_FILE	Close and save file
3	FR_CLOSE_DELETE_FILE	Close and delete file
4	FR_DIRECTORY_LOOKUP	Retrieve directory entry
5	FR_OPEN_TO_SEND_RA	Random access read
6	FR_OPEN_TO_RECEIVE_RA	Random access write

file_status_t (6)

Status

Defined in: snvt_fs.h

Value	Identifier	Notes
-1 (0xFF)	FS_NUL	Invalid Value
0	FS_XFER_OK	File transfer successful
1	FS_LOOKUP_OK	Directory lookup successful
2	FS_OPEN_FAIL	Error on opening file
3	FS_LOOKUP_ERR	Error on directory lookup
4	FS_XFER_UNDERWAY	File transfer in progress
5	FS_IO_ERR	Error on reading/writing file
6	FS_TIMEOUT_ERR	File transfer timed out
7	FS_WINDOW_ERR	Window sequence error
8	FS_AUTH_ERR	Authentication failure
9	FS_ACCESS_UNAVAIL	Access mode not supported
10	FS_SEEK_INVALID	Random access beyond EOF
11	FS_SEEK_WAIT	

fire_indicator_t (28)

Fire Indicator

Defined in: snvt_fn.h

Value	Identifier	Notes
-1 (0xFF)	FN_NUL	Invalid Value
0	FN_UNDEFINED	Undefined indicator
1	FN_STROBE_U	The indicator is un-synchronized
2	FN_STROBE_S	The indicator is synchronized
3	FN_HORN	The indicator is a DC input, pre coded Horn
4	FN_CHIME	The indicator is a DC input, pre coded Chime
5	FN_BELL	The indicator is a DC input
6	FN_SOUNDER	The indicator is powered from the device
7	FN_SPEAKER	The indicator is an AC input for the speaker
8	FN_UNIVERSAL	General purpose indicator

fire_initiator_t (27)

Fire Initiator

Defined in: snvt_fi.h

Value	Identifier	Notes
-1 (0xFF)	FI_NUL	Invalid Value
0	FI_UNDEFINED	Initiator is undefined
1	FI_THERMAL_FIXED	Initiator is thermal fixed (heat)
2	FI_SMOKE_ION	Initiator is smoke – ion
3	FI_MULTI_ION_THERMAL	Initiator is multi-ion and thermal
4	FI_SMOKE_PHOTO	Initiator is smoke and photo
5	FI_MULTI_PHOTO_THERMAL	Initiator is multi-photo and thermal
6	FI_MULTI_PHOTO_ION	Initiator is multi-photo and ion
7	FI_MULTI_PHOTO_ION_THERMAL	Initiator is multi-photo, ion and thermal
8	FI_THERMAL_ROR	Initiator is thermal fixed and Rate of Rise
9	FI_MULTI_THERMAL_ROR	Initiator is multi-thermal and Rate of Rise
10	FI_MANUAL_PULL	Initiator is manual pull
11	FI_WATER_FLOW	Initiator is water flow
12	FI_WATER_FLOW_TAMPER	Initiator is water flow and tamper
13	FI_STATUS_ONLY	Initiator is status only
14	FI_MANUAL_CALL	Initiator is a manual call point
15	FI_FIREMAN_CALL	Initiator is a fireman call point
16	FI_UNIVERSAL	General purpose initiator definition

fire_test_t (26)

Fire Test Request

Defined as: snvt_ft.h

Value	Identifier	Notes
-1(0xFF)	FT_NUL	Invalid Value
0	FT_NORMAL	Return object to normal status
1	FT_RESET	Perform a RESET function (for smoke detectors)
2	FT_TEST	Go into TEST mode
3	FT_NOTEST	Exit TEST mode

flow_direction_t (49)

Flow Direction

Defined in: snvt_fd.h

Value	Identifier	Notes

-1 (0xFF)	FD_NUL	Invalid Value
0	FD_NONE	No flow/movement allowed
1	FD_OUT	Exit/out/away direction only
2	FD_IN	Entry/in/toward direction only
3	FD_ANY	No restriction on flow/movement

gfci_status_t (39)

GFCI Status Type

Defined in: snvt_gfi.h

Value	Identifier	Notes
-1 (0xFF)	GFCI_NUL	Invalid Value
0	GFCI_UNKNOWN	Unknown response
1	GFCI_NORMAL	Normal GFCI operating condition
2	GFCI_TRIPPED	A ground-fault has caused the GFCI to interrupt the circuit
3	GFCI_TEST_FAILED	The GFCI failed testing
4	GFCI_TEST_PASSED	The GFCI passed testing
5	GFCI_TEST_NOW	The GFCI needs to be tested

hvac_hvt_t (31)

HVAC Equipment Type

Defined in: snvt_hvt.h

Value	Identifier	Notes
-1 (0xFF)	HVT_NUL	Invalid Value
0	HVT_GENERIC	Generic
1	HVT_FAN_COIL	Fan Coil
2	HVT_VAV	Variable Air Volume Terminal
3	HVT_HEAT_PUMP	Heat Pump
4	HVT_ROOFTOP	Rooftop Unit
5	HVT_UNIT_VENT	Unit Ventilator
6	HVT_CHILL_CEIL	Chilled Ceiling
7	HVT_RADIATOR	Radiator
8	HVT_AHU	Air Handling Unit
9	HVT_SELF_CONT	Self-Contained Unit

hvac_overid_t (16)

HVAC Override State

Defined in: snvt_hvo.h

Value	Identifier	Notes
-1 (0xFF)	HVO_NUL	Invalid Value
0	HVO_OFF	Not overridden
	// the next 16 override values apply to all devices or groups	
1	HVO_POSITION	
2	HVO_FLOW_VALUE	Override flow in liters/sec - use flow field
3	HVO_FLOW_PERCENT	Override flow percentage - use percent field
4	HVO_OPEN	Override to position = 100%
5	HVO_CLOSE	Override to position = 0%
6	HVO_MINIMUM	Override to configured minimum
7	HVO_MAXIMUM	Override to configured maximum
8	HVO_UNUSED8	
9	HVO_UNUSED9	
10	HVO_UNUSED10	
11	HVO_UNUSED11	
12	HVO_UNUSED12	
13	HVO_UNUSED13	
14	HVO_UNUSED14	
15	HVO_UNUSED15	
16	HVO_UNUSED16	
	//the next 16 override values apply to the first device or group	
17	HVO_POSITION_1	
18	HVO_FLOW_VALUE_1	Override flow in liters/sec - use flow field
19	HVO_FLOW_PERCENT_1	Override flow percentage - use percent field
20	HVO_OPEN_1	Override to position = 100%
21	HVO_CLOSE_1	Override to position = 0%
22	HVO_MINIMUM_1	Override to configured minimum
23	HVO_MAXIMUM_1	Override to configured maximum
24	HVO_UNUSED24	
25	HVO_UNUSED25	
26	HVO_UNUSED26	
27	HVO_UNUSED27	
28	HVO_UNUSED28	
29	HVO_UNUSED29	
30	HVO_UNUSED30	
31	HVO_UNUSED31	
32	HVO_UNUSED32	
	// the next 16 override values apply to the second device or group	
33	HVO_POSITION_2	
34	HVO_FLOW_VALUE_2	Override flow in liters/sec - use flow field
35	HVO_FLOW_PERCENT_2	Override flow percentage - use percent field
36	HVO_OPEN_2	Override to position = 100%
37	HVO_CLOSE_2	Override to position = 0%
38	HVO_MINIMUM_2	Override to configured minimum
39	HVO_MAXIMUM_2	Override to configured maximum
40	HVO_UNUSED40	
41	HVO_UNUSED41	
42	HVO_UNUSED42	
43	HVO_UNUSED43	
44	HVO_UNUSED44	
45	HVO_UNUSED45	
46	HVO_UNUSED46	
47	HVO_UNUSED47	

48	HVO_UNUSED48	

hvac_t (14)

HVAC Mode and HVAC Status

Defined in: snvt_hv.h

Value	Identifier	Notes
-1 (0xFF)	HVAC_NUL	Invalid value
0	HVAC_AUTO	Controller automatically changes between application modes
1	HVAC_HEAT	Heating only
2	HVAC_MRNG_WRMUP	Application-specific morning warm-up
3	HVAC_COOL	Cooling only
4	HVAC_NIGHT_PURGE	Application-specific night purge
5	HVAC_PRE_COOL	Application-specific pre-cool
6	HVAC_OFF	Controller not controlling outputs
7	HVAC_TEST	Equipment being tested
8	HVAC_EMERG_HEAT	Emergency heat mode (heat pump)
9	HVAC_FAN_ONLY	Air not conditioned, fan turned on
10	HVAC_FREE_COOL	Cooling with compressor not running
11	HVAC_ICE	Ice-making mode
12	HVAC_MAX_HEAT	Maximum heating mode
13	HVAC_ECONOMY	Economic Heat/Cool mode
14	HVAC_DEHUMID	Dehumidification mode
15	HVAC_CALIBRATE	Calibration mode
16	HVAC_EMERG_COOL	Emergency cool mode
17	HVAC_EMERG_STEAM	Emergency steam mode

learn_mode_t (11)

Learn Mode

Defined in: snvt_ln.h

Value	Identifier	Notes
-1(0xFF)	LN_NUL	Invalid Value

0	LN_RECALL	
1	LN_LEARN_CURRENT	
2	LN_LEARN_VALUE	
3	LN_REPORT_VALUE	

master_slave_t (51)

Flow Direction

Defined in: snvt_sl.h

Value	Identifier	Notes
-1 (0xFF)	MSC_NUL	Invalid Value
0	MSC_UNKNOWN	Undefined or unused
1	MSC_SLAVE	Slave control
2	MSC_MASTER	Master control

months_t (55)

Months

Defined in: snvt_mn.h

Value	Identifier	Notes
-1 (0xFF)	MN_NUL	Invalid value
0	MN_EVERY_MONTH	Every month
1	MN_JAN	January
2	MN_FEB	February
3	MN_MAR	March
4	MN_APR	April
5	MN_MAY	May
6	MN_JUN	June
7	MN_JUL	July
8	MN_AUG	August
9	MN_SEP	September
10	MN_OCT	October
11	MN_NOV	November
12	MN_DEC	December
13	MN_EVERY_2_MONTH	Every other month
14	MN_QUARTERLY	Every third month
15	MN_EVERY_4_MONTH	Every fourth month
16	MN_EVERY_5_MONTH	Every fifth month
17	MN_EVERY_6_MONTH	Every sixth month
18	MN_EVERY_7_MONTH	Every seventh month
19	MN_EVERY_8_MONTH	Every eighth month
20	MN_EVERY_9_MONTH	Every ninth month
21	MN_EVERY_10_MONTH	Every tenth month
22	MN_EVERY_11_MONTH	Every eleventh month

motor_state_t (40)

Motor State

Defined in: snvt_mot.h

Value	Identifier	Notes
-1 (0xFF)	MOTOR_NUL	The state of the motor is unknown (invalid value)

0	MOTOR_STOPPED	The motor is not running.
1	MOTOR_STARTING	The motor is performing its start-up sequence.
2	MOTOR_ACCELERATIN G	The motor is running. Speed is increasing.
3	MOTOR_AT_STANDBY	The motor is running in its standby mode.
4	MOTOR_AT_NORMAL	The motor is running in its normal operational mode.
5	MOTOR_AT_REFERENC E	The motor is running at its reference speed.
6	MOTOR_DECELERATIN G	The motor is running. Speed is decreasing.
7	MOTOR_STOPPING	The motor is running, beginning its shutdown sequence.

nv_type_category_t (46)

Network Variable Type Category

Defined in: snvt_nvt.h

Value	Identifier	Notes
-1 (0xFF)	NVT_CAT_NUL	Invalid Value
1	NVT_CAT_SIGNED_CHAR	8-bit signed character
2	NVT_CAT_UNSIGNED_CHAR	8-bit unsigned character
3	NVT_CAT_SIGNED_SHORT	8-bit signed integer
4	NVT_CAT_UNSIGNED_SHORT	8-bit unsigned integer
5	NVT_CAT_SIGNED_LONG	16-bit signed integer
6	NVT_CAT_UNSIGNED_LONG	16-bit unsigned integer
7	NVT_CAT_ENUM	8-bit enumeration
8	NVT_CAT_ARRAY	Array
9	NVT_CAT_STRUCT	Structure
10	NVT_CAT_UNION	Union
11	NVT_CAT_BITFIELD	Bitfield
12	NVT_CAT_FLOAT	32-bit IEEE 754 floating-point value
13	NVT_CAT_SIGNED_QUAD	32-bit signed integer
14	NVT_CAT_REFERENCE	Reference type

object_request_t (10)

Object Request

Defined in: snvt_rq.h

Value	Identifier	Notes
-1 (0xFF)	RQ_NUL	Invalid Value
0	RQ_NORMAL	Enable object and remove override
1	RQ_DISABLED	Disable object
2	RQ_UPDATE_STATUS	Report object status
3	RQ_SELF_TEST	Perform object self-test
4	RQ_UPDATE_ALARM	Update alarm status
5	RQ_REPORT_MASK	Report status bit mask
6	RQ_OVERRIDE	Override object
7	RQ_ENABLE	Enable object
8	RQ_RMV_OVERRIDE	Remove object override
9	RQ_CLEAR_STATUS	Clear object status
10	RQ_CLEAR_ALARM	Clear object alarm
11	RQ_ALARM_NOTIFY_ENABLED	Enable alarm notification
12	RQ_ALARM_NOTIFY_DISABLED	Disable alarm notification
13	RQ_MANUAL_CTRL	Enable object for manual control
14	RQ_REMOTE_CTRL	Enable object for remote control
15	RQ_PROGRAM	Enable programming of special configuration properties
16	RQ_CLEAR_RESET	Clear reset-complete flag (reset_complete)
17	RQ_RESET	Execute reset-sequence of object

occup_t (15)

Occupancy

Defined in: snvt_oc.h

Value	Identifier	Notes
-1 (0xFF)	OC_NUL	Invalid Value
0	OC_OCCUPIED	Area is occupied
1	OC_UNOCCUPIED	Area is unoccupied
2	OC_BYPASS	Area is temporarily occupied for the bypass period
3	OC_STANDBY	Area is temporarily unoccupied

override_t (12)

Override Code

Defined in: snvt_ov.h

Value	Identifier	Notes
-1 (0xFF)	OV_NUL	Invalid Value
0	OV_RETAIN	Retain current level
1	OV_SPECIFIED	Go to specified level
2	OV_DEFAULT	Go to default level

pan_dir_t (33)

Pan Direction

Defined in: snvt_pan.h

Value	Identifier	Notes
-1 (0xFF)	PAN_NUL	Invalid Value
0	PAN_STOP	Stop
1	PAN_RIGHT	Right
2	PAN_LEFT	Left

priority_level_t (8)

Priority Level

Defined in: snvt_pr.h

Value	Identifier	Notes
-1 (0xFF)	PR_NUL	Invalid Value
0	PR_LEVEL_0	Lowest alarm priority level
1	PR_LEVEL_1	
2	PR_LEVEL_2	
3	PR_LEVEL_3	Highest alarm priority level
LONMARK Fire products should use the priority fields listed below		
4	PR_1	Life Safety Fire Alarms (BACnet Priority 2)
5	PR_2	Property Safety Fire Alarms (BACnet Priority 3)
6	PR_3	Fire Supervisory Alarm (BACnet Priority 4)
7	PR_4	Fire Trouble/Fault (Display) (BACnet Priority 5)
8	PR_6	Fire Pre-Alarm, HVAC Critical Equipment Alarm (BACnet Priority 6)
9	PR_8	HVAC Alarms (BACnet Priority 8)
10	PR_10	HVAC Critical Equipment RTN, Fire RTN (Display) (BACnet Priority 10)
11	PR_16	HVAC RTN (lowest priority) (BACnet Priority 16)

privacyzone_t (36)

Privacy Zone Action Type

Defined in: snvt_pz.h

Value	Identifier	Notes
-1 (0xFF)	PZ_NUL	Invalid value
0	PZ_DISABLE	Disable privacy zone warning
1	PZ_ENABLE	Enable privacy zone warning
2	PZ_UPPER_LEFT	Set upper left corner
3	PZ_LOWER_RIGHT	Set lower right corner
4	PZ_ENTER	Privacy zone enter warning
5	PZ_EXIT	Privacy zone exit message

reg_val_unit_t (30)

Unit Code

Defined in: snvt_rvu.h

Value	Identifier	Notes
-1 (0xFF)	RVU_NUL	invalid unit of measure (INVALID)
0	RVU_NONE	no units specified ( )
1	RVU_W	Watts (W)
2	RVU_KW	kiloWatts (kW)
3	RVU_MW	megaWatts (MW)
4	RVU_GW	gigaWatts (GW)
5	RVU_VAR	Volt-Amperes reactive (var)
6	RVU_KVAR	kilo-Volt-Amperes reactive (kvar)
7	RVU_MVAR	mega-Volt-Amperes reactive (Mvar)
8	RVU_GVAR	giga-Volt-Amperes reactive (Gvar)
9	RVU_WH	Watt-hour (Wh)
10	RVU_KWH	kiloWatt-hour (kWh)
11	RVU_MWH	megaWatt-hour (MWh)
12	RVU_GWH	gigaWatt-hour (GWh)
13	RVU_VARH	Volt-Amperes reactive -hour (varh)
14	RVU_KVARH	kilo-Volt-Amperes reactive -hour (kvarh)
15	RVU_MVARH	mega-Volt-Amperes reactive -hour (Mvarh)
16	RVU_GVARH	giga-Volt-Amperes reactive -hour (Gvarh)
17	RVU_V	Volts (V)
18	RVU_A	Amps (A)
19	RVU_COSF	(cosf)
20	RVU_M3	cubic meters (m^3)(cu.m)
21	RVU_L	liters (l)
22	RVU_ML	milliliters (ml)
23	RVU_USGAL	U.S. Gallons (USG)
24	RVU_GJ	giga-Joules (GJ)
25	RVU_MJ	mega-Joules (MJ)
26	RVU_MCAL	megacalories (Mcal)
27	RVU_KCAL	kilocalories (kcal) / Calories (Cal)
28	RVU_MBTU	mega-British thermal units (mBtu)
29	RVU_KBTU	kilo-British thermal units (kBtu)
30	RVU_MJH	mega-Joules per hour (MJ/h)
31	RVU_MLS	milliliters per second (ml/s)
32	RVU_LS	liters per second (l/s)
33	RVU_M3S	cubic-meters per second (m^3/s) (cu.m/s)

34	RVU_C	(C)
35	RVU_LH	liters per hour (l/h)
36	RVU_VA	Volt-Amperes (VA)
37	RVU_KVA	kiloVolt-Amperes (kVA)
38	RVU_MVA	megaVolt-Amperes (MVA)
39	RVU_GVA	gigaVolt-Amperes (GVA)
40	RVU_VAH	Volt-Ampere hours (VAh)
41	RVU_KVAH	kiloVolt-Ampere hours (kVAh)
42	RVU_MVAH	megaVolt-Ampere hours (MVAh)
43	RVU_GVAH	giga-Volt-Ampere hours (GVAh)

scene_config_t (18)

Scene Configuration Function

Defined in: snvt_scf.h

Value	Identifier	Notes
-1 (0xFF)	SCF_NUL	Invalid Value
0	SCF_SAVE	Overwrite this scene with new data
1	SCF_CLEAR	Delete this scene from the list
2	SCF_REPORT	Display this scene's data
3	SCF_SIZE	Report the number of programmed scenes
4	SCF_FREE	Report the number of free scene storage spaces

scene_t (17)

Scene Control

Defined in: snvt_sc.h

Value	Identifier	Notes
-1 (0xFF)	SC_NUL	Invalid Value
0	SC_RECALL	Recall value for specified scene
1	SC_LEARN	Learn current value for specified scene
2	SC_DISPLAY	Display current settings locally
3	SC_GROUP_OFF	Network group OFF
4	SC_GROUP_ON	Network group ON
5	SC_STATUS_OFF	Network group status = OFF
6	SC_STATUS_ON	Network group status = ON
7	SC_STATUS_MIXED	Network group status = indeterminate
8	SC_GROUP_STATUS	Query for current group status
9	SC_FLICK	Do a flick warn off routine
10	SC_TIMEOUT	Do 'ON' with timeout
11	SC_TIMEOUT_FLICK	Do 'ON' with timeout with flick warn
12	SC_DELAYOFF	Do 'OFF' after timed period (egress)
13	SC_DELAYOFF_FLICK	Do 'OFF' after timed period with flick warn
14	SC_DELAYON	Do 'ON' after timed period

15	SC_ENABLE_GROUP	Enable the group for network commands
16	SC_DISABLE_GROUP	Disable the group for network commands
17	SC_CLEANON	Cleaning mode ‘ON’
18	SC_CLEANOFF	Cleaning mode ‘OFF’
19	SC_WINK	Toggle state for group, then return to original state
20	SC_RESET	Reset scene to default mode
21	SC_MODE1	reserved for future lighting mode
22	SC_MODE2	reserved for future lighting mode
23	SC_MODE3	reserved for future lighting mode

setting_t (19)

Setting Control Function

Defined in: snvt_set.h

Value	Identifier	Notes
-1 (0xFF)	SET_NUL	Invalid Value
0	SET_OFF	Setting off
1	SET_ON	Setting on
2	SET_DOWN	Decrease setting by specified value
3	SET_UP	Increase setting by specified value
4	SET_STOP	Stop action
5	SET_STATE	Setting on at specified value

telcom_states_t (3)

Telecomm states

Defined in snvt_tel.h

Value	Identifier	Notes
-1(0xFF)	TEL_NUL	Invalid Value
0	TEL_NOTINUSE	“Null State (U0)” not in use
1	TEL_OFFHOOK	“Call Initiated (U1)”
2	TEL_DIALING	“Overlap Sending (U2)”
3	TEL_DIALCOMP	“Outgoing Call Proceeding (U3)”
4	TEL_RINGBACK	“Call Delivered (U4)” hearing ringback
5	TEL_INCOMING	“Call Present (U6)” incoming call has not yet started ringing (only on ISDN line)
7	TEL_RINGING	“Call Received (U7)” incoming call when the user has indicated alerting but has not yet answered
8	TEL_ANSWERED	“Connect Request (U8)” user has answered the call and is waiting to be awarded the call
9	TEL_TALKING	“Active (U10)” two parties are exchanging data
10	TEL_HANGINGUP	“Disconnect Request (U11)” user has hung up
11	TEL_HUNGUPX	“Disconnect Indication (U12)” the other side hung up
12	TEL_HOLD	"Suspend Request (U15)" user has requested the

		network suspend the call
13	TEL_UNHOLD	"Resume Request (U17)" resume a held call (usually go back to TEL_TALKING)
14	TEL_RELEASE	"Release Request (U19)" user has requested the network to release
15	TEL_FULLDUP	"Overlap Receiving (U25)" user has acknowledged the call and is prepared to receive additional information (if any) in overlap mode non-ISDN values
16	TEL_BLOCKED	connection with blocking, (call-waiting disabled)
17	TEL_CWAIT	call-waiting coming in
18	TEL_DESTBUSY	destination busy
19	TEL_NETBUSY	problem, network
20	TEL_ERROR	problem, non-network

therm_mode_t (21)

Thermostat Mode

Defined in: snvt_thm.h

Value	Identifier	Notes
-1 (0xFF)	THERM_NUL	Invalid Value
0	THERM_NO_CONTROL	Thermostat disabled
1	THERM_IN_OUT	Cut in/out control
2	THERM_MODULATING	Modulating control

tilt_dir_t (34)

Tilt Direction

Defined in: snvt_tlt.h

Value	Identifier	Notes
-1 (0xFF)	TILT_NUL	Invalid Value
0	TILT_STOP	Stop
1	TILT_UP	Up
2	TILT_DOWN	Down

unit_temp_t (43)

Pump Body Temp Control Status

Defined in: snvt_tmp.h

Value	Identifier	Notes
-1(0xFF)	TEMP_NUL	The status of the apparatus or unit is unknown, or not applicable (Invalid Value).
0	TEMP_INACTIVE	The temperature-sensing apparatus is present, but not currently operating.
1	TEMP_AT_DESIRED	The unit temperature is within the desired range.
2	TEMP_TOO_HOT	The unit temperature is above the upper limit of the desired range.
3	TEMP_TOO_COLD	The unit temperature is below the lower limit of the desired range.

valve_mode_t (45)

Valve Mode

Defined in: snvt_val.h

Value	Identifier	Notes
-1 (0xFF)	VALVE_NUL	Invalid value
0	VALVE_NORMAL	Valve works as normal valve
1	VALVE_COOLING	Valve works as cooling valve only
2	VALVE_HEATING	Valve works as heating valve only
3	VALVE_EMERGENCY	Valve works in emergency operation
4	VALVE_STROKE_ADP	Valve adapt its stroke and its end positions
5	VALVE_STROKE_SYN	Valve resynchronizes its position
6	VALVE_ERROR	Valve is in error mode
7	VALVE_OVERRIDDEN	Value is overridden

zoom_t (35)

Zoom

Defined in: snvt_zm.h

Value	Identifier	Notes
-1 (0xFF)	ZOOM_NUL	Invalid Value
0	ZOOM_STOP	Stop
1	ZOOM_TELE	Telephoto zoom
2	ZOOM_WIDE	Wide zoom