SYMBOL	FROM	TO	WIRE,NO.	CLASS	CABLE SIZE	CABLE TYPE
E01	EDB	ALERTER PMV	62B14-3,62B17-3	BA	16	600V, 1 core
E02	EDB	APC RACK BOARD	38B61(MA),38G61-1(MA),38G61-2(MA)	BA	14	2000V, 1 core
			89B10(MA),89B11(MA)			
E03	EDB	APC RACK BOARD	22B03-3(MA),38G55-16(MA)	BA	16	600V, 1 core
E04	EDB	ASSISTANT CAB LED LIGHT	70B32-2	BA	16	600V, 1 core
E05	EDB	ASSISTANT CAB WINDSHIELD HEATER	46U03-1,46V03-1	AC	16	2000V, 1 core
E06	EDB	EDB	38G70-2(INTERNAL COMMON CABLE)	BA	16	600V, 1 core
			△1 20B11-0(COM),20B12-0(COM),38G38(COM) △1			
E07	EDB	AUX. LIGHT CONTROLLER	38G21-2,38B60-2	BA	16	600V, 1 core
E08	EDB	AUX. LIGHT CONTROLLER	70B04,38G34-1	BA	△1 ~~14~~ 12	~~2000V~~ 600V, 1 core
E09	EDB	CAB HEATER	44H21-22,44H22-22,32U05	AC	14	2000V, 1 core
			32V05,32W05			
E10	EDB	CAB HEATER	△1 ~~38B43~~ 46B02	BA	16	600V, 1 core
E11	EDB	CAB SOCKET OUTLET	34P05,34N05	AC	12	600V, 1 core
E12	EDB	CCTV DVR	22B03-2,38G55-13,39B10-3	BA	16	600V, 1 core
			39B03-1,38G55-15			
E13	EDB	COMM. CONTROL PANEL(CCP)	39B10-1,39B11,38G55-11	BA	16	600V, 1 core
E14	EDB	DISASTER LIGHT (R1)	72B11-1,72G10-1	BA	16	600V, 1 core
E15	EDB	DOOR ZONE SW (F)	38B32-2,2001-1,2002-1	BA	16	600V, 1 core
			2003-1,2004-1,2051-1			
			2052-1,2053-1,2054-1			
E17	EDB	EMERGENCY PRESSURE SW	38B51,62B07	BA	16	600V, 1 core
E18	EDB	EMV	62B09,62B10	BA	16	600V, 1 core
E19	EDB	END DOOR LIGHT (F)	△1 70B33	BA	16	600V, 1 core
E20	EDB	FBCU	38B70-7,38G70-(~~38G70-2~~ 38G70-3)	BA	16	600V, 1 core
			6101-3,6104-3(38G70-4,38G70-5)			
			38G50-2,38G50-3,38B70-10,38B70-11			
			39B10,39B03,38G55-5,38G55-6			
			6201-5,38G51-3,61B16,61B18			
			61B11,61B12			
E21	EDB	FDP	38B33-1,93B13,38G33-1	BA	16	600V, 1 core
E22	EDB	HEAD LIGHT CONTROLLER	△1 70B01(~~38B60-1~~),38G21-1	BA	△1 ~~14~~ 12	~~2000V~~ 600V, 1 core
E23	EDB	LEFT CONSOLE SW PANEL	38B53,10B87,46B01,10B31-1	BA	16	600V, 1 core
			10B32-4			
E24	EDB	LEFT CONSOLE SW PANEL	5903-1/1,5903-1/2,5903-1/S	S1	16	600V, 2 core Shield
E25	EDB	LEFT DOOR CONTROL PANEL	20B02-1,20B04-1,38G55-2	BA	16	600V, 1 core
			20B09-1,20B27,20B26,25B01-1			
			2055-3,2056-3,2057-3,2058-3			
E26	EDB	LEFT LOWER SW PANEL	61B02,38B21,38B34,6105	BA	16	600V, 1 core
			6201-1,6401-3,64B13-1			
E27	EDB	LEFT UPPER SW PANEL	38B45,61B01,66B20,5201,5202	BA	16	600V, 1 core
			61B03,6104,6604			
E28	EDB	MARKER LIGHT (R)	△1 ~~70B31-1~~ 70B30,38G12-1	BA	16	600V, 1 core
E29	EDB	MASTER CONTROLLER	38B39,10B01,1001-1,(~~20B13-1~~) △1	BA	16	600V, 1 core
			20B14-1,56B01,56B02,38B29			
			38G29-1,62B04,38G51-1			
			△1 (~~38B29-1~~,38B38-1),62B11,62B12			
			△1 (38B56-1) ,38B32-1,(~~38G29-5~~,38G38-3) △1			
			38B28-4,62B20,38B28-8,62B21-1			
			5602,5603,5605,5606,5607			
			△1 60B70(~~20B11~~ 22B98,20B12,5601			
E30	EDB	MDS	9401-13/1,9401-13/2	S1	20	600V, 2 core Shield
			9401-13/S			
E31	EDB	MDS	38B32,95B30,95B31	BA	16	600V, 1 core
			95B13,95B14,95B15,95B22			
			95B32,95B34(MB),95B35,95B60			
			95B61,95B41,95B45,95B46			
			95B47,95B48,95B53,38G32-1			
			38G32-2,6201-7			
			38G51-5			
E32	EDB	OPERATORS CAB LED LIGHT	38G12-3	BA	16	600V, 1 core
E33	EDB	OPERATORS CAB WINDSHIELD HEATER	46U03,46V03	AC	16	2000V, 1 core
E35	EDB	PT RECTIFIER	50P01-2(MB),50N01-2(MB)	AC	16	600V, 1 core
E37	EDB	PTC P/S(13.5V)	38B28,38G28-1	BA	16	600V, 1 core
E38	EDB	RESISTOR PANEL	93B12,38B33,9308-1,9301	BA	16	600V, 1 core
			9302,9303,9304,9305,9306			
			9307			
E39	EDB	RIGHT CONSOLE SW PANEL	30B05-1,56B01-2,38B12,70B31	BA	16	600V, 1 core
			30B03,5609,38B60-3			
E40	EDB	RIGHT DOOR CONTROL PANEL	38B39-1,1001,20B02,20B04	BA	16	600V, 1 core
			38B55,20B08,20B10,38G55-1			
			20B09,20B07,20B06,25B01,(20B30-1) △1			
			2005-3,2006-3,2007-3,2008-3			
E41	EDB	SMOKE DETECT. CONTROLLER	38B44,38G44-1,48B02,48B03	BA	14	600V, 1core(FR)
			38B56,4801			
E42	EDB	SMOKE DETECT. CONTROLLER	38B32-12,38B32-13	BA	16	600V, 1 core
E43	EDB	SOCKET OUTLET(R1)	34P05-1,34N05-1	AC	12	600V, 1 core
E44	EDB	SPEED SENSOR P/S(15V)	38B38-11,38G38-2	BA	16	600V, 1 core
E46	EDB	700MHz TRAIN RADIO P/S(13.5V)	38B92,38G91-1	BA	16	600V, 1 core
E47	EDB	WIPER DC/DC CONVERTER	10B37,38G53-1,10B32,10B31	BA	16	600V, 1 core
E48	EDB	WIPER MOTOR (ASSISTANT CAB)	10B32-2,10B31-3	BA	16	600V, 1 core
E49	EDB	WIPER MOTOR (OPERATORS CAB)	10B32-1,10B31-2	BA	16	600V, 1 core
E50	EDB	END DOOR LIGHT (F)	38G12-5	BA	16	600V, 1 core
E51	EDB	ASSISTANT CAB HEATER	44H21-11,44H22-11	AC	14	2000V,1core
E52	EDB	CAB SIGNAL JUNCTION TB	9005-1/1,9005-1/2,9005-1/3,9005-1/4	S1	16	△1 ~~600V, 2 core Shield~~ 600V, 4 core Shield
			9005-1/S,9006-1/1,9006-1/2,9006-1/3			
			9006-1/4,9006-1/S,9007-1/1,9007-1/2			
			9007-1/3,9007-1/4,9007-1/S			
E53	EDB	220MHz PTC RADIO P/S(74V)	38B90,38G90-1	BA	16	600V, 1 core
E54	EDB	WiFi/WiMAX P/S(13.5V)	38B89,38G89-1	BA	16	600V, 1 core
△1 E55	ETHERNET SW	WiFi/WiMAX P/S(13.5V)	38B89-1,38G89-2	BA	16	600V, 1 core

SYMBOL	FROM	TO	WIRE,NO.	CLASS	CABLE SIZE	CABLE TYPE
H01	HEAD LIGHT (R)	HEAD LIGHT (L)	70B11-1	BA	△1 ~~14~~ 12	~~2000V~~ 600V, 1 core
H02	HEAD LIGHT CONTROLLER	DIMMER CONTROLLER	70B13,70B14,70B15	BA	16	600V, 1 core
H03	HEAD LIGHT CONTROLLER	HEAD LIGHT (L)	70B10,70B11	BA	△1 ~~14~~ 12	~~2000V~~ 600V, 1 core
△1 H04	HEAD LIGHT CONTROLLER	EDB	38B60-1	BA	16	600V, 1 core
H05	HEAD LIGHT CONTROLLER	HEAD LIGHT (R)	70B09	BA	△1 ~~14~~ 12	~~2000V~~ 600V, 1 core
H06	HORN PRESSURE SW1	EDB	14B01	BA	16	600V, 1 core
H07	HORN PRESSURE SW2	CAB SIGNAL JUNCTION TB	92B05, 38B38-5	BA	16	600V, 1 core
H08	HORN HEATER	EDB	△1 ~~38B49-2,38G49-4~~ 38B63, 38G63)	BA	16	600V, 1 core
H09	HORN PRESSURE SW1	DESK CONSOLE SW PANEL	38B49-1	BA	16	600V, 1 core
I01	INT. SPEAKER 1	COMM. JUNCTION TB	84L20,84L21	S1	16	600V, 1 core
L01	LEFT CONSOLE SW PANEL	DUPLEX GAUGE	96B20-1,96B21-5	BA	16	600V, 1 core
L03	LEFT CONSOLE SW PANEL	WIPER MOTOR (ASSISTANT CAB)	10B83,10B84,10B86	BA	16	600V, 1 core
L04	LEFT CONSOLE SW PANEL	WIPER MOTOR (OPERATORS CAB)	10B33,10B34,10B36	BA	16	600V, 1 core
L05	LEFT DOOR CONTROL PANEL	RIGHT DOOR CONTROL PANEL	96B22-1,(20B30) △1	BA	16	600V, 1 core
L06	LEFT LOWER SW PANEL	AUX. LIGHT CONTROLLER	70B02-1,70B05,70B06,70B07	BA	16	600V, 1 core
L07	LEFT LOWER SW PANEL	DESK CONSOLE SW PANEL	38B34-1,38B32-8	BA	16	600V, 1 core
L08	LEFT LOWER SW PANEL	HEAD LIGHT CONTROLLER	70B02,70B03	BA	16	600V, 1 core
L09	LEFT LOWER SW PANEL	MASTER CONTROLLER	62B05,6201	BA	16	600V, 1 core
L10	LEFT LOWER SW PANEL	MDS	95B23	BA	16	600V, 1 core
L11	LEFT UPPER SW PANEL	CAB SIGNAL JUNCTION TB	6104-5	BA	16	600V, 1 core
L12	LEFT UPPER SW PANEL	LEFT LOWER SW PANEL	38B32-7	BA	16	600V, 1 core
L13	LEFT UPPER SW PANEL	MDS	95B36,95B37,95B42	BA	16	600V, 1 core
M01	MARKER LIGHT (R)	MARKER LIGHT (L)	△1 ~~70B31-2~~ 70B30-1,38G12-2	BA	16	600V, 1 core
M03	MASTER CONTROLLER	CAB SIGNAL JUNCTION TB	90B03,90B,04,90B41,90B15-3	BA	16	600V, 1 core
			92B01,92B08			
			92B09,92B10,92B11,92B12			
M04	MASTER CONTROLLER	FBCU	6001/1,6001/2,6001/3,6001/S	S1	16	600V, 3 core Shield
M05	MASTER CONTROLLER	FBCU	6002/1,6002/2,6002/S	S1	16	600V, 2 core Shield
M06	MASTER CONTROLLER	MDS	95B01,95B02,95B03,95B05	BA	16	600V, 1 core
			95B06,95B07,95B08,95B09			
			95B10,95B11,95B12 △1			
M07	MDS	APC RACK BOARD	89B30(MA),89B31(MA)	BA	16	600V, 1 core
M08	MDS	CCTV DVR	9401/1,9401/2,9401/S	S1	20	600V, 2 core Shield
M09	MDS FAULT LED	MDS	95B90	BA	16	600V, 1 core
M10	MDS FAULT LED	EDB	SP155,38B32-14	BA	16	600V, 1 core
M11	MDS	COMM. JUNCTION TB	38G32-10,38G32-11,38G32-12,38G32-7	BA	16	600V, 1 core
			38G32-6,38G32-8,38G32-9			
O01	OPERATORS CAB LED LIGHT	ASSISTANT CAB LED LIGHT	70B32-1	BA	16	600V, 1 core
O02	OPERATORS CAB LED LIGHT	END DOOR LIGHT (F)	38G12-4	BA	16	600V, 1 core
O03	OVER HEAD INDICATOR PANEL	LEFT UPPER SW PANEL	96B22-4,96B23-1	BA	16	600V, 1 core
P01	PT RECTIFIER	BACK WALL SW PANEL	50B01(MB),50B02(MB)	BA	16	600V, 1 core
P02	PTC P/S (13.5V)	CM-05	△1 (~~38G28-1~~,38B28-9),38G28-5	BA	16	600V, 1 core
P03	PT RECTIFIER	EDB	50B01-1(MB), 50B02-1(MB)	BA	16	600V, 1 core
P07	PTC PMVCOS	ATC PMVCOS	10B60-3,1006-7	BA	16	600V, 1 core
P08	△1 PTC PMVCOS ~~PTC PMV CUT OUT COCK~~	CAB SIGNAL JUNCTION TB	38B28-6,90B23	BA	16	600V, 1 core
R01	READING LIGHT (RED) (ASSISTANT)	READING LIGHT (WHITE) (OPERATOR)	96B19-2,96B21-2	BA	16	600V, 1 core
R02	READING LIGHT (RED) (OPERATOR)	LEFT CONSOLE SW PANEL	96B21-4	BA	16	600V, 1 core
R03	READING LIGHT (RED) (OPERATOR)	READING LIGHT (RED) (ASSISTANT)	96B18-1	BA	16	600V, 1 core
R04	READING LIGHT (WHITE) (ASSISTANT)	READING LIGHT (RED) (ASSISTANT)	96B19-1,96B21-1	BA	16	600V, 1 core
R05	READING LIGHT (WHITE) (OPERATOR)	READING LIGHT (RED) (OPERATOR)	96B19-3,96B21-3	BA	16	600V, 1 core
R06	READING LIGHT (WHITE) (OPERATOR)	READING LIGHT (WHITE) (ASSISTANT)	96B17-1	BA	16	600V, 1 core
R07	RESISTOR PANEL	FDP	9301-1,9302-1,9303-1,9304-1	BA	16	600V, 1 core
			9305-1,9306-1,9307-1,9308-2			
			93B21			
R08	RESISTOR PANEL	MDS	9301-2,9302-2,9303-2,9304-2	BA	16	600V, 1 core
			9305-2,9306-2,9307-2,9308-3			
			9308-4			
R09	RIGHT CONSOLE SW PANEL	READING LIGHT (RED) (OPERATOR)	96B18	BA	16	600V, 1 core
R10	RIGHT CONSOLE SW PANEL	READING LIGHT (WHITE) (OPERATOR)	96B17	BA	16	600V, 1 core
R11	RIGHT DOOR CONTROL PANEL	LEFT UPPER SW PANEL	38B32-6	BA	16	600V, 1 core
R12	RIGHT DOOR CONTROL PANEL	MDS	95B20	BA	16	600V, 1 core
R13	RIGHT DOOR CONTROL PANEL	OVER HEAD INDICATOR PANEL	96B22-3	BA	16	600V, 1 core
S01	SMOKE DETECT. CONTROLLER	MDS	95B54,95B55	BA	16	600V, 1 core
△1 S02	SPEED SENSOR P/S(15V)	CAB SIGNAL JUNCTION TB	91B01,91B02	BA	16	600V, 1 core
T01	TWC P/S(24V)	700MHz TRAIN RADIO P/S(13.5V)	38B92-1,38G91-2	BA	16	600V, 1 core
T02	TWC P/S(24V)	CAB SIGNAL JUNCTION TB	△1 ~~38B97,38B98~~ 86B01,86B02)	BA	16	600V, 1 core
△1 C60	CCTV DVR	NVR	8521/1,8521/2,8521/3,8521/4,8521/S	S1	ETHERNET	ETHERNET CABLE
D40	DC/DC CONVERTER FOR NVR	EDB	38B65, 38G65, 97L02	BA	16	600V, 1 core
D41	DC/DC CONVERTER FOR NVR	NVR	97L01, 97E01	BA	16	600V, 1 core
E60	ETHERNET SW	NVR	8520/1,8520/2,8520/3,8520/4,8520/S	S1	ETHERNET	ETHERNET CABLE

SPARE CABLE LIST

SYMBOL	FROM	TO	WIRE,NO.	CLASS	CABLE SIZE	CABLE TYPE
B02	BACK WALL SW PANEL	CAB SIGNAL JUNCTION TB	SP101, SP102, SP103, SP104	BA	16	600V, 1 core
C11	EDB	CAB SIGNAL JUNCTION TB	SP105, SP106, SP107, SP108, SP109	BA	16	600V, 1 core
C11	EDB	CAB SIGNAL JUNCTION TB	SP110, SP111	BA	16	600V, 1 core
C28	COMM. JUNCTION TB	DPO	SP112, SP113, SP114	BA	16	600V, 1 core
C34	COMM. JUNCTION TB	EDB	SP115, SP116, SP117, SP118	BA	16	600V, 1 core
D05	DESK CONSOLE SW PANEL	EDB	SP119, SP120, SP121	BA	16	600V, 1 core
D17	DIMMER CONTROLLER	OVER HEAD INDICATOR PANEL	SP122, SP123, SP124	BA	16	600V, 1 core
△1 E08-1	EDB	AUX. LIGHT CONTROLLER	SP125, SP126, SP127	BA	14	600V, 1 core
E22-1	EDB	HEAD LIGHT CONTROLLER	SP128, SP129, SP130	BA	14	2000V, 1 core
E23	EDB	LEFT CONSOLE SW PANEL	SP131, SP132, SP133	BA	16	600V, 1 core
E25	EDB	LEFT DOOR CONTROL PANEL	SP134, SP135, SP136	BA	16	600V, 1 core
E27	EDB	LEFT UPPER SW PANEL	SP138, SP139, SP140	BA	16	600V, 1 core
E29	EDB	MASTER CONTROLLER	SP141, SP142, SP143, SP144, SP145	BA	16	600V, 1 core
			△1 (~~SP146~~)			
E51	EDB	ASSISTANT CAB HEATER	SP147, SP148, SP149	AC	14	2000V, 1 core
M03	MASTER CONTROLLER	CAB SIGNAL JUNCTION TB	SP150, SP151, SP152	BA	16	600V, 1 core
R07	RESISTOR PANEL	FDP	SP153, SP154, SP155	BA	16	600V, 1 core
△1 E08	EDB	AUX. LIGHT CONTROLLER	SP156, SP157, SP158	BA	12	600V, 1 core
E22	EDB	HEAD LIGHT CONTROLLER	SP159, SP160, SP161	BA	12	600V, 1 core
△1 E99	COMM. JUNCTION TB	FAN	38B93-5,38G93-5	BA	16	600V, 1 core

두께			
두께 THICKNESS	~ 40	2	4
	~ 30	2	3
	~ 10	1	1.5
	< 3	0.5	1
재료			
최소 구멍 MIN. HOLE	~3150	-	7
	~1600	4	5
	~ 800	3	4
	~ 400	2	3
	~ 200	1.5	2
	~ 100	1	1.5
등급 GRADE		A	B
주물 주강품 CASTING			(±)
~ 20M	8	14	24
~ 15M	7	12	21
~ 12M	6	10	18
~ 8M	5	8	14
~ 4M	4	6	11
~ 2M	3	4	8
~ 1M	2	3	6
~ 315	1	2	4
~ 120	1	2	3
~ 30	1	1	1
등급 GRADE	A	B	C
용접 구조물 WELDING			(±)
~ 20M	-	5.0	8.0
~ 15M	-	5.0	7.0
~ 12M	-	4.0	6.0
~ 8M	-	3.0	5.0
~ 4M	0.8	2.0	4.0
~ 2M	0.5	1.2	3.0
~ 1M	0.3	0.8	2.0
~ 315	0.2	0.5	1.2
~ 120	0.15	0.3	0.8
~ 30	0.1	0.2	0.5
3~6	0.05	0.1	0.2
등급 GRADE	A	B	C
기계 가공품 MACHINING			(±)

규정치않은 일반공차표
GENERAL TOLERANCE

기호 MARK	일자 DATE	변경내역 DETAIL OF REVISION(E.C ZONE)	설변번호 E.C NO.	설계 DGN	검도 CHK	승인 APP	기호 MARK	일자 DATE	변경내역 DETAIL OF REVISION(E.C ZONE)	설변번호 E.C NO.	설계 DGN	검도 CHK	승인 APP
△x3	2018.01.11	SYMBOL H08 38B49-2,38G49-4 -> 38B63,38G63 ADDED SYMBOL "C60,D40,D41,E60,E99"	RNE1002-U529	BJHWANG	M.S.KIM	H.G.RYU	△x3	2013.09.05	DELETED WIRE NUMBER 20B13-1 AND ADDED WIRE 38B56-1 BY USING SPARE CABLE "SP146"	RNE1002-U357	J.H.KIM	H.S.PARK	D.I.KIM
△x7	2016.01.07	CHANGED WIRING CABLE SIZE (14->12)	RNE1002-U523	BJHWANG	M.S.KIM	H.G.RYU	△x5	2013.07.04	CHANGED THE WIRE NUMBER AT "E29" AND ADDED WIRING CABLE AT "E06,E40,L05"	RNE1002-U324	J.H.KIM	H.S.PARK	D.I.KIM
△x2	2015.04.02	SYMBOL E28 70B31-1 -> 70B30 SYMBOL M01 70B31-2 -> 70B30-1	RNE1002-U483	BJHWANG	C.H.CHOI	S.H.JEON	△x1	2012.12.26	ADDED CABLE SYMBOL 'E55'	RNE1002-U249	J.H.KIM	H.S.PARK	D.I.KIM
△x2	2014.10.24	ADDED WIRE 38B60-1 AT SYMBOL 'H04' REMOVED WIRE 38B60-1 AT SYMBOL 'E22'	RNE1002-U467	J.H.KIM	H.S.PARK	D.I.KIM	△x8	2012.10.31	CHANGED WIRING INFORMATION	RNE1002-U199	J.H.KIM	H.S.PARK	D.I.KIM
△x3	2014.03.18	ADDED WIRE AT SYMBOL 'E06' CHANGED THE WIRE NUMBER AT SYMBOL 'E29'	RNE1002-U405	J.H.KIM	H.S.PARK	D.I.KIM	△x6	2012.08.23	CHANGED WIRING INFORMATION	RNE1002-U180	J.H.KIM	H.S.PARK	D.I.KIM

품번 NO.	부품 번호 PART NO.	품 명 DESCRIPTION	재 질 MATERIAL / 수량 Q'TY / 중량 W.T / 비 고 REMARKS
승인 APP	D.I.KIM 2012.05.28	재질 MAT'L N/A	명 칭 TITLE: WIRING DIAGRAM, F-END, MA, MB (5/5)
검도 CHK	H.S.PARK 2012.05.28	중량 G.W N/A	
설계 DGN	J.H.KIM 2012.05.28	일반공차 MC WD CT	도면 번호 DRG. NO: REW60003CT0 Ver. 00 Rev. -P
제도 DRG		SIZE D	SCALE / 매수 SHEET 5 of 5

참고번호 REF. NO.

HYUNDAI Rotem 현대로템주식회사

RNE1002 / 년-PRJT / 정리번호

본 도면은 당사 재산으로서 허가없이 무단복사/배포 금지함. PROPERTY OF ISSUING ENTITY. CANNOT BE DISTRIBUTED OR REPRODUCED WITHOUT AUTHORIZATION.

AutoCAD