

API COMMAND SET

MX0808-1023-000

4K Seamless Switching HDMI Matrix with Multiple View and Video Wall

📁 V1.0.1 | 📅 November 11, 2025

RS232 Default Setting

Parameters	Value
Baud Rate	9600 bps
Data bits	8 bits
Parity	None
Stop bits	1 bit
Flow control	None

Telnet Session Setup

Before sending API commands to the device's LAN port, telnet session between the device and the PC should be established.

To establish a telnet session, send the following command:

telnet ip (port)

- *ip*: The device's IP address.
- *port*: The protocol port number, this is non-required on some telnet client tools or platforms. By default, the telnet port number is 23 and telnet-TLS port number is 24.

For example, if the device's IP address is 192.168.10.254, the command for establishing a telnet session shall be:

telnet 192.168.10.254 23

Command Description

Take Command *SET SW in out<CR><LF>* as an example:

1. *[SET SW]* denotes command key words, case insensitive.
2. *[in out]* denotes parameters, case insensitive; incorrect parameters will not be recognized.
3. *<CR><LF>* denotes a carriage return or a line feed; all commands must be ended up with a carriage return or a line feed.

No.	Description	Command	Example
Video Switch			
1	Switch one Input to one Output	Command: SET SW <i>in out</i> <CR><LF> Return: SW <i>in out</i> <CR><LF> Parameter: <i>in</i> = {in1, in2...in8, in0}; <i>out</i> = {out1,out2...out8}; Description: SW is short for Switch Switch one input source to one output sink.	Command: SET SW in1 out2<CR><LF> Return: SW in1 out2<CR><LF> Description: Switch input 1 to hdmi output 2.
2	Switch one indicate input to all outputs	Command: SET SW <i>in all</i> <CR><LF> Return: SW <i>in all</i> <CR><LF> Parameter: <i>in</i> = { in1, in2... in8, in0}; <i>all</i> = {all}; Description: SW is short for Switch Switch one input source to all output sinks.	Command: SET SW in1 <i>all</i> <CR><LF> Return: SW in1 <i>all</i> <CR><LF> Description: Switch input1 to all output sinks.
3	Get which input is mapping to the indicate Output	Command: GET MP <i>out</i> <CR><LF> Return: Mp <i>in out</i> <CR><LF> Parameter: <i>in</i> = {in1, in2...in8, in0}; <i>out</i> = {out1,out2...out8}; Description: MP is short for mapping Get which input is mapping to the indicate Output.	Command: GET MP <i>out1</i> <CR><LF> Return: MP <i>hdmiin2 out1</i> <CR><LF> Description: Get which input is mapping to output 1.
4	Get correspondence between all inputs and outputs	Command: GET MP <i>all</i> <CR><LF> Return: MP <i>in out</i> <CR><LF> MP <i>in out</i> <CR><LF> Parameter: <i>in</i> = {in1,in2...in8,in0}; <i>out</i> = {out1,out2...out8}; <i>all</i> = {all}; Description: MP is short for mapping Get correspondence between all inputs and outputs.	Command: GET MP <i>all</i> <CR><LF> Return: MP <i>in1 out1</i> <CR>... MP <i>in2 out2</i> <CR><LF> Description: Get correspondence between all inputs and outputs.

No.	Description	Command	Example
5	Set AV mute status	Command: SET AV_MUTE <i>out prm</i> <CR><LF> Return: AV_MUTE <i>out prm</i> <CR><LF> Parameter: <i>out</i> = {out1, out2, out3, out4...out8}; <i>prm</i> = {on, off}// on means mute;off means unmute Description: Mute the output audio and video	Command: SET AV_MUTE <i>out1 on</i> <CR><LF> Return: AV_MUTE <i>out1 on</i> <CR><LF> Description: Mute output1.
6	Get AV mute status	Command: GET AV_MUTE <i>out</i> <CR><LF> Return: AV_MUTE <i>out prm</i> <CR><LF> Parameter: <i>out</i> = {out1, out2, out3, out4...out8}; <i>prm</i> = {on, off}// on means mute;off means unmute Description: Get the mute status of outputs.	Command: GET AV_MUTE <i>out1</i> <CR><LF> Return: AV_MUTE <i>out1 on</i> <CR><LF> Description: Get mute status of out1, and the status is mute.
Audio Switch			
1	Set the mode of audio switching	Command: SET AUDIOSW_M <i>prm</i> <CR><LF> Return: AUDIOSW_M <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {independent, follow}; Description: Set the mode of audio switching.	Command: SET AUDIOSW_M <i>independent</i> <CR><LF> Return: AUDIOSW_M <i>independent</i> <CR><LF> Description: Set the audio switching mode to independent.
2	Get the mode of audio switching	Command: GET AUDIOSW_M<CR><LF> Return: AUDIOSW_M <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {independent, follow}; Description: Get the mode of audio switching.	Command: GET AUDIOSW_M<CR><LF> Return: AUDIOSW_M <i>independent</i> <CR><LF> Description: Get the mode of audio switching, the result is independent mode.
3	Switch one audio input to one audio output	Command: SET AUDIOSW <i>in out</i> <CR><LF> Return: AUDIOSW <i>in out</i> <CR><LF> Parameter: <i>in</i> = {IN1~IN8}; <i>out</i> = {LINEOUT1~LINEOUT4, all}; Description: Audio channel switching supported only in standalone mode.	Command: SET AUDIOSW <i>IN1 LINEOUT1</i> <CR><LF> Return: AUDIOSW <i>IN1 LINEOUT1</i> <CR><LF> Description: In independent mode, switch the IN1 audio source to LINEOUT1.

No.	Description	Command	Example
4	Get which audio input is mapping to the indicate audio Output	Command: GET AUDIOMP <i>out</i> <CR><LF> Return: AUDIOMP <i>in out</i> <CR><LF> Parameter: <i>in</i> = {IN1~IN8}; <i>out</i> = {LINEOUT1~LINEOUT4, all}; Description: Get the output audio source only available in standalone mode.	Command: GET AUDIOMP <i>LINEOUT1</i> <CR><LF> Return: AUDIOMP IN1 LINEOUT1<CR><LF> Description: In independent mode, the audio source switched to LINEOUT1 is IN1.
5	Audio output volume gain adjust	Command: SET VOLGAIN_DATA <i>out prm</i> <CR><LF> Return: VOLGAIN_DATA <i>about prm</i> <CR><LF> Parameter: <i>out</i> = { <i>lineout1, lineout2,...lineout4</i> }; <i>prm</i> = {-100 ~ 0} Description: VOLGAIN is volgain	Command: SET VOLGAIN_DATA <i>lineout1 -50</i> <CR><LF> Return: VOLGAIN_DATA <i>lineout1</i> <CR><LF> Description: Set volume gain to -50.
6	Get audio output volume	Command: GET VOLGAIN_DATA <i>out</i> <CR><LF> Return: VOLGAIN_DATA <i>out prm</i> <CR><LF> Parameter: <i>out</i> = { <i>lineout1, lineout2,...lineout4</i> }; <i>prm</i> = {-100~0} Description: VOLGAIN is volgain	Command: GET VOLGAIN_DATA <i>lineout1</i> <CR><LF> Return: VOLGAIN_DATA <i>lineout1 -50</i> <CR><LF> Description: Get volume gain, the gain is -50.
7	Mute/unmute audio output	Command: SET AUDIO_MUTE <i>out prm</i> <CR><LF> Return: AUDIO_MUTE <i>out prm</i> <CR><LF> Parameter: <i>about</i> = { <i>lineout1,lineout2,...lineout4</i> }; <i>prm</i> = {on,off}// on means mute;off means unmute Description: MUTE is mute	Command: SET AUDIO_MUTE <i>lineout1 on</i> <CR><LF> Return: AUDIO_MUTE <i>lineout1 on</i> <CR><LF> Description: Mute hdmi1
8	Get audio output mute status	Command: GET AUDIO_MUTE <i>out</i> <CR><LF> Return: AUDIO_MUTE <i>out prm</i> <CR><LF> Parameter: <i>out</i> = { <i>lineout1, lineout2,...lineout4</i> }; <i>prm</i> = {on,off}// on means mute;off means unmute	Command: GET AUDIO_MUTE <i>lineout1</i> <CR><LF> Return: AUDIO_MUTE <i>lineout1 on</i> <CR><LF> Description: Get mute status of out1,and the status is mute.

No.	Description	Command	Example
		Description: MUTE is mute	
CEC			
1	Set CEC POWER ON/OFF	Command: SET CEC_PWR out prm<CR><LF> Return: CEC_PWR out prm<CR><LF> Parameter: prm = {on, off} out = {out1, out2...out8,all}; Description: Set sink to power on or off.	Command: SET CEC_PWR out1 on<CR><LF> Return: CEC_PWR out1 on<CR><LF> Description: Set sink hdmi output 1 to power on.
2	Set CEC AUTO POWER ON/OFF	Command: SET AUTOCEC_FN out prm<CR><LF> Return: AUTOCEC_FN out prm<CR><LF> Parameter: prm = {on, off} out = {out1,out2...out8,all}; Description: Set sink auto power Function to ON or OFF.	Command: SET AUTOCEC_FN out1 on<CR><LF> Return: AUTOCEC_FN out1 on<CR><LF> Description: Set sink hdmi output 1 auto power to ON.
3	Get CEC AUTO POWER ON/OFF Status	Command: GET AUTOCEC_FN out<CR><LF> Return: AUTOCEC_FN out prm<CR><LF> Parameter: prm = {on, off} out = {out1,out2...out8}; Description: Get Sink auto power Function ON or OFF Status.	Command: GET AUTOCEC_FN out1<CR><LF> Return: AUTOCEC_FN on Description: Get Sink auto power status, and the status is ON.
4	Set CEC POWER Delay Time	Command: SET AUTOCEC_D out prm<CR><LF> Return: AUTOCEC_D out prm<CR><LF> Parameter: out = {out1,out2...out8,all}; prm = {1,2,3,...,} // according to the actual time counter, 1 means 1 minute ,2 means 2 minutes, Default wait time is 2 minutes, Max wait time is 30 minutes. 0 means when no active signal, the unit auto power off immediately. Description: AUTOCEC_D is short for CEC auto Power Delay Timing.	Command: SET AUTOCEC_D out1 2<CR><LF> Return: AUTOCEC_D out1 2<CR><LF> Description: when no active signal to hdmi1, 2 minutes later, the unit will auto power off.

No.	Description	Command	Example
5	Get CEC POWER Delay Time Status	Command: GET AUTOCEC_D <i>out</i> <CR><LF> Return: AUTOCEC_D <i>out prm</i><CR><LF> Parameter: <i>out</i> = {out1,out2...out8,all}; <i>prm</i> = {1,2,3,...};// according to the actual time counter,1 means 1 minute ,2 means 2 minutes, Default wait time is 2 minutes,Max wait time is 30 minutes. 0 means when no active signal, the unit auto power off immediately. Description: AUTOCEC_D is short for CEC auto Power Delay Timing.	Command: GET AUTOCEC_D <i>out1</i> <CR><LF> Return: AUTOCEC_D <i>out1 2</i> <CR><LF> Description: Get hdmi1 auto power delay time, the result is 2 minutes.
6	Set CEC command for defining Poweron/Poweroff	Command: SET CECCMD_EDIT <i>out prm1 prm2</i><CR><LF> Return: CECCMD_EDIT <i>out prm1 prm2</i><CR><LF> Parameter: <i>out</i> = {out1,out2...out8,all}; <i>prm1</i> = {pwron, pwroff}, // <i>prm2</i> = {...},// many hexadecimal numbers, the total is less than 16. Space separated Description: Set CEC command for defined Poweron/Poweroff. If relevant commands are required, please refer to CEC specification for details.	Command: SET CECCMD_EDIT <i>out1 pwron 40 04</i><CR><LF> Return: CECCMD_EDIT <i>out1 pwron 40 04</i><CR><LF> Description: Set CEC command.
7	Get CEC command for defining Poweron/Poweroff	Command: GET CECCMD_EDIT <i>out prm1</i><CR><LF> Return: CECCMD_EDIT <i>out prm1 prm2</i><CR><LF> Parameter: <i>out</i> = {out1,out2...out8, all}; <i>prm1</i> = {pwron, pwroff}, // <i>prm2</i> = {...},// many hexadecimal numbers, the total is less than 16. Space separated Description: Get CEC command for defining Poweron/Poweroff.	Command: GET CECCMD_EDIT <i>out1 pwron</i><CR><LF> Return: CECCMD_EDIT <i>out1 pwron 40 04</i><CR><LF>

No.	Description	Command	Example
8	Send CEC command	Command: SET CEC_CMD <i>out prm</i> <CR><LF> Return: CEC_CMD <i>out prm</i> <CR><LF> Parameter: <i>out</i> = {out1,out2...out8,all}; <i>prm</i> = {...},// many hexadecimal numbers, the total is less than 16. Space separated Description: Send CEC command If relevant commands are required ,please refer to CEC specification for details.	Command: SET CEC_CMD out1 40 04<CR><LF> Return: CEC_CMD out1 40 04<CR><LF> Description: Send CEC command.
HDCP			
1	Set Input HDCP support to ON/OFF	Command: SET HDCP_S <i>in prm</i> <CR><LF> Return: HDCP_S <i>in prm</i> <CR><LF> Parameter: <i>prm</i> = {on, off} <i>in</i> = {in2...in8} Description: HDCP_S will control source hdp support on or off.	Command: SET HDCP_S in2 <i>on</i> <CR><LF> Return: HDCP_S in2 <i>on</i> <CR><LF> Description: Set hdmi input 2 hdp support to on.
2	Get Input HDCP support ON/OFF Status	Command: GET HDCP_S <i>in</i> <CR><LF> Return: HDCP_S <i>in prm</i> <CR><LF> Parameter: <i>prm</i> = {on, off} <i>in</i> = {in2...in8} Description: HDCP_S is short for HDCP support.	Command: GET HDCP_S in2<CR><LF> Return: HDCP_S <i>in2 on</i> <CR><LF> Description: Get hdmi2 hdp support on or off status, and the result is on
3	Set Output HDCP	Command: SET HDCP <i>out prm</i> <CR><LF> Return: HDCP <i>out prm</i> <CR><LF> Parameter: <i>out</i> = {out1,out2...out8,all};// all includes hdmiout1-hdmiout8 <i>prm</i> = {follow, hdp1.x}// follow means source use hdp 1.4 ,then output also use hdp 1.4. the same with hdp 2.2 and off. Description: Set Output HDCP.	Command: SET HDCP <i>out1 follow</i> <CR><LF> Return: HDCP <i>out1 follow</i> <CR><LF> Description: set output hdp to follow mode.

No.	Description	Command	Example
4	Get Output HDCP	Command: GET HDCP <i>out</i><CR><LF> Return: HDCP <i>out prm</i><CR><LF> Parameter: <i>out</i> = {out1,out2...out8,all};// all includes hdmiout1-hdmiout8 <i>prm</i> = {follow, hdcpl.x}// follow means source use hdcpl.4 ,then output also use hdcpl.4. the same with hdcpl.2 and off. Description: Get Output HDCP.	Command: GET HDCP <i>out1</i><CR><LF> Return: HDCP <i>out1 follow</i><CR><LF> Description: Get output hdcpl, the result is follow mode.
EDID			
1	Set Input EDID	Command: SET EDID <i>in prm</i><CR><LF> Return: EDID <i>in prm</i><CR><LF> Parameter: <i>in</i> = {in1, in2...in8}; <i>prm</i> = {1 ~30} 1: Copy form hdmi output 1 2: Copy form hdmi output 2 ... 8: Copy form hdmi output 8 9: Fixed 3840x2160@60 PCM Audio with HDR; 10: Fixed 3840x2160@60 PCM Audio with SDR; 11: Fixed 3840x2160@30 PCM Audio with HDR; 12: Fixed 3840x2160@30 PCM Audio with SDR; 13: Fixed 1920x1080@60 PCM Audio with HDR; 14: Fixed 1920x1080@60 PCM Audio with SDR; specail edid 15: Fixed 8Kx1K, 5Kx1K@60Hz PCM Audio 16: Fixed 3840x1080@60Hz PCM Audio 17: Fixed 3440x1440@60 PCM Audio 18: Fixed 2560x1600@60 PCM Audio 19: Fixed 2560x1536@60 PCM Audio 20: Fixed 2560x1440@60 PCM Audio 21: Fixed 2560x1080@60 PCM Audio 22: Fixed 1920x2160@60 PCM Audio 23: Fixed 1680x1050@60 PCM Audio 24: Fixed 1600x1200@60 PCM Audio 25. Fixed 5K Superwide PCM Audio with HDR 26. Fixed 5K Ultrawide PCM Audio with HDR Description: Set Input EDID.	Command: SET EDID <i>in1 10</i><CR><LF> Return: EDID <i>in1 10</i><CR><LF> Description: Set in1 EDID to Fixed 3840x2160@60 PCM Audio with SDR.

No.	Description	Command	Example
2	Get All Input EDID status	Command: GET EDID <i>all</i> <CR><LF> Return: EDID <i>in prm</i><CR> EDID <i>in prm</i><CR> EDID <i>in prm</i><CR><LF> Parameter: in = {in1, in2...in8}; prm = {1 ~30} 1: Copy form hdmi output 1 2: Copy form hdmi output 2 ... 8: Copy form hdmi output 8 9: Fixed 4K60 2.0CH PCM Audio with HDR; 10: Fixed 4K60 2.0CH PCM Audio with SDR; 11: Fixed 4K30 2.0CH PCM Audio with HDR; 12: Fixed 4K30 2.0CH PCM Audio with SDR; 13: Fixed 1080p@60Hz 2.0CH PCM Audio with HDR; 14: Fixed 1080p@60Hz 2.0CH PCM Audio with SDR; specail edid 15: Fixed 8Kx1K, 5Kx1K@60Hz PCM Audio 16: Fixed 3840x1080@60Hz PCM Audio 17: Fixed 3440x1440@60 PCM Audio 18: Fixed 2560x1600@60 PCM Audio 19: Fixed 2560x1536@60 PCM Audio 20: Fixed 2560x1440@60 PCM Audio 21: Fixed 2560x1080@60 PCM Audio 22: Fixed 1920x2160@60 PCM Audio 23: Fixed 1680x1050@60 PCM Audio 24: Fixed 1600x1200@60 PCM Audio 25. Fixed 5K Superwide PCM Audio with HDR 26. Fixed 5K Ultrawide PCM Audio with HDR Description: Get all input EDID Status.	Command: GET EDID <i>all</i> <CR><LF> Return: EDID in1 01<CR> EDID in2 02<CR> EDID in3 03<CR><LF> Description: Get all input EDID Status.

No.	Description	Command	Example
3	Get one input EDID Status 获取一个输入口的EDID	Command: GET EDID <i>in</i> <CR><LF> Return: EDID <i>in prm</i> <CR><LF> Parameter: 1: Copy form hdmi output 1 2: Copy form hdmi output 2 ... 8: Copy form hdmi output 8 9: Fixed 4K60 2.0CH PCM Audio with HDR; 10: Fixed 4K60 2.0CH PCM Audio with SDR; 11: Fixed 4K30 2.0CH PCM Audio with HDR; 12: Fixed 4K30 2.0CH PCM Audio with SDR; 13: Fixed 1080p@60Hz 2.0CH PCM Audio with HDR; 14: Fixed 1080p@60Hz 2.0CH PCM Audio with SDR; specail edid 15: Fixed 8Kx1K, 5Kx1K@60Hz PCM Audio 16: Fixed 3840x1080@60Hz PCM Audio 17: Fixed 3440x1440@60 PCM Audio 18: Fixed 2560x1600@60 PCM Audio 19: Fixed 2560x1536@60 PCM Audio 20: Fixed 2560x1440@60 PCM Audio 21: Fixed 2560x1080@60 PCM Audio 22: Fixed 1920x2160@60 PCM Audio 23: Fixed 1680x1050@60 PCM Audio 24: Fixed 1600x1200@60 PCM Audio 25. Fixed 5K Superwide PCM Audio with HDR 26. Fixed 5K Ultrawide PCM Audio with HDR Description: Get one input EDID Status	Command: GET EDID in1<CR><LF> Return: EDID in1 10<CR><LF> Description: Get in1 edid status,and the status is Fixed 3840x2160@60 PCM Audio with SDR
4	Write EDID to an input	Command: SET EDID_W <i>in prm1 prm2</i> <CR><LF> Return: EDID_W <i>in prm1 prm3</i> <CR><LF> Parameter: <i>in</i> = {in1, in2...in8}; <i>prm1</i> = {block0, block1}; <i>prm2</i> = one block of 256 bytes edid ascii data with spaces(hex data need conversion into ASCII code) <i>prm3</i> = {ok, error}; error : check sum error Description: Write EDID content to input..	Command: SET EDID_W in1 <i>block0</i> XX...XX<CR><LF> Return: EDID_W in1 <i>block0 ok</i> <CR><LF> Description: write EDID content to input.

No.	Description	Command	Example
5	Read Output EDID	Command: GET EDID_R out<CR><LF> Return: EDID_R out prm1 prm2<CR><LF> Parameter: out = {out1, out2...out8}; prm1 = {block0, block1}; prm2 = { one block of 256 bytes edid ascii data with no spaces(hex data need conversion into ASCII code), error, unconnect}; Description: Read EDID content form output.	Command: GET EDID_R out1<CR><LF> Return: EDID_R out1 block0 XX...XX<CR><LF> EDID_R out1 block1 XX...XX<CR><LF> Description: EDID_R out1 block0 XX...XX<CR><LF> --- Read EDID ok or EDID_R out1 error<CR><LF> --- Check Sum Error or EDID_R out1 unconnect<CR><LF> --- Sink unconnect
System			
1	Factory reset	Command: RESET<CR><LF> Return: RESET<CR><LF> Description: Factory reset.	Command: RESET<CR><LF> Return: RESET<CR><LF> Description: Factory reset all board
2	System reboot	Command: REBOOT<CR><LF> Return: REBOOT<CR><LF> Description: System reboot.	Command: REBOOT<CR><LF> Return: REBOOT<CR><LF> Description: System reboot.
3	Get the API list	Command: help<CR><LF> Return: xxxx Description: Get the API list.	Command: help<CR><LF> Return: xxxx Description: Get the API list.
4	GET IP address	Command: GET IPADDR<CR><LF> Return: IPADDR xx.xx.xx.xx<CR><LF> Description: GET IP address.	Command: GET IPADDR<CR><LF> Return: IPADDR 192.168.11.243<CR><LF>
5	Get selected target firmware version	Command: GET VER<CR><LF> Return: VER prm<CR><LF> Parameter: prm = {...} // according to actual firmware version Description: Get selected target firmware version.	Command: GET VER<CR><LF> Return: ARM_Vx.y.z<CR><LF> Description: Get all module firmware version.

No.	Description	Command	Example
Preset			
1	Save or Load Preset Scene	Command: SET PRESET_X {ACTION} {TYPE} PRESETID<CR><LF> Return: PRESET_X {ACTION} {TYPE} PRESETID<CR><LF> Parameter: PRESETID = {1, 2, 3, ...}; // preset scene number ACTION = {save restore}; // operation type: save: Save the current configuration as a preset scene with the specified number. restore: Restore the configuration of the preset scene with the specified number. the {type} parameter has no effect during a restore operation. This is designed to simplify usage. TYPE = {video audio usb global videowall multiview}; // preset scene type video: Applies to video settings only audio: Applies to audio settings only usb: Applies to USB-related settings videowall: Applies to videowall settings only multiview: Applies to multiview settings only global: Applies to all types (video, audio, USB, etc.) Description: This command allows performing preset operations on a specified type of configuration (video, audio, USB, or global). According to the ACTION parameter, you can save, restore the configuration preset.	1 Command: SET PRESET_X save video 1<CR><LF> Return: PRESET_X save video 1<CR><LF> Description: Save current video settings to preset scene 1. 2 Command: SET PRESET_X restore global 2<CR><LF> Return: PRESET_X restore global 2<CR><LF> Description: Restore the preset settings saved in preset scene 2.
2	Name Preset Scene	Command: SET PRESET_X name global PRESETID [NAME] <CR><LF> Return: PRESET_X name global PRESETID [NAME] <CR><LF> Parameter: PRESETID = {1, 2, 3, ...}; // preset scene number NAME = {name}; // NAME preset scene name for name: The label can use numbers, letters, space and "_", "-"special character. Label length should be less than 32 characters. Description: This command allows performing preset operations on a specified type of configuration (video, audio, USB, or global). According to the ACTION parameter, you can name the configuration preset.scene's name.	3 Command: SET PRESET_X name global 3 MeetingRoom<CR><LF> Return: PRESET_X name global 3 MeetingRoom<CR><LF> Description: Set the name of preset scene 4 to "MeetingRoom".

No.	Description	Command	Example
3	Get Preset Status	Command: GET PRESET_X {prm1} {TYPE} {index_or_all} <CR><LF> Return: PRESET_X {prm1} {TYPE} PRESETINDEX STATUS PRESETNAME <CR><LF> Parameter: {prm1} = request operation The requested operation, only supports 'info' TYPE = {all}; all: Query all types (video, audio, usb, global, videowall, multiview) index_or_all = {1, 2, 3, ..., all}; // The preset scene number or 'all' can be used to retrieve information for all preset scenes. PRESETINDEX = preset scene number STATUS = {0, 1, 2}; // 0 represents an empty preset (Empty), 1 represents a defined but inactive preset (Inactive), and 2 represents a defined and active preset (Active). PRESETNAME = preset scene name Description: This command retrieves information about preset scenes by type and index. When TYPE is 'all', it queries all preset types (video, audio, usb, global). When index_or_all is 'all', it retrieves all presets under that TYPE.	1 Command: GET PRESET_X info all 1<CR><LF> Return: PRESET_X info video 1 2 MeetingRoom<CR><LF> Description: Get the information of preset scene 1. The status is 2, type is video, meaning this preset is defined and currently active, and the preset name is MeetingRoom. 2 Command: GET PRESET_X info all all<CR><LF> Return: PRESET_X info video 1 2 MeetingRoom<CR><LF> PRESET_X info audio 2 0 default_name<CR><LF> PRESET_X info usb 3 1 Conference<CR><LF> ** default_name: preset x Description: Query all presets from all types. Useful for full inspection or preset listing.
Resolution			
1	To set output resolution	Command: SET VIDOUT_RES out prm<CR><LF> Return: VIDOUT_RES out prm<CR><LF> Description: This function can only be set in SCALE manual mode out = {out1~out8, MV1 in multiview mode}; prm = { AUTO, 3840x2160@60, 3840x2160@50, 3840x2160@30, 3840x2160@25, 3840x2160@24, 1920x1200@60, 1920x1080@60, 1920x1080@50, 1680x1050@60, 1600x1200@60, 1600x900@60, 1440x900@60, 1366x768@60, 1360x768@60, 1280x1024@60, 1280x960@60, 1280x800@60, 1280x768@60, 1280x720@60,	Command: SET VIDOUT_RES out1 3840x2160@60<CR><LF> Return: VIDOUT_RES out1 3840x2160@60<CR><LF> Description: Set out1 resolution is 3840x2160@60.

No.	Description	Command	Example
		1280x720@50, 1024x768@60, 800x600@60 , Customized_1, Customized_2, Customized_3, }	
2	To get output resolution	Command: GET VIDOUT_RES <i>out</i><CR><LF> Return: VIDOUT_RES <i>out prm</i><CR><LF> Description: This function can only be set in SCALE manual mode <i>out</i> = {<i>out1~out8, MV1 in multiview mode</i>}; <i>prm</i>= { AUTO, 1280x800@60, 1280x768@60, 1024x768@60, 800x600@60 , Customized_1, Customized_2, Customized_3, }	Command: GET VIDOUT_RES <i>out1</i><CR><LF> Return: VIDOUT_RES <i>out1</i> 1280x800@60<CR><LF> Description: HDMI out resolution is 1280x800@60.
3	Set customized resolution	Command: SET CUSTOM_RES <i>out prm hactive vactive [fps]</i> <CR><LF> Return: CUSTOM_RES <i>out prm hactive vactive fps</i> <CR><LF> Parameter: <i>out</i> = {<i>out1~out8</i>}; <i>prm</i> = {<i>Customized_1~ Customized_3</i>}; <i>hactive</i> = {<i>0~7680</i>}; <i>vactive</i> = {<i>0~7680</i>}; <i>fps</i> = 60 Description: Set custom resolution. Note that the maximum transmission bandwidth for the <i>hactive*vactive@fps</i> combination cannot exceed 600Mhz.	Command: SET CUSTOM_RES Customized_1 3840 2160 60 <CR><LF> Return: CUSTOM_RES Customized_1 3840 2160 60 <CR><LF> Description: Set Customized_1 resolution to 3840x2160@60.

No.	Description	Command	Example
4	Get custom resolution	Command: GET CUSTOM_RES <i>prm</i> <CR><LF> Return: CUSTOM_RES <i>prm hactive vactive fps</i> <CR><LF> Parameter: out = {out1~out8}; prm = {Customized_1~Customized_3}; hactive = {0~7680}; vactive = {0~7680}; Description: Get custom resolution.	Command: GET CUSTOM_RES out1 Customized_1 <CR><LF> Return: CUSTOM_RES out1 Customized_1 3840 2160 60 <CR><LF> Description: The Customized_1 resolution is 3840x2160@60.
HTTPS & TelnetS			
1	Set HTTPS service status	Command: SET HTTPS <i>prm</i> <CR><LF> Return: HTTPS <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {on, off}; Description: Whether to open HTTP service	Command: SET HTTPSS on<CR><LF> Return: HTTPS on<CR><LF> Description: Whether to open HTTP service.
2	Get HTTPS service status	Command: GET HTTPS<CR><LF> Return: HTTPS<CR><LF> Parameter: <i>prm</i> = {on, off}; Description: Get HTTP service status.	Command: GET HTTPS<CR><LF> Return: HTTPS on<CR><LF> Description: Get HTTP service status.
3	Set Telnet-TLS service status	Command: SET TELNETS <i>prm</i> <CR><LF> Return: TELNETS <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {on, off}; // on means to enable Description: Telnet-TLS; off means to enable Telnet. TELNETS is short for Telnet-TLS.	Command: SET TELNETS on<CR><LF> Return: TELNETS on<CR><LF> Description: To enable Telnet-TLS.
4	Get TelnetS service status	Command: GET TELNETS<CR><LF> Return: TELNETS <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {on, off}; // on means to enable Description: Telnet-TLS; off means to enable Telnet. TELNETS is short for Telnet-TLS.	Command: GET TELNETS<CR><LF> Return: TELNETS on<CR><LF> Description: To get Telnet service status, and the result is Telnet-TLS is enabled

No.	Description	Command	Example
5	Set Telnet New password	Command: SET TEL_PWD Oldpwd Newpwd NewpwdVerify<CR><LF> Return: TEL_PWD prm<CR><LF> Parameter: Old/Newpwd : Must be 4 to 16 characters in length (alphanumeric only) prm : {0, 1}; // 0: failed, 1: success Description: Set the username and password for logging in to the telnet.	Command: SET TEL_PWD admin admin123 admin123<CR><LF> Return: TEL_PWD 1<CR><LF> Description: Change Telnet's password from [admin] to [admin123].
Xyte			
1	Set XYTE Enable Status	Command: SET XYTE_EN prm<CR><LF> Return: XYTE_EN prm<CR><LF> Parameter: prm = {ON, OFF} // ON means enabling the XYTE feature, OFF means disabling it Description: This command is used to set the status of the XYTE feature to ON or OFF.	Command: SET XYTE_EN ON<CR><LF> Return: XYTE_EN ON<CR><LF> Description: Set the XYTE feature to enabled.
2	Get XYTE Enable Status	Command: GET XYTE_EN<CR><LF> Return: XYTE_EN prm<CR><LF> Parameter: prm = {ON, OFF} // ON means the XYTE feature is enabled, OFF means the XYTE feature is disabled Description: This command retrieves the current status of the XYTE feature, indicating whether it is enabled (ON) or disabled (OFF).	Command: GET XYTE_EN<CR><LF> Return: XYTE_EN ON<CR><LF> Description: Retrieve the XYTE feature status, which is currently enabled.
3	Get XYTE Registration Status	Command: GET XYTE_REG<CR><LF> Return: XYTE_REG prm<CR><LF> Parameter: prm = {0, 1} // 0 means not registered, 1 means registered Description: This command retrieves the current registration status of the XYTE feature, indicating whether it is registered (1) or not registered (0).	Command: GET XYTE_REG<CR><LF> Return: XYTE_REG 1<CR><LF> Description: Retrieve the XYTE registration status, which is currently registered.

No.	Description	Command	Example
4	Get XYTE Connection Status	Command: GET XYTE_CONN<CR><LF> Return: XYTE_CONN prm<CR><LF> Parameter: prm = {0, 1} // 0 means not connected, 1 means connected Description: This command retrieves the current connection status of the XYTE feature, indicating whether it is connected (1) or not connected (0).	Command: GET XYTE_CONN<CR><LF> Return: XYTE_CONN 1<CR><LF> Description: Retrieve the XYTE connection status, which is currently connected.
5	Set XYTE Server URL	Command: SET XYTE_SRV_URL prm<CR><LF> Return: XYTE_SRV_URL prm<CR><LF> Parameter: prm = {xxx, DEFAULT} // "xxx" represents a custom XYTE server URL. If the URL contains spaces, they must be encoded as "%20". "DEFAULT" resets to the default XYTE server URL. Description: This command sets the XYTE server URL to a specified value or resets it to the default URL. Ensure that any spaces in the URL are encoded as "%20".	Command: SET XYTE_SRV_URL %20server.com<CR><LF> Return: XYTE_SRV_URL %20server.com<CR><LF> Description: Set the XYTE server URL to " server.com" (spaces are encoded as "%20").
6	Get XYTE Server URL	Command: GET XYTE_SRV_URL<CR><LF> Return: XYTE_SRV_URL prm<CR><LF> Parameter: prm = {xxx} // "xxx" represents the current XYTE server URL. If the URL contains spaces, they will be encoded as "%20". Description: This command retrieves the current URL of the XYTE server. If the URL contains spaces, they will be encoded as "%20".	Command: GET XYTE_SRV_URL<CR><LF> Return: XYTE_SRV_URL %20server.com<CR><LF> Description: Retrieve the current XYTE server URL, which is set to " server.com" (spaces are encoded as "%20").
Video / Audio Detail			
1	Get the signal status of the video input	Command: GET VIDIN_SIG in<CR><LF> Return: VIDIN_SIG in prm<CR><LF> in = {in1, in2...in8}; prm = {No, Valid} Description: Get the signal status of the video input.	Command: GET VIDIN_SIG in1<CR><LF> Return: VIDIN_SIG in1 Valid<CR><LF>

No.	Description	Command	Example
2	Get input video format information	Command: GET VIDIN_FORMAT <i>in</i><CR><LF> Return: VIDIN_FORMAT <i>in prm</i><CR><LF> <i>in</i> = {<i>in1</i>, <i>in2</i>...<i>in8</i>}; <i>prm</i> = { } Description: Get the resolution of the video input <i>prm</i> = {<horizontal>x<vertical>,<rate>; <HDR info>;<ColorSpace>,<DeepColor>} • horizontal = An integer value representing the horizontal. • vertical = An integer value representing the vertical. May have an additional qualifier such as 'i' or 'p'. • rate = An integer value representing the refresh rate. • HDR info = none hdr/ static hdr/ dynamic hdr • Color space = RGB / Ycbcr 444 /Ycbcr 422/Ycbcr 420 • DeepColor = 8 bit/10 bit /12 bit/ 16 bit	Command: GET VIDIN_FORMAT <i>in1</i><CR><LF> Return: VIDIN_FORMAT <i>in1 3840x2160,60;none</i> <i>hdr;rgb;8bit</i><CR><LF>
3	Get input audio format information	Command: GET AUDIN_FORMAT <i>in</i><CR><LF> Return: AUDIN_FORMAT <i>in prm</i><CR><LF> <i>in</i> = {<i>in1</i>, <i>in2</i>...<i>in8</i>}; <i>prm</i> = { } Description: Get the resolution of the video input <i>prm</i> = {<PCM / non-PCM>; <Sampling rate>}	Command: GET AUDIN_FORMAT <i>in1</i><CR><LF> Return: AUDIN_FORMAT <i>in1</i> <i>PCM;48kHz</i><CR><LF>
4	Get hdcp version of input video	Command: GET VIDIN_HDCP <i>in</i><CR><LF> Return: VIDIN_HDCP <i>in prm</i><CR><LF> <i>in</i> = {<i>in1</i>, <i>in2</i>...<i>in8</i>}; <i>prm</i> = {no hdcp, hdcp1.4, hdcp2.2} Description: Get hdcp version of input video.	Command: GET VIDIN_HDCP <i>in1</i><CR><LF> Return: VIDIN_HDCP <i>in1 no hdcp</i><CR><LF>
5	Get the signal status of the video output	Command: GET VIDOUT_SIG <i>out</i><CR><LF> Return: VIDOUT_SIG <i>out prm</i><CR><LF> <i>out</i> = {<i>out1</i>,<i>out2</i>...<i>out8</i>}; <i>prm</i> = {No, Valid} Description: Get the signal status of the video output.	Command: GET VIDOUT_SIG <i>out1</i><CR><LF> Return: VIDOUT_SIG <i>out1 Valid</i><CR><LF>

No.	Description	Command	Example
6	Get the video format information of output	Command: GET VIDOUT_FORMAT out<CR><LF> Return: VIDOUT_FORMAT out prm<CR><LF> out = {out1, out2...out8}; prm = { } Description: Get the resolution of the video input prm = {<horizontal>x<vertical>,<rate>; <HDR info>;<ColorSpace>,<DeepColor>} - horizontal = An integer value representing the horizontal. - vertical = An integer value representing the vertical. May have an additional qualifier such as 'i' or 'p'. - rate = An integer value representing the refresh rate. - HDR info = none hdr/ static hdr/ dynamic hdr - Color space = RGB / Ycbcr 444 /Ycbcr 422/Ycbcr 420 - DeepColor = 8 bit/10 bit /12 bit/ 16 bit	Command: GET VIDOUT_FORMAT out1<CR><LF> Return: VIDOUT_FORMAT out1 3840x2160,60;none hdr;rgb;8bit<CR><LF>
7	Get the audio format information of output	Command: GET AUDOUT_FORMAT in<CR><LF> Return: AUDOUT_FORMAT in prm<CR><LF> out = {out1,out2...out8}; prm = { } Description: Get the resolution of the video input prm = {<PCM / non-PCM>; <Sampling rate>}	Command: GET AUDOUT_FORMAT out1<CR><LF> Return: AUDOUT_FORMAT out1 PCM;48kHz<CR><LF>
8	Get hdcp version of output video	Command: GET VIDOUT_HDCP out<CR><LF> Return: VIDOUT_HDCP out prm<CR><LF> out = {out1, out2...out8}; prm = {no hdcp, hdcp1.4, hdcp2.2} Description: Get hdcp version of output video.	Command: GET VIDOUT_HDCP out1<CR><LF> Return: VIDOUT_HDCP out1 no hdcp<CR><LF>
Stretch			
1	Configure the HDMI output port for best fit and full settings	Command: SET VIDOUT_STRETCH out prm<CR><LF> Return: VIDOUT_STRETCH out prm<CR><LF> Parameter: out = {out1,out2...out8}; prm = {0, 1}; //0: full, 1: bestfit Description: Set Stretch Mode.	Command: SET VIDOUT_STRETCH out1 0<CR><LF> Return: VIDOUT_STRETCH out1 0<CR><LF> Description: Set out1's Stretch Mode to full

No.	Description	Command	Example
2	Retrieve the best fit and full configuration settings of the HDMI output port	Command: GET VIDOUT_STRETCH out prm<CR><LF> Return: VIDOUT_STRETCH out prm<CR><LF> Parameter: out = {out1,out2...out8}; prm = {0, 1}; //0: full, 1: bestfit Description: Get Stretch Mode.	Command: GET VIDOUT_STRETCH out1<CR><LF> Return: VIDOUT_STRETCH out1 0<CR><LF> Description: Get out1's Stretch Mode, the result is full.
Video Wall			
1	Set the video wall activation status	Command: SET VIDOUT_ACTIVE <output_id> <prm><CR><LF> Return: VIDOUT_ACTIVE <output_id> <prm><CR><LF> Parameter: <output_id> = Output identifier, such as vw1, vw2 <prm> = ON or OFF Description: Set the video wall activation status.	Command: SET VIDOUT_ACTIVE vw1 ON<CR><LF> Return: VIDOUT_ACTIVE vw1 ON<CR><LF> Description: Activate the video wall.
2	Get the video wall activation status	Command: GET VIDOUT_ACTIVE <output_id><CR><LF> Return: VIDOUT_ACTIVE <output_id> <prm><CR><LF> Parameter: <output_id> = Output identifier, such as vw1, vw2 <prm> = ON or OFF Description: Get the video wall activation status.	Command: GET VIDOUT_ACTIVE vw1<CR><LF> Return: VIDOUT_ACTIVE vw1 ON<CR><LF> Description: Get the video wall activation status, the result is on.
3	Set Video output layout	Command: SET VIDOUT_MODE <output_id> <scene><CR><LF> Return: VIDOUT_MODE <output_id> <scene><CR><LF> Parameter: <output_id> = Output identifier, such as vw1, vw2 <scene> = {layout1, layout2} Description: Set Video output layout.	Command: SET VIDOUT_MODE vw1 layout1<CR><LF> Return: VIDOUT_MODE vw1 layout1<CR><LF> Description: Set Video output layout to layout1.

No.	Description	Command	Example
4	Get Video output layout	Command: GET VIDOUT_MODE <output_id><CR><LF> Return: VIDOUT_MODE <output_id> <scene><CR><LF> Parameter: <output_id> = Output identifier, such as vw1, vw2 <scene> = {layout1, layout2} Description: Get Video output layout.	Command: GET VIDOUT_MODE vw1<CR><LF> Return: VIDOUT_MODE vw1 pip<CR><LF> Description: Get Video output layout, the result is pip.
5	Set the input sources for each window in the video wall	Command: SET VW_WIN_SRC <vwname> <layoutname> <winref> <sourcename> <winref1> <sourcename1> ...<CR><LF> Return: VW_WIN_SRC <vwname> <layoutname> <winref> <sourcename> <winref1> <sourcename1> ...<CR><LF> Parameter: <vwname> = video wall name, such as VW1, VW2 <layoutname> = layout name, such as layout1, layout2 <winref> = Window reference, which can be a name (e.g., win1), a coordinate format XY (e.g., 12 for the panel in row 1, column 2), or the corresponding output port (outx) <sourcename> = { in1 ~ in8} Description: Set the input sources for each window in the video wall.	Command: SET VW_WIN_SRC VW1 layout1 win1 in1 11 in2 out3 in3<CR><LF> Return: VW_WIN_SRC VW1 layout1 win1 in1 11 in2 out3 in3<CR><LF> Description: Set the input sources for each window in the video wall.
6	Obtain the input sources of each window in the video wall	Command: GET VW_WIN_SRC <vwname> <layoutname> <winref> <winref1> ...<CR><LF> Return: VW_WIN_SRC <vwname> <layoutname> <winref> <sourcename> <winref1> <sourcename1> ...<CR><LF> Parameter: <vwname> = video wall name, such as VW1, VW2 <layoutname> = layout name, such as layout1, layout2 <winref> = Window reference, which can be a name (e.g., win1), a coordinate format XY (e.g., 12 for the panel in row 1, column 2), or the corresponding output port (outx) <sourcename> = { in1 ~ in8} Description: Get the input sources of each window in the video wall.	Command: GET VW_WIN_SRC VW1 layout1 win1 11 in2 out3<CR><LF> Return: VW_WIN_SRC VW1 layout1 win1 in1 11 in2 out3 in3<CR><LF> Description: Get the input sources for each window in the video wall.

No.	Description	Command	Example
Multiview			
1	Set the activation status of the multiview	Command: SET VIDOUT_ACTIVE <output_id> <prm><CR><LF> Return: VIDOUT_ACTIVE <output_id> <prm><CR><LF> Parameter: <output_id> = mv1 <prm> = ON or OFF Description: Set the activation status of the multiview.	Command: SET VIDOUT_ACTIVE mv1 ON<CR><LF> Return: VIDOUT_ACTIVE mv1 ON<CR><LF> Description: Set the activation status of the multiview to open
2	Get the activation status of the multiview	Command: GET VIDOUT_ACTIVE <output_id><CR><LF> Return: VIDOUT_ACTIVE <output_id> <prm><CR><LF> Parameter: <output_id> = mv1 <prm> = ON or OFF Description: Get the activation status of the multiview.	Command: GET VIDOUT_ACTIVE mv1<CR><LF> Return: VIDOUT_ACTIVE mv1 ON<CR><LF> Description: Get the activation status of the multiview, the result is on.
3	Set current Multiview's mode	Command: SET VIDOUT_MODE <output_id> <scene><CR><LF> Return: VIDOUT_MODE <output_id> <scene><CR><LF> Parameter: <output_id> = mv1 <scene> = {FULL_SCREEN, DUAL_VIEW, PIP, PYRAMID, 1LEFT_3RIGHT, QUAD} Description: Set current Multiview's mode	Command: SET VIDOUT_MODE mv1 pip<CR><LF> Return: VIDOUT_MODE mv1 pip<CR><LF> Description: Set current Multiview's mode to pip.
4	Get current Multiview's mode	Command: GET VIDOUT_MODE <output_id><CR><LF> Return: VIDOUT_MODE <output_id> <scene><CR><LF> Parameter: <output_id> = mv1 <scene> = {FULL_SCREEN, DUAL_VIEW, PIP, PYRAMID, 1LEFT_3RIGHT, QUAD} Description: Get current Multiview's mode.	Command: GET VIDOUT_MODE mv1<CR><LF> Return: VIDOUT_MODE mv1 pip<CR><LF> Description: Get current Multiview's mode, the result is pip

No.	Description	Command	Example
5	Set the input sources for each window in the multiview	Command: SET MV_WIN_SRC <output_id> <scene> <win1> <src1> ... <winN> <srcN><CR><LF> Return: MV_WIN_SRC <output_id> <scene> <win1> <src1> ... <winN> <srcN><CR><LF> Parameter: <output_id> = mv1 <scene> = {FULL_SCREEN, DUAL_VIEW, PIP, PYRAMID, 1LEFT_3RIGHT, QUAD} <winN> = window number, such as win1 <srcN> = { in1 ~ in8} Description: Set the input sources for each window in the multiview.	Command: SET MV_WIN_SRC MV1 pip win1 in1 win2 in3<CR><LF> Return: MV_WIN_SRC MV1 pip win1 in1 win2 in3<CR><LF> Description: Set the input sources for each window in the multiview
6	Obtain the input sources of each window in the multiview	Command: GET MV_WIN_SRC <output_id> <scene><CR><LF> Return: MV_WIN_SRC <output_id> <scene> <win1> <src1> ... <winN> <srcN><CR><LF> Parameter: <output_id> = mv1 <scene> = {FULL_SCREEN, DUAL_VIEW, PIP, PYRAMID, 1LEFT_3RIGHT, QUAD} <winN> = window number, such as win1 <srcN> = { in1 ~ in8} Description: Get the input sources for each window in the multiview.	Command: GET MV_WIN_SRC MV1 pip<CR><LF> Return: MV_WIN_SRC MV1 pip win1 in1 win2 in3<CR><LF> Description: Get the input sources for each window in the multiview.
7	Set audio input of multiview	Command: SET MV_AUDIO_SW <output_id> <scene> <audio_mode> <source><CR><LF> Return: MV_AUDIO_SW <output_id> <scene> <audio_mode> <source><CR><LF> Parameter: <output_id> = mv1 <scene> = {FULL_SCREEN, DUAL_VIEW, PIP, PYRAMID, 1LEFT_3RIGHT, QUAD} <audio_mode> = {WINDOW} <source> = audio_mode=in WINDOW mode, source is the window name, such as win1 Description: Set the audio input of multiview to window mode, and set audio input source.	Command: SET MV_AUDIO_SW MV1 pip WINDOW win1<CR><LF> Return: MV_AUDIO_SW MV1 pip WINDOW win1<CR><LF> Description: Set the audio input in multiview mode to window mode, with WIN1 as the source

No.	Description	Command	Example
8	Obtain audio input in multiview	Command: GET MV_AUDIO_SW <output_id> <scene><CR><LF> Return: MV_AUDIO_SW <output_id> <scene> <audio_mode> <source><CR><LF> Parameter: <output_id> = mv1 <scene> = {FULL_SCREEN, DUAL_VIEW, PIP, PYRAMID, 1LEFT_3RIGHT, QUAD} <audio_mode> = {WINDOW} <source> = audio_mode=in WINDOW mode, source is the window name, such as win1 Description: Obtain audio input in multiview.	Command: GET MV_AUDIO_SW MV1 pip<CR><LF> Return: MV_AUDIO_SW MV1 pip WINDOW win1<CR><LF> Description: Obtain audio input in multiview, the result is win1.
9	Set the ratio between the small window and the main window in PIP mode	Command: SET VIDOUT_PIP_SIZE prm <CR><LF> Return: VIDOUT_PIP_SIZE prm <CR><LF> Parameter: prm = {0, 1, 2} // 0: 1/4 // 1: 1/9 // 2: 1/16 Description: Set pip small window size	Command: SET VIDOUT_PIP_SIZE 0 <CR><LF> Return: VIDOUT_PIP_SIZE 0 <CR><LF> Description: Set the ratio between the small window and the main window in PIP mode to 0.
10	Get the ratio between the small window and the main window in PIP mode	Command: GET VIDOUT_PIP_SIZE <CR><LF> Return: VIDOUT_PIP_SIZE prm <CR><LF> Parameter: prm = {0, 1, 2} // 0: 1/4 // 1: 1/9 // 2: 1/16 Description: Set pip small window size	Command: GET VIDOUT_PIP_SIZE<CR><LF> Return: VIDOUT_PIP_SIZE 0 <CR><LF> Description: Set the ratio between the small window and the main window in PIP mode, the result is 0.
11	Set the small window position in PIP mode	Command: SET VIDOUT_PIP_POS prm<CR><LF> Return: VIDOUT_PIP_POS prm <CR><LF> Parameter: prm = {0, 1, 2, 3} // 0: top of the left // 1: top of the right // 2: bottom of the left // 3: bottom of the right Description: Set the small window position in PIP mode.	Command: SET VIDOUT_PIP_POS 0 <CR><LF> Return: VIDOUT_PIP_POS 0 <CR><LF> Description: Set the small window position in PIP mode.

No.	Description	Command	Example
12	Get the small window position in pip mode	Command: GET VIDOUT_PIP_POS<CR><LF> Return: VIDOUT_PIP_POS prm <CR><LF> Parameter: prm = {0,1, 2, 3} // 0: top of the left // 1: top of the right // 2: bottom of the left // 3: bottom of the right Description: Get the small window position in pip mode.	Command: GET VIDOUT_PIP_POS <CR><LF> Return: VIDOUT_PIP_POS 0 <CR><LF> Description: Get the small window position in pip mode, the result is 0 (top of the left).
13	Set the mute status of the audio source of the window for multiview audio output	Command: SET AUDOUT_WND_MUTE prm <CR><LF> Return: AUDOUT_WND_MUTE prm<CR><LF> Parameter: prm = {on, off} Description: Set the mute status of the audio source of the window for multiview audio output.	Command: SET AUDOUT_WND_MUTE on<CR><LF> Return: AUDOUT_WND_MUTE on<CR><LF> Description: Set the audio source of the window for multiview audio output to mute.
14	Get the mute status of the audio source of the window for multiview audio output	Command: GET AUDOUT_WND_MUTE <CR><LF> Return: AUDOUT_WND_MUTE prm<CR><LF> Parameter: prm = {on, off} Description: Get the mute status of the audio source of the window for multiview audio output.	Command: GET AUDOUT_WND_MUTE <CR><LF> Return: AUDOUT_WND_MUTE off<CR><LF> Description: Get the mute status of the audio source of the window for multiview audio output, the result is off.