

Telnet API commands for the MX0404-N301 matrix switcher

DEVICE API Reference

Telnet API commands for the MX0404-N301 matrix switcher

Table of Contents

- Switch / Get
- Switch / Set
- Audio Mute / Get
- Audio Mute / Set
- Audio Switch Mode / Get
- Audio Switch Mode / Set
- AV Mute / Get
- AV Mute / Set
- CEC Power
- CEC Auto / Get
- CEC Auto / Set
- CEC Delay / Get
- CEC Delay / Set
- Input HDCP Support / Get
- Input HDCP Support / Set
- Output HDCP Mode / Get
- Output HDCP Mode / Set
- EDID / Get
- EDID / Set
- EDID Write
- EDID Read
- Preset / Save
- Preset / Restore
- IR System Code / Get
- IR System Code / Set
- IP Address / Get
- IP Address / Set
- Network Mode / Get
- Network Mode / Set

- Standby / Get
- Standby / Set
- Input Status / Connection
- Input Status / Signal
- Input Status / Format
- Input Status / HDCP
- Input Status / Stretch / Get
- Input Status / Stretch / Set
- Output Status / Connection
- Output Status / Signal
- Output Status / Video Format
- Output Status / Audio Format
- Output Status / HDCP
- Output Status / Scaling / Get
- Output Status / Scaling / Set
- Output Status / Resolution / Get
- Output Status / Resolution / Set
- Output Status / Forced SDR / Get
- Output Status / Forced SDR / Set
- Output Status / Active / Get
- Output Status / Active / Set
- Output Status / Mode / Get
- Output Status / Mode / Set
- Videowall Window Source / Get
- Videowall Window Source / Set
- Multiview Window Source / Get
- Multiview Window Source / Set
- Multiview Audio Switch / Get
- Multiview Audio Switch / Set
- Multiview Window Border / Get
- Multiview Window Border / Set
- Multiview Window Border Attr / Get
- Multiview Window Border Attr / Set
- Legacy Multiview / Layout / Get
- Legacy Multiview / Layout / Set
- Legacy Multiview / Dual Source / Get
- Legacy Multiview / Dual Source / Set
- Legacy Multiview / Pip Source / Get

- Legacy Multiview / Pip Source / Set
- Legacy Multiview / Quad Source / Get
- Legacy Multiview / Quad Source / Set
- Legacy Multiview / Master Source / Get
- Legacy Multiview / Master Source / Set
- Legacy Multiview / Pip Size / Get
- Legacy Multiview / Pip Size / Set
- Legacy Multiview / Pip Position / Get
- Legacy Multiview / Pip Position / Set
- Legacy Videowall / Wall Map / Get
- Legacy Videowall / Wall Map / Set
- Legacy Videowall / Mode / Get
- Legacy Videowall / Mode / Set
- Legacy Videowall / Bezel / Get
- Legacy Videowall / Bezel / Set
- Legacy Videowall / Rotation / Get
- Legacy Videowall / Rotation / Set
- Audio Follow Window / Get
- Audio Follow Window / Set
- System / Firmware Version
- System / Hardware Version
- System / Factory Reset
- System / Reboot
- System / API Help

Command Reference

Switch / Get

- **Command:** GET MP
- **Syntax:** GET MP <output|all>
- **Description:** Get the input mapping for one output or all outputs
- **Parameters:** output
- **Response Type:** string
mapping: string

Switch / Set

- **Command:** SET SW
- **Syntax:** SET SW <input> <output|all>
- **Description:** Route one input to one output or to all outputs
- **Parameters:** input, output
- **Response Type:** confirmation


```
input: string
output: string
```

Audio Mute / Get

- **Command:** GET AUDIO_MUTE
- **Syntax:** GET AUDIO_MUTE <zone>
- **Description:** Get the mute state for an analog audio zone
- **Parameters:** zone
- **Response Type:** string


```
zone: string
state: string
```

Audio Mute / Set

- **Command:** SET AUDIO_MUTE
- **Syntax:** SET AUDIO_MUTE <zone> <on|off>
- **Description:** Mute or unmute an analog audio zone
- **Parameters:** zone, state
- **Response Type:** confirmation


```
zone: string
state: string
```

Audio Switch Mode / Get

- **Command:** GET AUDIOSW_M
- **Syntax:** GET AUDIOSW_M <out1|out2|all>
- **Description:** Get the audio switching mode for one or all audio-follow outputs
- **Parameters:** output
- **Response Type:** string


```
output: string
mode: string
```

Audio Switch Mode / Set

- **Command:** SET AUDIOSW_M
- **Syntax:** SET AUDIOSW_M <out1|out2|all> <independent|followvm>
- **Description:** Set the audio switching mode for one or all audio-follow outputs
- **Parameters:** output, mode
- **Response Type:** confirmation
 - output: string
 - mode: string

AV Mute / Get

- **Command:** GET AVMUTE
- **Syntax:** GET AVMUTE <output>
- **Description:** Get the AV mute state on an HDMI output
- **Parameters:** output
- **Response Type:** string
 - output: string
 - state: string

AV Mute / Set

- **Command:** SET AVMUTE
- **Syntax:** SET AVMUTE <output> <on|off>
- **Description:** Enable or disable AV mute on an HDMI output
- **Parameters:** output, state
- **Response Type:** confirmation
 - output: string
 - state: string

CEC Power

- **Command:** SET CEC_PWR
- **Syntax:** SET CEC_PWR <output|all> <on|off>
- **Description:** Send a CEC power command to one or all sinks
- **Parameters:** output, state
- **Response Type:** confirmation
 - output: string
 - state: string

CEC Auto / Get

- **Command:** GET AUTOCEC_FN
- **Syntax:** GET AUTOCEC_FN <output|all>
- **Description:** Get the automatic CEC power state
- **Parameters:** output
- **Response Type:** string
 - output: string
 - state: string

CEC Auto / Set

- **Command:** SET AUTOCEC_FN
- **Syntax:** SET AUTOCEC_FN <output|all> <on|off>
- **Description:** Enable or disable automatic CEC power behavior
- **Parameters:** output, state
- **Response Type:** confirmation
 - output: string
 - state: string

CEC Delay / Get

- **Command:** GET AUTOCEC_D
- **Syntax:** GET AUTOCEC_D <output|all>
- **Description:** Get the automatic CEC power-off delay
- **Parameters:** output
- **Response Type:** string
 - output: string
 - minutes: integer

CEC Delay / Set

- **Command:** SET AUTOCEC_D
- **Syntax:** SET AUTOCEC_D <output|all> <minutes>
- **Description:** Set the automatic CEC power-off delay
- **Parameters:** output, minutes
- **Response Type:** confirmation
 - output: string
 - minutes: integer

Input HDCP Support / Get

- **Command:** GET HDCP_S
- **Syntax:** GET HDCP_S <input|all>
- **Description:** Get the HDCP support state for one or all inputs
- **Parameters:** input
- **Response Type:** string


```
input: string
state: string
```

Input HDCP Support / Set

- **Command:** SET HDCP_S
- **Syntax:** SET HDCP_S <input|all> <on|off>
- **Description:** Enable or disable HDCP support on one or all inputs
- **Parameters:** input, state
- **Response Type:** confirmation


```
input: string
state: string
```

Output HDCP Mode / Get

- **Command:** GET HDCP
- **Syntax:** GET HDCP <output|all>
- **Description:** Get the HDCP mode for one or all outputs
- **Parameters:** output
- **Response Type:** string


```
output: string
mode: string
```

Output HDCP Mode / Set

- **Command:** SET HDCP
- **Syntax:** SET HDCP <output|all> <follow|auto|hdc1.x|off>
- **Description:** Set the HDCP mode for one or all outputs
- **Parameters:** output, mode
- **Response Type:** confirmation


```
output: string
mode: string
```

EDID / Get

- **Command:** GET EDID
- **Syntax:** GET EDID <input|all>
- **Description:** Get the EDID preset assigned to one input or all inputs
- **Parameters:** input
- **Response Type:** string


```
edid: string
```

EDID / Set

- **Command:** SET EDID
- **Syntax:** SET EDID <input|all> <profile>
- **Description:** Assign an EDID preset to one or all inputs
- **Parameters:** input, profile
- **Response Type:** confirmation


```
input: string
profile: integer
```

EDID Write

- **Command:** SET EDID_W
- **Syntax:** SET EDID_W <input|all> <block0|block1> <hex_data>
- **Description:** Write EDID block data to an input
- **Parameters:** input, block, hex_data
- **Response Type:** confirmation


```
input: string
block: string
status: string
```

EDID Read

- **Command:** GET EDID_R
- **Syntax:** GET EDID_R <output>
- **Description:** Read EDID block data from an output
- **Parameters:** output
- **Response Type:** string


```
output: string
block: string
data: string
```

Preset / Save

- **Command:** SAVE PRESET
- **Syntax:** SAVE PRESET <slot>
- **Description:** Save the current routing state to a preset slot
- **Parameters:** slot
- **Response Type:** confirmation
slot: integer

Preset / Restore

- **Command:** RESTORE PRESET
- **Syntax:** RESTORE PRESET <slot>
- **Description:** Recall a stored preset slot
- **Parameters:** slot
- **Response Type:** confirmation
slot: integer

IR System Code / Get

- **Command:** GET IR_SC
- **Syntax:** GET IR_SC
- **Description:** Get the current IR system code
- **Parameters:** None
- **Response Type:** string
mode: string

IR System Code / Set

- **Command:** SET IR_SC
- **Syntax:** SET IR_SC <all|mode1|mode2>
- **Description:** Set the IR system code
- **Parameters:** mode
- **Response Type:** confirmation
mode: string

IP Address / Get

- **Command:** GET IPADDR
- **Syntax:** GET IPADDR

- **Description:** Get the current IP address, mask, and gateway
- **Parameters:** None
- **Response Type:** string

```
ip: string
mask: string
gateway: string
```

IP Address / Set

- **Command:** SET IPADDR
- **Syntax:** SET IPADDR <ip> MASK <mask> GATEWAY <gateway>
- **Description:** Set the static IP address values
- **Parameters:** ip, mask, gateway
- **Response Type:** confirmation

```
ip: string
mask: string
gateway: string
```

Network Mode / Get

- **Command:** GET NETCFG MODE
- **Syntax:** GET NETCFG MODE
- **Description:** Get the network configuration mode
- **Parameters:** None
- **Response Type:** string

```
mode: string
```

Network Mode / Set

- **Command:** SET NETCFG MODE
- **Syntax:** SET NETCFG MODE <DHCP|STATIC>
- **Description:** Set the network configuration mode
- **Parameters:** mode
- **Response Type:** confirmation

```
mode: string
```

Standby / Get

- **Command:** GET STANDBY
- **Syntax:** GET STANDBY

- **Description:** Get the current standby state
- **Parameters:** None
- **Response Type:** string
state: string

Standby / Set

- **Command:** STANDBY / WAKE
- **Syntax:** STANDBY | WAKE
- **Description:** Put the unit into standby or wake it
- **Parameters:** None
- **Response Type:** confirmation
state: string

Input Status / Connection

- **Command:** GET VIDIN_CONNECT
- **Syntax:** GET VIDIN_CONNECT <input>
- **Description:** Get whether an input is physically connected
- **Parameters:** input
- **Response Type:** string
input: string
state: string

Input Status / Signal

- **Command:** GET VIDIN_SIG
- **Syntax:** GET VIDIN_SIG <input>
- **Description:** Get whether an input has a valid signal
- **Parameters:** input
- **Response Type:** string
input: string
state: string

Input Status / Format

- **Command:** GET VIDIN_FORMAT
- **Syntax:** GET VIDIN_FORMAT <input>
- **Description:** Get the video format details for an input

- **Parameters:** input
- **Response Type:** string
 - input: string
 - format: string

Input Status / HDCP

- **Command:** GET VIDIN_HDCP
- **Syntax:** GET VIDIN_HDCP <input>
- **Description:** Get the negotiated HDCP version on an input
- **Parameters:** input
- **Response Type:** string
 - input: string
 - hdcv: string

Input Status / Stretch / Get

- **Command:** GET VIDIN_STRETCH
- **Syntax:** GET VIDIN_STRETCH <input>
- **Description:** Get the legacy input stretch mode
- **Parameters:** input
- **Response Type:** string
 - input: string
 - mode: string

Input Status / Stretch / Set

- **Command:** SET VIDIN_STRETCH
- **Syntax:** SET VIDIN_STRETCH <input> <origin|full>
- **Description:** Set the legacy input stretch mode
- **Parameters:** input, mode
- **Response Type:** confirmation
 - input: string
 - mode: string

Output Status / Connection

- **Command:** GET VIDOUT_CONNECT
- **Syntax:** GET VIDOUT_CONNECT <output>
- **Description:** Get whether an output is physically connected
- **Parameters:** output

- **Response Type:** string

output: string
state: string

Output Status / Signal

- **Command:** GET VIDOUT_SIG
- **Syntax:** GET VIDOUT_SIG <output>
- **Description:** Get whether an output has a valid signal
- **Parameters:** output
- **Response Type:** string
output: string
state: string

Output Status / Video Format

- **Command:** GET VIDOUT_FORMAT
- **Syntax:** GET VIDOUT_FORMAT <output>
- **Description:** Get the video format details for an output
- **Parameters:** output
- **Response Type:** string
output: string
format: string

Output Status / Audio Format

- **Command:** GET AUDOUT_FORMAT
- **Syntax:** GET AUDOUT_FORMAT <output>
- **Description:** Get the audio format details for an output
- **Parameters:** output
- **Response Type:** string
output: string
format: string

Output Status / HDCP

- **Command:** GET VIDOUT_HDCP
- **Syntax:** GET VIDOUT_HDCP <output>
- **Description:** Get the negotiated HDCP version on an output
- **Parameters:** output

- **Response Type:** string

output: string
hdcp: string

Output Status / Scaling / Get

- **Command:** GET VIDOUT_SCALE
- **Syntax:** GET VIDOUT_SCALE <output|all>
- **Description:** Get the output scaler mode
- **Parameters:** output
- **Response Type:** string
output: string
mode: string

Output Status / Scaling / Set

- **Command:** SET VIDOUT_SCALE
- **Syntax:** SET VIDOUT_SCALE <output|all> <auto|manual|bypass>
- **Description:** Set the output scaler mode
- **Parameters:** output, mode
- **Response Type:** confirmation
output: string
mode: string

Output Status / Resolution / Get

- **Command:** GET VIDOUT_RES
- **Syntax:** GET VIDOUT_RES <output|all>
- **Description:** Get the configured output resolution
- **Parameters:** output
- **Response Type:** string
output: string
resolution: string

Output Status / Resolution / Set

- **Command:** SET VIDOUT_RES
- **Syntax:** SET VIDOUT_RES <output|all> <resolution>
- **Description:** Set the output resolution when scaling is manual
- **Parameters:** output, resolution
- **Response Type:** confirmation

```
output: string
resolution: string
```

Output Status / Forced SDR / Get

- **Command:** GET FORCED_SDR
- **Syntax:** GET FORCED_SDR <output>
- **Description:** Get the forced SDR state of an output
- **Parameters:** output
- **Response Type:** string

```
output: string
state: string
```

Output Status / Forced SDR / Set

- **Command:** SET FORCED_SDR
- **Syntax:** SET FORCED_SDR <output> <on|off>
- **Description:** Enable or disable forced SDR on an output
- **Parameters:** output, state
- **Response Type:** confirmation

```
output: string
state: string
```

Output Status / Active / Get

- **Command:** GET VIDOUT_ACTIVE
- **Syntax:** GET VIDOUT_ACTIVE <mv1|vw1|vw2|vw3>
- **Description:** Get whether a multiview or videowall profile is active
- **Parameters:** output_id
- **Response Type:** string

```
output_id: string
state: string
```

Output Status / Active / Set

- **Command:** SET VIDOUT_ACTIVE
- **Syntax:** SET VIDOUT_ACTIVE <mv1|vw1|vw2|vw3> <ON|OFF>
- **Description:** Enable or disable a multiview or videowall profile
- **Parameters:** output_id, state
- **Response Type:** confirmation

```
output_id: string
state: string
```

Output Status / Mode / Get

- **Command:** GET VIDOUT_MODE
- **Syntax:** GET VIDOUT_MODE [output_id]
- **Description:** Get the scene summary or the scene for one multiview or videowall profile
- **Parameters:** output_id
- **Response Type:** string

```
output_id: string
scene: string
```

Output Status / Mode / Set

- **Command:** SET VIDOUT_MODE
- **Syntax:** SET VIDOUT_MODE <output_id> <scene>
- **Description:** Set the active multiview or videowall scene
- **Parameters:** output_id, scene
- **Response Type:** confirmation

```
output_id: string
scene: string
```

Videowall Window Source / Get

- **Command:** GET VW_WIN_SRC
- **Syntax:** GET VW_WIN_SRC <vw> <layout> [window_refs...]
- **Description:** Get source assignments for a videowall layout
- **Parameters:** videowall, layout, window_refs
- **Response Type:** string

```
videowall: string
layout: string
mapping: string
```

Videowall Window Source / Set

- **Command:** SET VW_WIN_SRC
- **Syntax:** SET VW_WIN_SRC <vw> <layout> <winref1> <src1> [<winref2> <src2> ...]
- **Description:** Assign sources to windows in a videowall layout
- **Parameters:** videowall, layout, window_source_pairs
- **Response Type:** confirmation

```
videowall: string
```


layout: string
mapping: string

Multiview Window Source / Get

- **Command:** GET MV_WIN_SRC
- **Syntax:** GET MV_WIN_SRC <mv> <scene>
- **Description:** Get source assignments for a multiview scene
- **Parameters:** multiview, scene
- **Response Type:** string

multiview: string
scene: string
mapping: string

Multiview Window Source / Set

- **Command:** SET MV_WIN_SRC
- **Syntax:** SET MV_WIN_SRC <mv> <scene> <win1> <src1> [<win2> <src2> ...]
- **Description:** Assign sources to windows in a multiview scene
- **Parameters:** multiview, scene, window_source_pairs
- **Response Type:** confirmation

multiview: string
scene: string
mapping: string

Multiview Audio Switch / Get

- **Command:** GET MV_AUDIO_SW
- **Syntax:** GET MV_AUDIO_SW <mv> <scene>
- **Description:** Get multiview audio routing
- **Parameters:** multiview, scene
- **Response Type:** string

multiview: string
scene: string
audio_mode: string
source: string

Multiview Audio Switch / Set

- **Command:** SET MV_AUDIO_SW
- **Syntax:** SET MV_AUDIO_SW <mv> <scene> <WINDOW|INDEPENDENT> <source>
- **Description:** Set multiview audio routing

- **Parameters:** multiview, scene, audio_mode, source
- **Response Type:** confirmation

```
multiview: string
scene: string
audio_mode: string
source: string
```

Multiview Window Border / Get

- **Command:** GET MV_WIN_BORDER_FN
- **Syntax:** GET MV_WIN_BORDER_FN <output_id> <scene>
- **Description:** Get border enable states for a scene
- **Parameters:** output_id, scene
- **Response Type:** string

```
output_id: string
scene: string
borders: string
```

Multiview Window Border / Set

- **Command:** SET MV_WIN_BORDER_FN
- **Syntax:** SET MV_WIN_BORDER_FN <output_id> <scene> <win1> <ON|OFF> [<win2> <ON|OFF> ...]
- **Description:** Enable or disable borders on one or more windows
- **Parameters:** output_id, scene, window_state_pairs
- **Response Type:** confirmation

```
output_id: string
scene: string
borders: string
```

Multiview Window Border Attr / Get

- **Command:** GET MV_WIN_BORDER_ATTR
- **Syntax:** GET MV_WIN_BORDER_ATTR <output_id> <scene> [window_ref]
- **Description:** Get border color and width for a scene or one window
- **Parameters:** output_id, scene, window_ref
- **Response Type:** string

```
output_id: string
scene: string
borders: string
```

Multiview Window Border Attr / Set

- **Command:** SET MV_WIN_BORDER_ATTR
- **Syntax:** SET MV_WIN_BORDER_ATTR <output_id> <scene> <win1> <color;width> [<win2> <color;width> ...]
- **Description:** Set border color and width for one or more windows
- **Parameters:** output_id, scene, window_attr_pairs
- **Response Type:** confirmation


```
output_id: string
scene: string
borders: string
```

Legacy Multiview / Layout / Get

- **Command:** GET VIDOUT_MODE
- **Syntax:** GET VIDOUT_MODE
- **Description:** Get the legacy global multiview layout mode
- **Parameters:** None
- **Response Type:** string


```
mode: string
```

Legacy Multiview / Layout / Set

- **Command:** SET VIDOUT_MODE
- **Syntax:** SET VIDOUT_MODE <0|1|2|4|5>
- **Description:** Set the legacy global multiview layout mode
- **Parameters:** mode
- **Response Type:** confirmation


```
mode: integer
```

Legacy Multiview / Dual Source / Get

- **Command:** GET VIDOUT_DUAL_SRC
- **Syntax:** GET VIDOUT_DUAL_SRC
- **Description:** Get the legacy dual-view source assignment
- **Parameters:** None
- **Response Type:** string


```
sources: string
```

Legacy Multiview / Dual Source / Set

- **Command:** SET VIDOUT_DUAL_SRC
- **Syntax:** SET VIDOUT_DUAL_SRC <left_input> <right_input>

- **Description:** Set the legacy dual-view source assignment
- **Parameters:** left_input, right_input
- **Response Type:** confirmation
sources: string

Legacy Multiview / Pip Source / Get

- **Command:** GET VIDOUT_PIP_SRC
- **Syntax:** GET VIDOUT_PIP_SRC
- **Description:** Get the legacy PIP source assignment
- **Parameters:** None
- **Response Type:** string
sources: string

Legacy Multiview / Pip Source / Set

- **Command:** SET VIDOUT_PIP_SRC
- **Syntax:** SET VIDOUT_PIP_SRC <main_input> <pip_input>
- **Description:** Set the legacy PIP source assignment
- **Parameters:** main_input, pip_input
- **Response Type:** confirmation
sources: string

Legacy Multiview / Quad Source / Get

- **Command:** GET VIDOUT_QUAD_SRC
- **Syntax:** GET VIDOUT_QUAD_SRC
- **Description:** Get the legacy quad-view source assignment
- **Parameters:** None
- **Response Type:** string
sources: string

Legacy Multiview / Quad Source / Set

- **Command:** SET VIDOUT_QUAD_SRC
- **Syntax:** SET VIDOUT_QUAD_SRC <tl> <tr> <bl>

- **Description:** Set the legacy quad-view source assignment
- **Parameters:** top_left, top_right, bottom_left, bottom_right
- **Response Type:** confirmation
sources: string

Legacy Multiview / Master Source / Get

- **Command:** GET VIDOUT_MASTER_SRC
- **Syntax:** GET VIDOUT_MASTER_SRC
- **Description:** Get the legacy master-view source assignment
- **Parameters:** None
- **Response Type:** string
sources: string

Legacy Multiview / Master Source / Set

- **Command:** SET VIDOUT_MASTER_SRC
- **Syntax:** SET VIDOUT_MASTER_SRC <left> <top_right> <middle_right> <bottom_right>
- **Description:** Set the legacy master-view source assignment
- **Parameters:** left, top_right, middle_right, bottom_right
- **Response Type:** confirmation
sources: string

Legacy Multiview / Pip Size / Get

- **Command:** GET VIDOUT_PIP_SIZE
- **Syntax:** GET VIDOUT_PIP_SIZE
- **Description:** Get the legacy PIP window size
- **Parameters:** None
- **Response Type:** string
size: integer

Legacy Multiview / Pip Size / Set

- **Command:** SET VIDOUT_PIP_SIZE
- **Syntax:** SET VIDOUT_PIP_SIZE <0|1|2>
- **Description:** Set the legacy PIP window size
- **Parameters:** size
- **Response Type:** confirmation
size: integer

Legacy Multiview / Pip Position / Get

- **Command:** GET VIDOUT_PIP_POS
- **Syntax:** GET VIDOUT_PIP_POS
- **Description:** Get the legacy PIP window position
- **Parameters:** None
- **Response Type:** string
position: integer

Legacy Multiview / Pip Position / Set

- **Command:** SET VIDOUT_PIP_POS
- **Syntax:** SET VIDOUT_PIP_POS <0|1|2|3>
- **Description:** Set the legacy PIP window position
- **Parameters:** position
- **Response Type:** confirmation
position: integer

Legacy Videowall / Wall Map / Get

- **Command:** GET VIDWALL
- **Syntax:** GET VIDWALL
- **Description:** Get the legacy videowall source and output tile map
- **Parameters:** None
- **Response Type:** string
mapping: string

Legacy Videowall / Wall Map / Set

- **Command:** SET VIDWALL
- **Syntax:** SET VIDWALL <input> <top_left> <top_right> <bottom_left> <bottom_right>
- **Description:** Set the legacy videowall source and output tile map
- **Parameters:** input, top_left, top_right, bottom_left, bottom_right
- **Response Type:** confirmation
mapping: string

Legacy Videowall / Mode / Get

- **Command:** GET VIDMODE
- **Syntax:** GET VIDMODE
- **Description:** Get the legacy global video mode

- **Parameters:** None
- **Response Type:** string
mode: string

Legacy Videowall / Mode / Set

- **Command:** SET VIDMODE
- **Syntax:** SET VIDMODE <Matrix|Videowall|MultiView>
- **Description:** Set the legacy global video mode
- **Parameters:** mode
- **Response Type:** confirmation
mode: string

Legacy Videowall / Bezel / Get

- **Command:** GET VIDWALLBEZEL
- **Syntax:** GET VIDWALLBEZEL
- **Description:** Get the legacy videowall bezel compensation values
- **Parameters:** None
- **Response Type:** string
bezel: string

Legacy Videowall / Bezel / Set

- **Command:** SET VIDWALLBEZEL
- **Syntax:** SET VIDWALLBEZEL <vw> <ow> <vh> <oh>
- **Description:** Set the legacy videowall bezel compensation values
- **Parameters:** view_width, outer_width, view_height, outer_height
- **Response Type:** confirmation
bezel: string

Legacy Videowall / Rotation / Get

- **Command:** GET VIDWALL_ROTATION
- **Syntax:** GET VIDWALL_ROTATION <output>
- **Description:** Get legacy 180-degree rotation for one output
- **Parameters:** output
- **Response Type:** string
output: string
state: string

Legacy Videowall / Rotation / Set

- **Command:** SET VIDWALL_ROTATION
- **Syntax:** SET VIDWALL_ROTATION <output> <enable|disable>
- **Description:** Set legacy 180-degree rotation for one output
- **Parameters:** output, state
- **Response Type:** confirmation
 - output: string
 - state: string

Audio Follow Window / Get

- **Command:** GET AUDOUT_WND
- **Syntax:** GET AUDOUT_WND
- **Description:** Get the legacy audio-follow window source
- **Parameters:** None
- **Response Type:** string
 - input: string

Audio Follow Window / Set

- **Command:** SET AUDOUT_WND
- **Syntax:** SET AUDOUT_WND <input>
- **Description:** Set the legacy audio-follow window source
- **Parameters:** input
- **Response Type:** confirmation
 - input: string

System / Firmware Version

- **Command:** GET VER
- **Syntax:** GET VER
- **Description:** Get the firmware version
- **Parameters:** None
- **Response Type:** string
 - firmware: string

System / Hardware Version

- **Command:** GET HW_VER
- **Syntax:** GET HW_VER
- **Description:** Get the hardware version
- **Parameters:** None
- **Response Type:** string
hardware: string

System / Factory Reset

- **Command:** RESET
- **Syntax:** RESET
- **Description:** Restore the unit to factory defaults
- **Parameters:** None
- **Response Type:** confirmation

System / Reboot

- **Command:** REBOOT
- **Syntax:** REBOOT
- **Description:** Reboot the unit
- **Parameters:** None
- **Response Type:** confirmation

System / API Help

- **Command:** help
- **Syntax:** help
- **Description:** Print the device command list
- **Parameters:** None
- **Response Type:** string
commands: string