

MX0808-1022-000

8x8 HDMI Matrix with Analog and Digital Audio Outputs

API Command Set

Version: V1.0.1

RS232 Default Setting

Parameters	Value
Baud Rate	9600 bps
Data bits	8 bits
Parity	None
Stop bits	1 bit
Flow control	None

About Telnet Connection

Before the process of sending the telnet command, shall make telnet connection to the corresponding device.

The form of telnet command is as follow:

telnet ip (port)

ip: The unit's IP address. Suppose the IP address of the matrix is 192.168.11.143.

port: The unit's port number, this is non-required on some Telnet control tools or platforms. If required, port number is 23 by default.

Example: If the unit's IP address is 192.168.11.143, the telnet command is *telnet 192.168.11.143*

Command

Take Command *SET SW in out<CR><LF>* as an example:

1. *[SET SW]* denotes command key words, case insensitive.
2. *[in out]* denotes parameters, case insensitive; incorrect parameters number will not be recognized.
3. *<CR><LF>* denotes a carriage return or a line feed; all commands must be ended up with a carriage return or a line feed.

No.	Description	Command	Description
Video switch			
1	Switch one Input to one Output	Command: SET SW <i>in out</i><CR><LF> Return: SW <i>in out</i><CR><LF> Parameter: <i>in</i> = {hdmiin1, hdmiin2...hdmiin8, hdmiin0}; <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; Description: in -hdmiin0 means power down output SW is short for Switch Switch one input source for one output sink	Command: SET SW hdmiin1 hdmiout2<CR><LF> Return: SW hdmiin1 hdmiout2<CR><LF> Description: Switch input 1 for hdmi output 2
2	Switch indicate input for all outputs	Command: SET SW <i>in all</i><CR><LF> Return: SW <i>in all</i> <CR><LF> Parameter: <i>in</i> = { hdmiin1, hdmiin2...hdmiin8, hdmiin0}; <i>all</i> = {all}; Description: in - hdmiin0 means power down output SW is short for Switch Switch one input source for all output sink	Command: SET SW hdmiin1 <i>all</i> <CR><LF> Return: SW hdmiin1 <i>all</i><CR><LF> Description: Switch input1 for all output sink.

No.	Description	Command	Description
3	Get which input mapping to the indicate Output	Command: GET MP <i>out</i><CR><LF> Return: MP <i>in out</i><CR><LF> Parameter: <i>in</i> = {hdmiin1, hdmiin2...hdmiin8, hdmiin0}; <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; Description: <i>in</i> - hdmiin0 means power down output MP is short for mapping Get which input mapping to the indicate Output	Command: GET MP <i>hdmiout1</i><CR><LF> Return: MP <i>hdmiin2</i> <i>hdmiout1</i><CR><LF> Description: Get which input mapping to output 1
4	Get which output mapping to all input	Command: GET MP <i>all</i><CR><LF> Return: MP <i>in out</i><CR><LF> MP <i>in out</i><CR><LF> Parameter: <i>in</i> = {hdmiin1, hdmiin2...hdmiin8, hdmiin0}; <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; <i>all</i> = {all}; Description: <i>in</i> - none means power down output MP is short for mapping Get which output mapping to all input	Command: GET MP <i>all</i> <CR><LF> Return: MP <i>hdmiin1</i> <i>hdmiout1</i><CR>... MP <i>hdmiin2</i> <i>hdmiout2</i><CR><LF> Description: Get which output mapping to all input

No.	Description	Command	Description
Audio switch			
1	Audio Switch Input for Output	Command: SET AUDIOSW <i>in</i> <i>out</i><CR><LF> Return: AUDIOSW <i>in out</i><CR><LF> Parameter: <i>in</i> = {hdmi, arc}; <i>out</i> = {audioout1, audioout2,...audioout8}; Description: AUDIOSW is short for audio switch Set Audio Switch form one input source to one audio output. <i>in</i> = {hdmi, arc}; // hdmi means the audio source extract from HDMI OUT , arc means the audio source is ARC from HDMI OUT.	Command: SET AUDIOSW <i>arc</i> <i>audioout1</i><CR><LF> Return: AUDIOSW <i>arc</i> <i>audioout1</i><CR><LF> Description: Set Audio Switch ARC from hdmiout1 to audioout1.

No.	Description	Command	Description
2	Get which audio input mapping to the indicate Output	Command: GET AUDIOMP <i>out</i><CR><LF> Return: AUDIOMP <i>in out</i><CR><LF> Parameter: <i>in</i> = {hdmi, arc}; <i>out</i> = {audioout1, audioout2,...audioout8}; Description: AUDIOSW is short for audio switch Get which input mapping to the indicate Output <i>in</i> = {hdmi, arc}; // hdmi means the audio source extract from HDMI OUT , arc means the audio source is ARC from HDMI OUT.	Command: GET AUDIOMP <i>audioout1</i><CR><LF> Return: AUDIOSW arc <i>audioout1</i><CR><LF> Description: Get who is mapping to <i>audioout1</i>, the result is ARC from <i>hdmiout1</i>.
CEC Control			
1	Set CEC POWER ON/OFF	Command: SET CEC_PWR <i>out prm</i><CR><LF> Return: CEC_PWR <i>out prm</i><CR><LF> Parameter: <i>prm</i> = {on, off} <i>out</i> = {hdmiout1, hdmiout2...hdmiout8, all}; Description: Set sink power on or off	Command: SET CEC_PWR <i>hdmiout1 on</i><CR><LF> Return: CEC_PWR <i>hdmiout1 on</i><CR><LF> Description: Set sink <i>hdmi</i> output 1 power on

No.	Description	Command	Description
2	Set CEC AUTO POWER ON/OFF	Command: SET AUTOCEC_FN <i>out</i> <i>prm</i><CR><LF> Return: AUTOCEC_FN <i>out</i> <i>prm</i><CR><LF> Parameter: <i>prm</i> = {on,off} <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; Description: Set sink auto power Function ON or OFF	Command: SET AUTOCEC_FN <i>hdmiout1 on</i><CR><LF> Return: AUTOCEC_FN <i>hdmiout1</i> <i>on</i><CR><LF> Description: Set sink hdmi output 1 auto power ON
3	Get CEC AUTO POWER ON/OFF Status	Command: GET AUTOCEC_FN <i>out</i><CR><LF> Return: AUTOCEC_FN <i>out</i> <i>prm</i><CR><LF> Parameter: <i>prm</i> = {on, off} <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; Description: Get Sink auto power Function ON or OFF Status.	Command: GET AUTOCEC_FN <i>hdmiout1</i><CR><LF> Return: AUTOCEC_FN <i>on</i> Description: Get Sink auto power status, and the status is ON.

No.	Description	Command	Description
4	Set CEC POWER Delay Time	Command: SET AUTOCEC_D <i>out</i> <i>prm</i><CR><LF> Return: AUTOCEC_D <i>out</i> <i>prm</i><CR><LF> Parameter: <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; <i>prm</i> = {1,2,3,...} // according to the actual time counter, 1 means 1 minute ,2 means 2 minutes, Default wait time is 2 minutes, Max wait time is 30 minutes. 0 means when no active signal ,the unit auto power off immediately. Description: AUTOCEC_D is short for CEC auto Power Delay Timing	Command: SET AUTOCEC_D <i>hdmiout1 2</i><CR><LF> Return: AUTOCEC_D <i>hdmiout1</i> <i>2</i><CR><LF> Description: when no active signal to hdmi1, 2 minutes later, the unit will auto power off.

No.	Description	Command	Description
5	Get CEC POWER Delay Time Status	Command: GET AUTOCEC_D <i>out</i> <CR><LF> Return: AUTOCEC_D <i>out</i> <i>prm</i><CR><LF> Parameter: <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; <i>prm</i> = {1,2,3,...} // according to the actual time counter, 1 means 1 minute, 2 means 2 minutes, Default wait time is 2 minutes, Max wait time is 30 minutes. 0 means when no active signal, the unit auto power off immediately. Description: AUTOCEC_D is short for CEC auto Power Delay Timing	Command: GET AUTOCEC_D hdmiout1 <CR><LF> Return: AUTOCEC_D <i>hdmiout1</i> 2 <CR><LF> Description: Get hdmi1 auto power delay time, the result is 2 minutes

No.	Description	Command	Description
6	Set CEC command for defined Poweron/Poweroff	Command: SET CECCMD_EDIT <i>out prm1 prm2</i><CR><LF> Return: CECCMD_EDIT <i>out prm1 prm2</i><CR><LF> Parameter: <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; <i>prm1</i> = {pwron, pwroff}, // <i>prm2</i> = {...}, // many hexadecimal numbers, the total is less than 16. Space separated Description: Set CEC command for defined Poweron/Poweroff. If relevant commands are required, please refer to CEC specification for details.	Command: SET CECCMD_EDIT hdmiout1 pwron 40 04<CR><LF> Return: CECCMD_EDIT hdmiout1 pwron 40 04<CR><LF> Description: Send CEC command
7	Get CEC command for defined Poweron/Poweroff	Command: GET CECCMD_EDIT <i>out prm1</i><CR><LF> Return: CECCMD_EDIT <i>out prm1 prm2</i><CR><LF> Parameter: <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; <i>prm1</i> = {pwron, pwroff}, // <i>prm2</i> = {...}, // many hexadecimal numbers, the total is less than 16. Space separated Description: Get CEC command for defined Poweron/Poweroff.	Command: GET CECCMD_EDIT hdmiout1 pwron<CR><LF> Return: CECCMD_EDIT hdmiout1 pwron 40 04<CR><LF>

No.	Description	Command	Description
8	Send CEC command	Command: SET CEC_CMD <i>out prm</i><CR><LF> Return: CEC_CMD <i>out prm</i><CR><LF> Parameter: <i>out</i> = {hdmiout1, hdmiout2...hdmiout8}; <i>prm</i> = {...},// many hexadecimal numbers,the total is less than 16. Space separated Description: Send CEC command If relevant commands are required, please refer to CEC specification for details.	Command: SET CEC_CMD hdmiout1 40 04<CR><LF> Return: CEC_CMD hdmiout1 40 04<CR><LF> Description: Send CEC command
HDCP			
1	Set Input HDCP support ON/OFF	Command: SET HDCP_S <i>in prm</i><CR><LF> SET HDCP_S <i>in prm</i><CR><LF> Return: HDCP_S <i>in prm</i><CR><LF> Parameter: <i>prm</i> = {on, off} <i>in</i> = {hdmiin1, hdmiin2...hdmiin8} Description: HDCP_S will control source hdcp support on or off	Command: SET HDCP_S hdmiin1 <i>on</i><CR><LF> Return: HDCP_S hdmiin1 <i>on</i><CR><LF> Description: Set hdmi input 1 hdcp support on

No.	Description	Command	Description
2	Get Input HDCP support ON/OFF Status	Command: GET HDCP_S <i>in</i> <CR><LF> Return: HDCP_S <i>in prm</i> <CR><LF> Parameter: <i>prm</i> = {on, off} <i>in</i> = {hdmiin1, hdmiin2...hdmiin8} Description: HDCP_S is short for HDCP support	Command: GET HDCP_S hdmiin1<CR><LF> Return: HDCP_S <i>hdmiin1 on</i> <CR><LF> Description: Get hdmi1 hdcp support on or off status, and the result is on
EDID			
1	Set Input EDID	Command: SET EDID <i>in prm</i> <CR><LF> Return: EDID <i>in prm</i> <CR><LF> Parameter: <i>in</i> = {hdmiin1, hdmiin2...hdmiin8}; <i>prm</i> = {1 ~27} 1: Copy form hdmi output 1 2: Copy form hdmi output 2 ... 8: Copy form hdmi output 8 9: Fixed 4K60 7.1CH Encoded Audio with HDR; 10: Fixed 4K60 5.1CH Encoded Audio with HDR; 11: Fixed 4K60 2.0CH PCM Audio with HDR; 12: Fixed 4K60 2.0CH PCM Audio with SDR; 13: Fixed 4K30 7.1CH Encoded Audio with HDR; 14: Fixed 4K30 5.1CH Encoded Audio with HDR; 15: Fixed 4K30 2.0CH PCM Audio with HDR; 16: Fixed 4K30 2.0CH PCM	Command: SET EDID <i>hdmiin1 13</i> <CR><LF> Return: EDID <i>hdmiin1 13</i> <CR><LF> Description: Set in1 EDID Fixed 4K30 7.1CH Encoded Audio with HDR

No.	Description	Command	Description
		Audio with SDR; 17: Fixed 1080p@60Hz 7.1CH Encoded Audio with HDR; 18: Fixed 1080p@60Hz 5.1CH Encoded Audio with HDR; 19: Fixed 1080p@60Hz 2.0CH PCM Audio with HDR; 20: Fixed 1080p@60Hz 2.0CH PCM Audio with SDR; 21: Fixed 4K60 7.1CH Encoded Audio with SDR; 22: Fixed 4K60 5.1CH Encoded Audio with SDR; 23: Fixed 4K30 7.1CH Encoded Audio with SDR; 24: Fixed 4K30 5.1CH Encoded Audio with SDR; 25: Fixed 1080p@60Hz 7.1CH Encoded Audio with SDR; 26: Fixed 1080p@60Hz 5.1CH Encoded Audio with SDR; Description: Set Input EDID	
2	Get All Input EDID status	Command: GET EDID <i>all</i> <CR><LF> Return: EDID <i>in prm</i><CR> EDID <i>in prm</i><CR> EDID <i>in prm</i><CR><LF> Parameter: <i>in</i> = {hdmiin1, hdmiin2...hdmiin8}; <i>prm</i> = {1 ~27} 1: Copy form hdmi output 1 2: Copy form hdmi output 2 ... 8: Copy form hdmi output 8 9: Fixed 4K60 7.1CH Encoded Audio with HDR;	Command: GET EDID <i>all</i> <CR><LF> Return: EDID hdmiin1 01<CR> EDID hdmiin2 02<CR> EDID hdmiin3 03<CR><LF> Description: Get all input EDID Status

No.	Description	Command	Description
		10: Fixed 4K60 5.1CH Encoded Audio with HDR; 11: Fixed 4K60 2.0CH PCM Audio with HDR; 12: Fixed 4K60 2.0CH PCM Audio with SDR; 13: Fixed 4K30 7.1CH Encoded Audio with HDR; 14: Fixed 4K30 5.1CH Encoded Audio with HDR; 15: Fixed 4K30 2.0CH PCM Audio with HDR; 16: Fixed 4K30 2.0CH PCM Audio with SDR; 17: Fixed 1080p@60Hz 7.1CH Encoded Audio with HDR; 18: Fixed 1080p@60Hz 5.1CH Encoded Audio with HDR; 19: Fixed 1080p@60Hz 2.0CH PCM Audio with HDR; 20: Fixed 1080p@60Hz 2.0CH PCM Audio with SDR; 21: Fixed 4K60 7.1CH Encoded Audio with SDR; 22: Fixed 4K60 5.1CH Encoded Audio with SDR; 23: Fixed 4K30 7.1CH Encoded Audio with SDR; 24: Fixed 4K30 5.1CH Encoded Audio with SDR; 25: Fixed 1080p@60Hz 7.1CH Encoded Audio with SDR; 26: Fixed 1080p@60Hz 5.1CH Encoded Audio with SDR; Description: Get all input EDID Status	

No.	Description	Command	Description
3	Get one input EDID Status	Command: GET EDID <i>in</i> <CR><LF> Return: EDID <i>in prm</i> <CR><LF> Parameter: <i>in</i> = {hdmiin1, hdmiin2....hdmiin8}; <i>prm</i> = {1 ~27} 1: Copy form hdmi output 1 2: Copy form hdmi output 2 ... 8: Copy form hdmi output 8 9: Fixed 4K60 7.1CH Encoded Audio with HDR; 10:Fixed 4K60 5.1CH Encoded Audio with HDR; 11: Fixed 4K60 2.0CH PCM Audio with HDR; 12: Fixed 4K60 2.0CH PCM Audio with SDR; 13: Fixed 4K30 7.1CH Encoded Audio with HDR; 14: Fixed 4K30 5.1CH Encoded Audio with HDR; 15: Fixed 4K30 2.0CH PCM Audio with HDR; 16: Fixed 4K30 2.0CH PCM Audio with SDR; 17: Fixed 1080p@60Hz 7.1CH Encoded Audio with HDR; 18: Fixed 1080p@60Hz 5.1CH Encoded Audio with HDR; 19: Fixed 1080p@60Hz 2.0CH PCM Audio with HDR; 20: Fixed 1080p@60Hz 2.0CH PCM Audio with SDR; 21: Fixed 4K60 7.1CH Encoded Audio with SDR; 22: Fixed 4K60 5.1CH Encoded Audio with SDR; 23: Fixed 4K30 7.1CH	Command: GET EDID hdmiin1<CR><LF> Return: EDID hdmiin1 13<CR><LF> Description: Get in1 edid status, and the status is Fixed 4K30 7.1CH Encoded Audio with HDR

No.	Description	Command	Description
		Encoded Audio with SDR; 24: Fixed 4K30 5.1CH Encoded Audio with SDR; 25: Fixed 1080p@60Hz 7.1CH Encoded Audio with SDR; 26: Fixed 1080p@60Hz 5.1CH Encoded Audio with SDR; Description: Get one input EDID Status	
4	Set Write Input EDID	Command: SET EDID_W <i>in prm1</i> <i>prm2</i> <CR><LF> Return: EDID_W <i>in prm1</i> <i>prm3</i> <CR><LF> Parameter: <i>in</i> = {hdmiin1,hdmiin2...hdmiin8}; <i>prm1</i> = {block0, block1}; <i>prm2</i> = one block of 256 bytes edid ascii data with spaces(hex data need conversion into ASCII code) <i>prm3</i> = {ok, error}; error: check sum error Description: Write EDID content to input.	Command: SET EDID_W hdmiin1 <i>block0</i> XX...XX<CR><LF> Return: EDID_W hdmiin1 <i>block0</i> <i>ok</i> <CR><LF> Description: write EDID content to input

No.	Description	Command	Description
5	Get Read Output EDID	Command: GET EDID_R out<CR><LF> Return: EDID_R out prm1 prm2<CR><LF> Parameter: out = {hdmiout1, hdmiout2...hdmiout8}; prm1 = {block0, block1}; prm2 = { one block of 256 bytes edid ascii data with no spaces(hex data need conversion into ASCII code), error, unconnect}; Description: Read EDID content form output.	Command: GET EDID_R hdmiout1<CR><LF> Return: EDID_R hdmiout1 block0 XX...XX<CR><LF> EDID_R hdmiout1 block1 XX...XX<CR><LF> Description: EDID_R hdmiout1 block0 XX...XX<CR><LF> --- Read EDID ok or EDID_R hdmiout1 error<CR><LF> --- Check Sum Error or EDID_R hdmiout1 unconnect<CR><LF> --- Sink unconnect
System Info			
1	Factory reset	Command: RESET<CR><LF> Return: RESET<CR><LF> Description: Factory reset	Command: RESET<CR><LF> Return: RESET<CR><LF> Description: Factory reset all board
2	System reboot	Command: REBOOT<CR><LF> Return: REBOOT<CR><LF> Description: system reboot	Command: REBOOT<CR><LF> Return: REBOOT<CR><LF> Description: System reboot

No.	Description	Command	Description
3	Set IR System Code	Command: Set IR_SC <i>prm</i> <CR><LF> Return: IR_SC <i>prm</i> <CR><LF> Parameter: <i>prm</i> = { <i>all</i> , <i>mode1</i> , <i>mode2</i> }; <i>mode1</i> = 0x00 <i>mode2</i> = 0x4e Description: Set IR System Code	Command: Set IR_SC <i>mode1</i> <CR><LF> Return: IR_SC <i>mode1</i> <CR><LF> Description: Set IR System code mode 1
4	Get IR System Code	Command: Get IR_SC<CR><LF> Return: IR_SC <i>prm</i> <CR><LF> Parameter: <i>prm</i> = { <i>all</i> , <i>mode1</i> , <i>mode2</i> }; <i>mode1</i> = 0x00 <i>mode2</i> = 0x4e Description: Get IR System Code	Command: Get IR_SC <CR><LF> Return: IR_SC <i>mode1</i> <CR><LF> Description: Get IR System code, IR System code is mode 1
5	Get the API list	Command: help<CR><LF> Return: xxxx Description: Get the API list	Command: help<CR><LF> Return: xxxx Description: Get the API list
6	GET IP address	Command: GET IPADDR<CR><LF> Return: IPADDR xx.xx.xx.xx<CR><LF> Description: GET IP address	Command: GET IPADDR<CR><LF> Return: IPADDR 192.168.11.243<CR><LF>

No.	Description	Command	Description
7	Set Standby	Command: STANDBY<CR><LF> Return: STANDBY!<CR><LF>	Command: STANDBY<CR><LF> Return: STANDBY!<CR><LF>
8	Set Wake	Command: WAKE<CR><LF> Return: WAKE!<CR><LF>	Command: WAKE<CR><LF> Return: WAKE!<CR><LF>
9	Get Standby	Command: GET STANDBY<CR><LF> Return: STANDBY!<CR><LF> or WAKE!<CR><LF>	Command: GET STANDBY<CR><LF> Return: STANDBY!<CR><LF> or WAKE!<CR><LF>
Update info			
1	Get selected target firmware version	Command: GET VER<CR><LF> Return: VER <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {...} // according to actual firmware version Description: Get selected target firmware version	Command: GET VER<CR><LF> Return: VER 1.0<CR><LF> Description: Get all module firmware version

No.	Description	Command	Description
Preset scene			
1	Save Preset Scene	Command: SAVE PRESET <i>prm</i> <CR><LF> Return: PRESET <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {1,2,3}// Description: Save Preset Scene	Command: SAVE PRESET 1<CR><LF> Return: PRESET 1 <CR><LF> Description: Save preset scene
2	Restore Preset Scene	Command: RESTORE PRESET <i>prm</i> <CR><LF> Return: PRESET <i>prm</i> <CR><LF> Parameter: <i>prm</i> = {1,2,3}// Description: Restore Preset Scene	Command: RESTORE PRESET 1<CR><LF> Return: PRESET 1<CR><LF> Description: Restore preset scene
HDCPout info			
1	Set Output HDCP	Command: SET HDCP <i>out prm</i> <CR><LF> Return: HDCP <i>out prm</i> <CR><LF> Parameter: <i>out</i> = {hdmiout1, hdmiout2...hdmiout8,all};// all include hdmiout1-hdmiout6 <i>prm</i> = { follow,hdcp1.4,off...}// off means without HDCP, follow means source use hdcp 1.4, then output also use hdcp 1.4. the same with hdcp 2.2 and off. Description: Set Output HDCP	Command: SET HDCP <i>hdmiout1 follow</i> <CR><LF> Return: HDCP <i>hdmiout1 follow</i> <CR><LF> Description: set output hdcp is follow mode

No.	Description	Command	Description
2	Get Output HDCP	Command: GET HDCP <i>out</i><CR><LF> Return: HDCP <i>out prm</i><CR><LF> Parameter: <i>out</i> = {hdmiout1, hdmiout2...hdmiout8, all};// all include hdmiout1-hdmiout6 <i>prm</i> = {follow, hdc1.4, off...}// off means without HDCP, follow means source use hdc1.4 ,then output also use hdc1.4. the same with hdc1.4 and off. Description: Get Output HDCP	Command: GET HDCP <i>hdmiout1</i><CR><LF> Return: HDCP <i>hdmiout1 follow</i><CR><LF> Description: Get output hdc1 is follow mode
Video/Audio Detail			
1	Get the connection status of video input	Command: GET VIDIN_CONNECT <i>in</i><CR><LF> Return: VIDIN_CONNECT <i>in prm</i><CR><LF> <i>in</i> = {in1, in2...in8}; <i>prm</i> = {DISCONNECTE, CONNECTE} Description: Get the connection status of the video input	Command: GET VIDIN_CONNECT <i>in1</i><CR><LF> Return: VIDIN_CONNECT <i>in1 DISCONNECTE</i><CR><LF>
2	Get the status of input signal	Command: GET VIDIN_SIG <i>in</i><CR><LF> Return: VIDIN_SIG <i>in prm</i><CR><LF> <i>in</i> = {in1, in2...in8}; <i>prm</i> = {no, valid}	Command: GET VIDIN_SIG <i>in1</i><CR><LF> Return: VIDIN_SIG <i>in1 valid</i><CR><LF>

No.	Description	Command	Description
		Description: Get the status of the input signal	
3	Get input video format information	Command: GET VIDIN_FORMAT in<CR><LF> Return: VIDIN_FORMAT in prm<CR><LF> in = {in1, in2...in8}; prm = { } Description: Get the resolution of the video input prm = {<horizontal>x<vertical>,<rate>; <HDR info>;<ColorSpace>,<DeepColor>} - horizontal = An integer value representing the horizontal. - vertical = An integer value representing the vertical. May have an additional qualifier such as 'i' or 'p'. - rate = An integer value representing the refresh rate. - HDR info = none hdr/ static hdr/ dynamic hdr - Color space = RGB / Ycbcr 444 /Ycbcr 422/Ycbcr 420 - DeepColor = 8 bit/10 bit /12 bit/ 16 bit	Command: GET VIDIN_FORMAT in1<CR><LF> Return: VIDIN_FORMAT in1 3840x2160,60; none hdr; rgb;8bit<CR><LF>
4	Get input audio format information	Command: GET AUDIN_FORMAT in<CR><LF> Return: AUDIN_FORMAT in prm<CR><LF> in = {in1, in2...in8};	Command: GET AUDIN_FORMAT in1<CR><LF> Return: AUDIN_FORMAT in1 PCM;48kHz<CR><LF>

No.	Description	Command	Description
		prm = { } Description: Get the resolution of the video input prm = {<PCM / non-PCM>; <Sampling rate>}	
5	Get HDCP version of input video	Command: GET VIDIN_HDCP in<CR><LF> Return: VIDIN_HDCP in prm<CR><LF> in = {in1, in2...in8}; prm = {no hdcv, hdcv1.4, hdcv2.2} Description: Get hdcv version of input video	Command: GET VIDIN_HDCP in1<CR><LF> Return: VIDIN_HDCP in1 no hdcv<CR><LF>
6	Get the connection status of video output	Command: GET VIDOUT_CONNECT in<CR><LF> Return: VIDOUT_CONNECT in prm<CR><LF> in = {in1, in2...in8}; prm = {DISCONNECTE, CONNECTE} Description: Get the connection status of the video output	Command: GET VIDOUT_CONNECT in1<CR><LF> Return: VIDOUT_CONNECT in1 DISCONNECTE<CR><LF>
7	Get the status of the output signals	Command: GET VIDOUT_SIG out<CR><LF> Return: VIDOUT_SIG out prm<CR><LF> out = {out1, out2...out10}; prm = {no, valid} Description: Get the status of the output signals	Command: GET VIDOUT_SIG out1<CR><LF> Return: VIDOUT_SIG out1 valid<CR><LF>

No.	Description	Command	Description
8	Get output video format information	Command: GET VIDOUT_FORMAT out<CR><LF> Return: VIDOUT_FORMAT out prm<CR><LF> out = {out1, out2...out10}; prm = { } Description: Get the resolution of the video input prm = {<horizontal>x<vertical>,<rate>; <HDR info>;<ColorSpace>,<DeepColor>} - horizontal = An integer value representing the horizontal. - vertical = An integer value representing the vertical. May have an additional qualifier such as 'i' or 'p'. - rate = An integer value representing the refresh rate. - HDR info = none hdr/ static hdr/ dynamic hdr - Color space = RGB / Ycbcr 444 /Ycbcr 422/Ycbcr 420 - DeepColor = 8 bit/10 bit /12 bit/ 16 bit	Command: GET VIDOUT_FORMAT out1<CR><LF> Return: VIDOUT_FORMAT out1 3840x2160,60; none hdr; rgb; 8bit<CR><LF>
9	Get output audio format information	Command: GET AUDOUT_FORMAT in<CR><LF> Return: AUDOUT_FORMAT in prm<CR><LF> out = {out1, out2...out10}; prm = { }	Command: GET AUDOUT_FORMAT out1<CR><LF> Return: AUDOUT_FORMAT out1 PCM; 48kHz<CR><LF>

No.	Description	Command	Description
		Description: Get the resolution of the video input prm = {<PCM / non-PCM>; <Sampling rate>}	
10	Get HDCP version of output video	Command: GET VIDOUT_HDCP out<CR><LF> Return: VIDOUT_HDCP out prm<CR><LF> out = {out1, out2...out10}; prm = {no hdcp, hdcp1.4, hdcp2.2} Description: Get hdcp version of output video	Command: GET VIDOUT_HDCP out1<CR><LF> Return: VIDOUT_HDCP out1 no hdcp<CR><LF>

