

Telnet API commands for the MX0808-1022 8x8 HDMI matrix with analog and digital audio outputs

DEVICE API Reference

Telnet API commands for the MX0808-1022 8x8 HDMI matrix with analog and digital audio outputs

Table of Contents

- Switch / Get
- Switch / Set
- Audio Switch / Get
- Audio Switch / Set
- Cec Power
- Cec Auto / Get
- Cec Auto / Set
- Cec Delay / Get
- Cec Delay / Set
- Cec Command / Get
- Cec Command / Set
- Cec Send
- Input Hdcv Support / Get
- Input Hdcv Support / Set
- Edid / Get
- Edid / Set
- Edid Write
- Edid Read
- System / Reset
- System / Reboot
- Ir Mode / Get
- Ir Mode / Set
- Api List
- Ip Address
- Power / Get
- Power / Standby
- Power / Wake
- Firmware Version
- Preset / Save

- Preset / Restore
- Output Hdcv Mode / Get
- Output Hdcv Mode / Set
- Video Input / Connection
- Video Input / Signal
- Video Input / Format
- Video Input / Audio Format
- Video Input / Hdcv Version
- Video Output / Connection
- Video Output / Signal
- Video Output / Format
- Video Output / Audio Format
- Video Output / Hdcv Version

Command Reference

Switch / Get

- **Command:** GET MP
- **Syntax:** GET MP <hdmiout1..hdmiout8|all>
- **Description:** Get the current HDMI input mapping for one output or all outputs.
- **Parameters:** output
- **Response Type:** string
mapping: string

Switch / Set

- **Command:** SET SW
- **Syntax:** SET SW <hdmiin1..hdmiin8|hdmiin0> <hdmiout1..hdmiout8|all>
- **Description:** Route one HDMI input to one HDMI output or to all outputs. hdmiin0 powers down the selected output path.
- **Parameters:** input, output
- **Response Type:** confirmation
input: string
output: string

Audio Switch / Get

- **Command:** GET AUDIOMP

- **Syntax:** GET AUDIOMP <audioout1..audioout8>
- **Description:** Get the current audio source mapped to one analog audio output.
- **Parameters:** output
- **Response Type:** string


```
source: string
output: string
```

Audio Switch / Set

- **Command:** SET AUDIOSW
- **Syntax:** SET AUDIOSW <hdmi|arc> <audioout1..audioout8>
- **Description:** Select whether an analog audio output follows HDMI audio extraction or ARC audio.
- **Parameters:** source, output
- **Response Type:** confirmation


```
source: string
output: string
```

Cec Power

- **Command:** SET CEC_PWR
- **Syntax:** SET CEC_PWR <hdmiout1..hdmiout8|all> <on|off>
- **Description:** Send a CEC power command to one sink or all sinks.
- **Parameters:** output, state
- **Response Type:** confirmation


```
output: string
state: string
```

Cec Auto / Get

- **Command:** GET AUTOCEC_FN
- **Syntax:** GET AUTOCEC_FN <hdmiout1..hdmiout8>
- **Description:** Get the automatic CEC power state for one output.
- **Parameters:** output
- **Response Type:** string


```
output: string
state: string
```

Cec Auto / Set

- **Command:** SET AUTOCEC_FN
- **Syntax:** SET AUTOCEC_FN <hdmiout1..hdmiout8> <on|off>
- **Description:** Enable or disable automatic CEC power behavior for one output.
- **Parameters:** output, state
- **Response Type:** confirmation
 - output: string
 - state: string

Cec Delay / Get

- **Command:** GET AUTOCEC_D
- **Syntax:** GET AUTOCEC_D <hdmiout1..hdmiout8>
- **Description:** Get the automatic CEC power-off delay for one output.
- **Parameters:** output
- **Response Type:** string
 - output: string
 - minutes: integer

Cec Delay / Set

- **Command:** SET AUTOCEC_D
- **Syntax:** SET AUTOCEC_D <hdmiout1..hdmiout8> <0..30>
- **Description:** Set the automatic CEC power-off delay in minutes for one output.
- **Parameters:** output, minutes
- **Response Type:** confirmation
 - output: string
 - minutes: integer

Cec Command / Get

- **Command:** GET CECCMD_EDIT
- **Syntax:** GET CECCMD_EDIT <hdmiout1..hdmiout8> <pwron|pwroff>
- **Description:** Read the stored custom CEC power-on or power-off command for one output.
- **Parameters:** output, command_type
- **Response Type:** string
 - output: string
 - command_type: string
 - hex_bytes: string

Cec Command / Set

- **Command:** SET CECCMD_EDIT
- **Syntax:** SET CECCMD_EDIT <hdmiout1..hdmiout8> <pwron|pwroff> <hex_bytes>
- **Description:** Store a custom CEC power-on or power-off command for one output.
- **Parameters:** output, command_type, hex_bytes
- **Response Type:** confirmation


```
output: string
command_type: string
hex_bytes: string
```

Cec Send

- **Command:** SET CEC_CMD
- **Syntax:** SET CEC_CMD <hdmiout1..hdmiout8> <hex_bytes>
- **Description:** Send a raw CEC command to one HDMI output.
- **Parameters:** output, hex_bytes
- **Response Type:** confirmation


```
output: string
hex_bytes: string
```

Input Hdcv Support / Get

- **Command:** GET HDCP_S
- **Syntax:** GET HDCP_S <hdmiin1..hdmiin8>
- **Description:** Get the HDCP support state for one HDMI input.
- **Parameters:** input
- **Response Type:** string


```
input: string
state: string
```

Input Hdcv Support / Set

- **Command:** SET HDCP_S
- **Syntax:** SET HDCP_S <hdmiin1..hdmiin8> <on|off>
- **Description:** Enable or disable HDCP support on one HDMI input.
- **Parameters:** input, state
- **Response Type:** confirmation


```
input: string
state: string
```

Edid / Get

- **Command:** GET EDID
- **Syntax:** GET EDID <hdmiin1..hdmiin8|all>
- **Description:** Get the EDID preset assigned to one input or all inputs.
- **Parameters:** input
- **Response Type:** string
edid: string

Edid / Set

- **Command:** SET EDID
- **Syntax:** SET EDID <hdmiin1..hdmiin8> <1..27>
- **Description:** Assign one of the vendor EDID presets to an HDMI input.
- **Parameters:** input, profile
- **Response Type:** confirmation
input: string
profile: integer

Edid Write

- **Command:** SET EDID_W
- **Syntax:** SET EDID_W <hdmiin1..hdmiin8> <block0|block1> <hex_bytes>
- **Description:** Write one EDID block to an HDMI input. The device returns ok or error for checksum validation.
- **Parameters:** input, block, hex_bytes
- **Response Type:** confirmation
input: string
block: string
status: string

Edid Read

- **Command:** GET EDID_R
- **Syntax:** GET EDID_R <hdmiout1..hdmiout8>
- **Description:** Read EDID block data from one HDMI output. The device can return block data, error, or unconnect.
- **Parameters:** output
- **Response Type:** string
output: string

```
block0: string
block1: string
status: string
```

System / Reset

- **Command:** RESET
- **Syntax:** RESET
- **Description:** Restore the device to factory defaults.
- **Parameters:** None
- **Response Type:** confirmation

System / Reboot

- **Command:** REBOOT
- **Syntax:** REBOOT
- **Description:** Reboot the device.
- **Parameters:** None
- **Response Type:** confirmation

Ir Mode / Get

- **Command:** GET IR_SC
- **Syntax:** GET IR_SC
- **Description:** Get the current IR system code mode.
- **Parameters:** None
- **Response Type:** string

```
mode: string
```

Ir Mode / Set

- **Command:** SET IR_SC
- **Syntax:** SET IR_SC <all|mode1|mode2>
- **Description:** Set the IR system code mode.
- **Parameters:** mode
- **Response Type:** confirmation

```
mode: string
```

Api List

- **Command:** help
- **Syntax:** help
- **Description:** Return the device's built-in API command list.
- **Parameters:** None
- **Response Type:** string
 commands: string

Ip Address

- **Command:** GET IPADDR
- **Syntax:** GET IPADDR
- **Description:** Get the configured IP address for the device.
- **Parameters:** None
- **Response Type:** string
 ip_address: string

Power / Get

- **Command:** GET STANDBY
- **Syntax:** GET STANDBY
- **Description:** Get whether the device is in standby or awake.
- **Parameters:** None
- **Response Type:** string
 state: string

Power / Standby

- **Command:** STANDBY
- **Syntax:** STANDBY
- **Description:** Put the device into standby mode.
- **Parameters:** None
- **Response Type:** confirmation

Power / Wake

- **Command:** WAKE
- **Syntax:** WAKE
- **Description:** Wake the device from standby mode.

- **Parameters:** None
- **Response Type:** confirmation

Firmware Version

- **Command:** GET VER
- **Syntax:** GET VER
- **Description:** Get the firmware version reported by the device.
- **Parameters:** None
- **Response Type:** string
firmware: string

Preset / Save

- **Command:** SAVE PRESET
- **Syntax:** SAVE PRESET <1|2|3>
- **Description:** Save the current routing and configuration state to one preset slot.
- **Parameters:** slot
- **Response Type:** confirmation
slot: integer

Preset / Restore

- **Command:** RESTORE PRESET
- **Syntax:** RESTORE PRESET <1|2|3>
- **Description:** Restore one saved preset slot.
- **Parameters:** slot
- **Response Type:** confirmation
slot: integer

Output Hdcp Mode / Get

- **Command:** GET HDCP
- **Syntax:** GET HDCP <hdmiout1..hdmiout8|all>
- **Description:** Get HDCP handling mode for one HDMI output or all outputs.
- **Parameters:** output
- **Response Type:** string
output: string
mode: string

Output Hdcv Mode / Set

- **Command:** SET HDCP
- **Syntax:** SET HDCP <hdmiout1..hdmiout8|all> <follow|hdcp1.4|hdcp2.2|off>
- **Description:** Set HDCP handling for one HDMI output or all outputs.
- **Parameters:** output, mode
- **Response Type:** confirmation
output: string
mode: string

Video Input / Connection

- **Command:** GET VIDIN_CONNECT
- **Syntax:** GET VIDIN_CONNECT <in1..in8>
- **Description:** Get whether one HDMI input is physically connected.
- **Parameters:** input
- **Response Type:** string
input: string
state: string

Video Input / Signal

- **Command:** GET VIDIN_SIG
- **Syntax:** GET VIDIN_SIG <in1..in8>
- **Description:** Get whether one HDMI input currently has a valid signal.
- **Parameters:** input
- **Response Type:** string
input: string
state: string

Video Input / Format

- **Command:** GET VIDIN_FORMAT
- **Syntax:** GET VIDIN_FORMAT <in1..in8>
- **Description:** Get the detected video format on one HDMI input.
- **Parameters:** input
- **Response Type:** string
input: string
format: string

Video Input / Audio Format

- **Command:** GET AUDIN_FORMAT
- **Syntax:** GET AUDIN_FORMAT <in1..in8>
- **Description:** Get the detected audio format on one HDMI input.
- **Parameters:** input
- **Response Type:** string
 - input: string
 - format: string

Video Input / Hdcv Version

- **Command:** GET VIDIN_HDCP
- **Syntax:** GET VIDIN_HDCP <in1..in8>
- **Description:** Get the HDCP version detected on one HDMI input.
- **Parameters:** input
- **Response Type:** string
 - input: string
 - hdcv: string

Video Output / Connection

- **Command:** GET VIDOUT_CONNECT
- **Syntax:** GET VIDOUT_CONNECT <out1..out8>
- **Description:** Get whether one HDMI output is physically connected.
- **Parameters:** output
- **Response Type:** string
 - output: string
 - state: string

Video Output / Signal

- **Command:** GET VIDOUT_SIG
- **Syntax:** GET VIDOUT_SIG <out1..out8>
- **Description:** Get whether one HDMI output currently has a valid signal.
- **Parameters:** output
- **Response Type:** string
 - output: string
 - state: string

Video Output / Format

- **Command:** GET VIDOUT_FORMAT
- **Syntax:** GET VIDOUT_FORMAT <out1..out8>
- **Description:** Get the current video format on one HDMI output.
- **Parameters:** output
- **Response Type:** string
 - output: string
 - format: string

Video Output / Audio Format

- **Command:** GET AUDOUT_FORMAT
- **Syntax:** GET AUDOUT_FORMAT <out1..out8>
- **Description:** Get the current audio format on one HDMI output.
- **Parameters:** output
- **Response Type:** string
 - output: string
 - format: string

Video Output / Hdcv Version

- **Command:** GET VIDOUT_HDCP
- **Syntax:** GET VIDOUT_HDCP <out1..out8>
- **Description:** Get the HDCP version detected on one HDMI output.
- **Parameters:** output
- **Response Type:** string
 - output: string
 - hdcv: string