MAINTENANCE TECHNICAL SUPPORT CENTER / MAINTENANCE POLICIES & PROGRAMS ENGINEERING / UNITED STATES POSTAL SERVICE

maintenance management order UNITED STATES



SUBJECT: PM Guidelines for Towveyor (Takeaway),

Type F (ACCO)

NO: MMO-050-98

DATE:

TO: Bulk Mail Centers FILE CODE: Y

dewa:M94154AC

July 28, 1998

| | Online Change Record | | | | | | | | | | |
|-------------------------------------|----------------------|--|--|--|--|--|--|--|--|--|--|
| Change # Date Description of Change | | | | | | | | | | | |
| 2 | 4/21/2022 | Attachment 2, corrected skill level 4, no longer in use, to 7. | | | | | | | | | |
| 1 | 5/16/2013 | This bulletin has been updated to reflect changes to the Attachment 1 Summary. The times have been updated to reflect accurate rollup times using the standard two decimal place rounding. | | | | | | | | | |

This Maintenance Management Order (MMO) provides Preventive Maintenance guidelines for Towveyor (Takeaway), Type F (ACCO) and supersedes Maintenance Checklist BO72.

The minimum maintenance skill level to perform each task on the various checklists is included in the Minimum Skill Level column. This does not preclude higher level employees from performing any of this work.

WARNING

Various products which require Material Safety Data Sheets (MSDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current MSDS for each product used is on file and available by all employees. When reordering such a product, it is suggested that a current MSDS be requested.

The workhours represented in this MMO reflect the maximum workhours required to maintain the equipment. Given local conditions, management may modify task frequencies.

For questions or comments concerning this bulletin contact the MTSC HelpDesk, either online at MTSC>HELPDESK>Create/Update Tickets or call (800) 366-4123.

Rex M. Gallaher Manager Maintenance Technical Support Center Maintenance Policies and Programs

- 1. Summary of Revised Workload Estimate
- 2. Towveyor (Takeaway), Type F (ACCO) Master Checklist

ATTACHMENT 1

-SUMMARY-

REVISED WORKLOAD ESTIMATE

FOR

TOWVEYOR (TAKEAWAY), TYPE F (ACCO)

| Routine Servicing (hrs/yr) | Repair* (hrs/yr) | Total Servicing & Repair Time (hrs/yr) | Nonproductive Time ** (hrs/yr) | Total Servicing Per Machine (hrs/yr) |
|----------------------------------|---------------------|--|--------------------------------------|--|
| 25.78 | 7.74 | 33.51 | 3.35 | 36.87 |

^{*} Repair estimates based on 30% of servicing.

TIME TOTALS

| Monthly Time Total: | 1.23 Hrs. *** |
|-------------------------|---------------|
| Quarterly Time Total: | 2.02 Hrs. *** |
| Semi-Annual Time Total: | 0.60 Hrs. *** |
| Annual Time Total: | 0.53 Hrs. *** |

NOTE

The time shown does not allow for multiple assemblies on any equipment. Should multiple assemblies exist, the time must be modified at the local level to account for those occurrences. Other unique site conditions that requires additional time are to be addressed at the local level.

^{**} Based on 10% of total servicing and repair.

^{***} These times are provided for data entry for the MARS System.

THIS PAGE BLANK

ATTACHMENT 2

TOWVEYOR (TAKEAWAY), TYPE F MASTER CHECKLIST

03-TOWVE-ZZ-006-M

The "Part or Component" column for each step on the Master Checklist provides a "Frequency Code" designation followed by a letter or series of letters. These letters correspond to the frequency codes as published in MS-63 and specify the frequency for which that instruction (step) must be performed. These frequency codes are in compliance with NMICS superseding route structure. The possible frequencies and their codes are given in the table below:

Table 2-1. MS-63 (NMICS) Frequency-Codes

| CODE | FREQUENCY | DESCRIPTION |
|------|--------------|-------------------------------|
| Α | ANNUAL | Once every 13 APs. |
| В | BI-WEEKLY | Once every 2 weeks |
| С | BI-MONTHLY | Once every 2 APs. |
| D | DAILY | Once a day; 7 days a week. |
| E | DAILY | Once a day; 6 days a week. |
| F | DAILY | Once a day; 5 days a week. |
| G | DAILY | Once a day; 4 days a week. |
| Н | DAILY | Once a day; 3 days a week. |
| J | SEMI-WEEKLY | 2 days a week. |
| K | BI-ANNUAL | Once every 2 years. |
| L | TRI-ANNUAL | Once every 3 years. |
| M | MONTHLY | Once every AP. |
| N | QUAD-ANNUAL | Once every 4 years. |
| Р | QUINT-ANNUAL | Once every 5 years. |
| Q | QUARTERLY | 4 times every 13 APs. |
| S | SEMI-ANNUAL | Twice every 13 AP. |
| Т | TOURLY | 3 times a day; 7 days a week. |
| U | TOURLY | Twice a day; 7 days a week. |
| V | TOURLY | 3 times a day; 6 days a week. |
| W | WEEKLY | Once a week. |
| X | TOURLY | Twice a day; 6 days a week. |
| Υ | TOURLY | 3 times a day; 5 days a week. |
| Z | TOURLY | Twice a day; 5 days a week. |

| U.S. Postal Service | IDENTIFICATION | | | | | | | | | | | | |
|-----------------------------|-----------------------------|---|------|---|---|-------------------|----------|---|----|-----------|---|---|---|
| Maintenance Checklist | Work Equipme Code Acrony | | | | | | Number | | | Туре | | | |
| | 0 | 3 | T | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | М |
| Equipment Nomenclature | Equipment Model | | | | | Bulletin Filename | | | me | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | | ACCO | | | | M94154AC | | | ALL | | | - |

| Part or | Item | Task Statement and Instruction | Est. | Min |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| • | | | Reg'd | Level |

SAFETY STATEMENT

Frequency Code: -M-Q-S-A- COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and activate lockouts as
appropriate while working on this equipment. Where
air pressure is required for cleaning, use a low air
pressure (30 psi or less) air source. Eye protection
(goggles or face shield) must be used when utilizing
compressed air for cleaning. Check to ensure all
employees are clear of the machine. Report safety
deficiencies to your supervisor immediately upon
detection.

AA-1

CHECK FOR MAIL. - Look for loose mail while performing activities.

2.5 4<u>7</u> min

3

ΑII

Frequency Code: -M-Q-S-A-

WARNING

Eye protection (goggles or face shield) must be worn when using compressed air, steam, or high pressure cleaner/washer device for cleaning.

CH-1 TOWPIN

3. **CLEAN CHAIN. -** Clean chain as follows:

1 4<u>7</u> min/

10ft.

of

chain

Frequency Code: -----S-A- 1. Clean chain with steam or high pressure cleaner/washer device. Run chain at least one (1) complete cycle.

or

2. Remove foreign material by blowing or vacuuming.

Frequency Code: -M-Q-S-A- 4. **LUBRICATE CHAIN. -** Manually turn on chain lubricator. Make at least two (2) complete cycles before turning the automatic lubricator off.

0.22 4<u>7</u> min/ 10ft.

| U.S. Postal Service | IDENTIFICATION | | | | | | | | | | | | |
|-----------------------------|-----------------|------------|------------|---|---------------|-------------------|---|----------|------------|-----------|-------|------|---|
| Maintenance Checklist | | ork ode | | | uipm crony | | | | ass ode | N | lumbe | Туре | |
| | 0 | 3 | Т | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | M |
| Equipment Nomenclature | Equipment Model | | | | | Bulletin Filename | | | me | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | | ACCO M9415 | | | | | 54AC ALL | | | | | |

| Part or Component | Item No. | Task Statement and Instruction (Comply with all current safety precautions) | Est. Time Req'd | Min Skill Level |
|----------------------|-------------|---|-----------------------|-----------------------|
| SYSTEM | 5. | POWER DOWN AND LOCKOUT POWER Power | 1 | 4 <u>7</u> |

Frequency Code:

down the equipment and lockout its electrical power as prescribed by the procedures contained in, or locally developed in accordance with, the current Maintenance ----Q-S-A-Management Order (MMO) providing lockout/restore procedures.

CH-1 **TOWPIN**

CHECK CHAIN. - Check chain for bent, cracked, or 6. excessively worn links.

1 4<u>7</u> min/ 10ft.

of

chain

Frequency Code:

----Q-S-A-

Frequency Code: -M-Q-S-A-

7 **REMOVE COVER PLATE. -** Remove cover plates. Erect barricades around open pits.

10 47 min

47

WARNING

Eye protection (goggles or face shield) must be worn when using compressed air for cleaning.

CHECK LUBRICATOR. - Check condition of chain Frequency 8. 6 47 Code: lubricator. Refill and clean reservoir as necessary. min -M-Q-S-A-

CB-1 CLEANOUT BOX

9. CLEAN BOXES. - Clean all foreign material from 15 cleanout boxes. min

Frequency Code: -M-Q-S-A-

| U.S. Postal Service | IDENTIFICATION | | | | | | | | | | | | |
|-----------------------------|-----------------------------|---|------|---|---|-------------------|----------|---|----|-----------|---|---|---|
| Maintenance Checklist | Work Equipme Code Acrony | | | | | | Number | | | Туре | | | |
| | 0 | 3 | T | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | М |
| Equipment Nomenclature | Equipment Model | | | | | Bulletin Filename | | | me | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | | ACCO | | | | M94154AC | | | ALL | | | - |

| Part or | Item | Task Statement and Instruction | Est. | Min |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| • | | | Reg'd | Level |

WARNING

Eye protection (goggles or face shield) must be worn when using compressed air for cleaning.

WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

| RT-1 ROLLER | 10. | CLEAN ROLLER TURNS Clean roller turns as follows: | 8 min | 4 <u>7</u> |
|------------------------------|-----|---|-----------|------------|
| TURN | | 1. Clean dirt and foreign material from roller turns. | ******* | |
| Frequency | | 2. Clean with solvent, and blow dry. | | |
| Code: Q-S-A- | | 3. Lubricate with GL-2. | | |
| Frequency Code: Q-S-A- | 11. | CHECK ROLLERS Check rollers for wear, gouging, and wobble. Check mounting bolts. | 2 min | 4 <u>7</u> |
| DA-1 DRIVE ASSEMBLY | 12. | CLEAN MOTOR AND REDUCER Clean motor and reducer as follows: | 10 min | 4 <u>7</u> |
| Frequency Code: | | 1. Clean motor and reducer by wiping. | | |
| Q-S-A- | | 2. Clean vent hole and cooling fins as applicable. | | |
| Frequency Code: Q-S-A- | 13. | CHECK MOTOR AND HOUSING Check motor and reducer housing for evidence of lubrication leakage. | 5 min | 4 <u>7</u> |

min

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | | |
|-----------------------------|--------------|-----------------|------------------|---|---|-----|-------------------|------|---------------|---|-----------|---|------|--|
| Maintenance Checklist | Work Code | | Equipm Acrony | | | | | | Class Code | | Number | | Туре | |
| | 0 | 3 | T | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | M | |
| Equipment Nomenclature | | Equipment Model | | | | | Bulletin Filename | | | | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | ACCO | | | | | M94154AC | | | | ALL | | | |

| | Part or | Item | Task Statement and Instruction | Est. | Min |
|--------------|-----------|------|--|-------|-------|
| Red'd Leve | Component | No. | (Comply with all current safety precautions) | Time | Skill |
| 11094 2010 | · | | | Req'd | Level |

DA-1 DRIVE 144. CHECK GREASE LEVEL AND BEARINGS. - Check 20 <u>47</u> ASSEMBLY grease level and bearings as follows: min (Cont.) Check grease level of reducer. Add as required. Frequency Bearings may be replaced as necessary. Code: ----Q-S----GREASE BEARINGS. - Grease motor and reducer 2 Frequency 15. 47 Code: bearings as applicable. min -----A-16. Drain and Refill Reducer - Disassemble reducer, clean Frequency 30 47 Code: out old lubricant and refill with GR-2. min -----A-CHECK AND CLEAN V-BELTS AND SHEAVES. -8 Frequency 17. 4<u>7</u> Code: Check and clean V-belts and sheaves as follows: min ----Q-S-A-Check V-belts and sheaves for wear and alignment. 2. Clean foreign material from belts and sheaves by wiping with clean rags. 3. Check sheave set screws and belt tension. Frequency 18. CHECK AND CLEAN SPEED SWITCH. - Check and 10 <u>47</u>

1. Check critical speed switch.

clean speed switch as follows:

- 2. Check flexible coupling and set screws for wear and damage.
- 3. Wipe clean.

Code:

----Q-S-A-

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | | |
|-----------------------------|--------------|-----------------|---|-----|---------------|-----|-------------------|-----------|------------|--------|-----------|----|------|--|
| Maintenance Checklist | Work Code | | | . ' | uipm crony | | | Cla Co | ass ode | Number | | er | Туре | |
| | 0 | 3 | T | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | М | |
| Equipment Nomenclature | | Equipment Model | | | | | Bulletin Filename | | | | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | ACCO | | | | | M94154AC | | | | ALL | | | |

| Part or | Item | Task Statement and Instruction | Est. | Min |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| · | | | Req'd | Level |

WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

DA-1 DRIVE CHECK AND CLEAN SPROCKET. - Check and clean 19. 5 4 ASSEMBLY sprocket as follows: min (Cont.) Check sprocket for wear and alignment. Frequency Code: Wrench test set screws. ----Q-S-A-Clean sprocket with solvent and rags. CHECK FLUID, SET SCREWS, AND KEYWAYS. -Frequency 20. 10 <u>47</u> Code: Check fluid level, set screws, and keyways as follows: min ----Q-S-A-

- 1. Check fluid level in coupling.
- 2. Check set screws and keyways for tightness.

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | | |
|-----------------------------|--|-----------------|---|---|---------------|-----|-------------------|------|------------|---|------------------------|---|------|--|
| Maintenance Checklist | | ork ode | | ' | uipm crony | | | | ass ode | N | Number 0 0 6 Frequency | | Туре | |
| | | 3 | Т | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | M | |
| Equipment Nomenclature | | Equipment Model | | | | | Bulletin Filename | | | | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | ACCO | | | | | M94154AC | | | | ALL | | | |

| Part or | Item | Task Statement and Instruction | Est. | Min |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| • | | | Reg'd | Level |

WARNING

Eye protection (goggles or face shield) must be worn when using compressed air for cleaning.

WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

| CATERPILLAR CHAIN | 21. | CLEAN AND LUBRICATE CHAIN Clean and lubricate caterpillar chain as follows: | _ | |
|------------------------------|-----|--|-------|---|
| Frequency Code: | | Clean caterpillar chain by brushing on solvent and blow or wipe dry. | | |
| Q-S-A- | | 2. Lubricate with GL-1. | | |
| | | 3. Wipe up excess. | | |
| Frequency Code: Q-S-A- | 22. | CHECK CHAIN TENSION Check caterpillar drive chain for proper tension. Use take-up bar to adjust if required. | _ | [|
| Frequency Code: Q-S-A- | 23. | CHECK LUBRICATOR Check condition of chain 6 lubricator. Refill and clean reservoir as necessary. | · · · | |

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | | |
|-----------------------------|--------------|-----------------|------------------|---|---|-----|-------------------|------|---------------|---|-----------|---|------|--|
| Maintenance Checklist | Work Code | | Equipm Acrony | | | | | | Class Code | | Number | | Туре | |
| | 0 | 3 | T | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | M | |
| Equipment Nomenclature | | Equipment Model | | | | | Bulletin Filename | | | | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | ACCO | | | | | M94154AC | | | | ALL | | | |

| Part or | Item | Task Statement and Instruction | Est. | Min |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| • | | , , , , , , , , , , , , , , , , , , , | Req'd | Level |

CATERPILLAR 24. **CLEAN BARS. -** Clean bars as follows: 30 47 CHAIN (Cont.) min Clean back-up and take-up bars by wiping. Frequency Code: Remove hardened deposits with solvent. -----S-A-3. Lubricate by brushing with GL-2. Wipe up excess. **CHECK AND LUBRICATE TRACTION WHEEL. - Check** TW-1 25. 15 <u>47</u> **TRACTION** and lubricate traction wheel as follows: min WHEEL Check traction wheel for wobbly or sloppy Frequency rotation. Code: Grease fittings. -M-Q-S-A-2. 3. Clean Pit. TU-1 26. CHECK AND LUBRICATE TAKE-UP. - Check Take-up 5 47 TAKE-UP assembly. Lubricate as necessary. min ASS'Y Frequency Code: ----S-A-AT-1 TRACK CHECK TRACK - Check entire length of track for loose 27. 47 min/ wear bars. Frequency 50 ft. Code: -M-Q-S-A ZZ-1 ROUTE 28. **REPLACE PLATES. -** Replace all cover plates. 10 47 COMPLETION min Frequency Code: -M-Q-S-A-CLEAN-UP 29. CLEAN- UP. - Ensure all tools, lubricants, rags, etc., are 3 ΑII removed from the work area. Report all deficiencies to

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | | |
|-----------------------------|--------------|-----------------|---|-----|---------------|-----|-------------------|-----------|------------|--------|-----------|----|------|--|
| Maintenance Checklist | Work Code | | | . ' | uipm crony | | | Cla Co | ass ode | Number | | er | Туре | |
| | 0 | 3 | T | 0 | W | ٧ | Е | Ζ | Ζ | 0 | 0 | 6 | М | |
| Equipment Nomenclature | | Equipment Model | | | | | Bulletin Filename | | | | Frequency | | | |
| TOWVEYOR (TAKEAWAY), TYPE F | | ACCO | | | | | M94154AC | | | | ALL | | | |

| Part or | Item | Task Statement and Instruction | Est. | Min |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| , | | | Req'd | Level |

Frequency Code:

your supervisor.

-M-Q-S-A-

WARNING

Be cautious when working around or on equipment when power has been applied.

SYSTEM

30. RESTORE EQUIPMENT TO SERVICE. - Restore equipment to service as prescribed by the procedures contained in, or locally developed in accordance with, the

3 ΑII min

Frequency Code: -M-Q-S-A-

current Maintenance Management Order (MMO) providing lockout/restore procedures.

START-UP

31. START-UP. - Perform normal start-up procedures as follows:

5 ΑII min

Frequency Code: -M-Q-S-A-

- Start or preset equipment.
- 2. Check for proper operation.
- 3. Report all deficiencies to your supervisor in order to initiate any necessary work orders to make necessary repairs, or to remove excessive debris.