MAINTENANCE TECHNICAL SUPPORT CENTER / MAINTENANCE POLICIES & PORTAL SERVICE

Maintenance managemen LIVITED STATES POSTAL SERVICETM POSTAL SER

SUBJECT: PM Guidelines for Towveyor (Spur), Type C

(SI Handling)

TO:

DATE: December 10, 1998

NO: MMO-157-98

Bulk Mail Centers FILE CODE: Y

dewa:M98066AA

| | | Online Change Record |
|----------|-----------|---|
| Change # | Date | Description of Change |
| 2 | 4/22/2022 | Attachment 2, corrected skill level 4, no longer in use, to level 7. |
| 1 | 5/8/2013 | This bulletin has been updated to reflect changes to Attachment 1 Summary. The mathematical calculations were originally added incorrectly. The times have been updated to reflect accurate rollup times using the standard two decimal place rounding. |

This Maintenance Management Order (MMO) supersedes MMO-144-98, dated November 20, 1998 due to recalculation of the roll up times. All other information remains the same.

This Maintenance Management Order (MMO) provides Preventive Maintenance (PM) guidelines for Towveyor (Spur), Type C (SI Handling) and supersedes Maintenance Checklist BO69.

The minimum maintenance skill level to perform each task on the various checklists is included in the Minimum Skill Level column. This does not preclude higher level employees from performing any of this work.

WARNING

Various products which require Material Safety Data Sheets (MSDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current MSDS for each product used is on file and available by all employees. When reordering such a product, it is suggested that a current MSDS be requested.

The workhours represented in this MMO reflect the maximum workhours required to maintain the equipment. Given local conditions, management may modify task frequencies.

For questions or comments concerning this bulletin contact the MTSC HelpDesk, either online at MTSC>HELPDESK>Create/Update Tickets or call (800) 366-4123.

Rex M. Gallaher Manager Maintenance Technical Support Center Maintenance Policies and Programs

Attachments: 1. Summary of Revised Workload Estimate

2. Towveyor (Spur), Type C (SI Handling) Master Checklist

1

ATTACHMENT 1

-SUMMARY-

REVISED WORKLOAD ESTIMATE

FOR

TOWVEYOR (SPUR), TYPE C (SI HANDLING)

| Routine Servicing (hrs/yr) | Repair* (hrs/yr) | Total Servicing & Repair Time (hrs/yr) | Nonproductive Time ** (hrs/yr) | Total Servicing Per Machine (hrs/yr) |
|----------------------------------|---------------------|--|--------------------------------------|--|
| 26.04 | 7.81 | 33.85 | 3.39 | 37.23 |

^{*} Repair estimates based on 30% of servicing.

TIME TOTALS

Monthly Time Total:

Quarterly Time Total:

Annual Time Total:

0.90 Hrs. ***

NOTE

The time shown does not allow for multiple assemblies on any equipment. Should multiple assemblies exist, the time must be modified at the local level to account for those occurrences. Other unique site conditions that require additional time are to be addressed at the local level.

^{**} Based on 10% of total servicing and repair.

^{***} These times are provided for data entry for the MARS System.

THIS PAGE BLANK

ATTACHMENT 2

TOWVEYOR (SPUR), TYPE C (SI HANDLING) MASTER CHECKLIST

03-TOWVE-SA-002-M

The "Part or Component" column for each step on the Master Checklist provides a "Frequency Code" designation followed by a letter or series of letters. These letters correspond to the frequency codes as published in MS-63 and specify the frequency for which that instruction (step) must be performed. These frequency codes are in compliance with NMICS superseding route structure. The possible frequencies and their codes are given in the table below:

Table 2-1. MS-63 (NMICS) Frequency-Codes

| CODE | FREQUENCY | DESCRIPTION |
|------|-------------------|-------------------------------|
| Α | ANNUAL | Once every 13 APs. |
| В | BI-WEEKLY | Once every 2 weeks |
| С | BI-MONTHLY | Once every 2 APs. |
| D | DAILY | Once a day; 7 days a week. |
| Ε | DAILY | Once a day; 6 days a week. |
| F | DAILY | Once a day; 5 days a week. |
| G | DAILY | Once a day; 4 days a week. |
| Н | DAILY | Once a day; 3 days a week. |
| J | SEMI-WEEKLY | 2 days a week. |
| K | BI-ANNUAL | Once every 2 years. |
| L | TRI-ANNUAL | Once every 3 years. |
| M | MONTHLY | Once every AP. |
| Ν | QUAD-ANNUAL | Once every 4 years. |
| Р | QUINT-ANNUAL | Once every 5 years. |
| Q | QUARTERLY | 4 times every 13 APs. |
| S | SEMI-ANNUAL | Twice every 13 AP. |
| Т | TOURLY | 3 times a day; 7 days a week. |
| U | TOURLY | Twice a day; 7 days a week. |
| V | TOURLY | 3 times a day; 6 days a week. |
| W | WEEKLY | Once a week. |
| X | TOURLY | Twice a day; 6 days a week. |
| Υ | TOURLY | 3 times a day; 5 days a week. |
| Z | TOURLY | Twice a day; 5 days a week. |
| WITH | ALL SAFETY PRECAU | ITIONS 3 All |

SAFETY STATEMENT

Frequency Code: -M-Q---A- COMPLY WITH ALL SAFETY PRECAUTIONS. - 3
Disconnect power and activate lockouts as appropriate while working on this equipment. Where air pressure is required for cleaning, use a low air pressure (30 psi or less) air source. Eye protection (goggles or face shield) must be used when utilizing compressed air for cleaning. Check to ensure all employees are clear of the machine. Report safety deficiencies to your supervisor immediately upon detection.

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | |
|--|----------|-----------------------------|---|---|---------------|----------------------------|------|---------------|-----|---------------|---|------|---|
| Maintenance Checklist | Wo Co | ork ide | | | uipm crony | | | Class Code | | Number | | Туре | |
| | 0 | 3 | Т | 0 | W | ٧ | Е | S | Α | 0 | 0 | 2 | M |
| Equipment Nomenclature TOWVEYOR (SPUR), TYPE C | | Equipment Model SI HANDLING | | | | Bulletin Filename M98066AA | | | | Frequency ALL | | | |

| | T | | | |
|-----------|------|--|-------|-------|
| Part or | Item | Task Statement and Instruction | Est. | Min. |
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| 1 | | | Rea'd | Level |

AA-1

CHECK FOR MAIL. - Look for loose mail while 2.5 47
performing activities. min

Frequency Code: -M-Q---A-

WARNING

Eye protection (goggles or face shield) must be worn when using compressed air, steam, or a high pressure cleaner/washer device for cleaning.

CH-1 TOWPIN 3. CLEAN CHAIN. -

1 4<u>7</u> min

<u>47</u>

<u>47</u>

per

10. ft.

per 10 ft.

CHAIN Frequency

Code: -----A-

1. Clean chain with steam or high pressure cleaner/washer device.

2. Run chain at least one (1) complete cycle.

3. Remove foreign material by blowing or vacuuming.

CH-1 TOWPIN CHAIN (Cont.) **LUBRICATE CHAIN. -** With equipment operating, pour 1 GL-4 slowly over return strand of chain. Two (2) min complete turns.

Frequency Code: -M-Q---A-

DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE

CHECK BRAKE. - With equipment operating, perform the following:

1. Check for proper brake action.

2. Feel for vibration.

Frequency Code: ----Q---A-

2

3. Listen for noise.

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | |
|-------------------------|--------------|-------|------------------|-----|---|------|--------|---------------|-----|--------|------|-----|------|
| Maintenance Checklist | Work Code | | Equipm Acrony | | | | | Class Code | | Number | | | Туре |
| | 0 | 3 | Т | 0 | W | ٧ | Е | S | Α | 0 | 0 | 2 | M |
| Equipment Nomenclature | | ıipme | nt Mo | del | | Bull | etin F | ilena | me | Fre | quen | су | |
| TOWVEYOR (SPUR), TYPE C | | | ND | LIN | G | M | 980 | 66A | Α | | | ALL | - |

| Part or Component | Item No. | Task Statement and Instruction (Comply with all current safety precautions) | Est. Time Req'd | Min. Skill Level |
|-------------------------------|-------------|--|---------------------------|------------------------|
| SYSTEM Frequency Code: -M-QA- | 6. | POWER DOWN AND LOCKOUT POWER Power down the equipment and lockout its electrical power as prescribed by the procedures contained in, or locally developed in accordance with, the current Maintenance Management Order (MMO) providing lockout/restore procedures. | 1 min | 4 <u>7</u> |
| Frequency Code: -M-QA- | 7. | REMOVE COVER PLATES Remove cover plates. Erect barricades around open pits. | 20 min | 4 <u>7</u> |
| CH-1 TOWPIN CHAIN | 8. | CHECK CHAIN. - Check chain for bent, cracked, or excessively worn links. Jog if necessary. | 1 min per 10 ft. | 4 <u>7</u> |
| Frequency Code: | | | 10 11. | |

WARNING

Eye protection (goggles or face shield) must be worn when using compressed air for cleaning.

WARNING

soaked Discard solvent materials according to local procedures to prevent spontaneous combustion.

CS-1 CONTAINER **SENSORS**

----Q---A-

CLEAN PIT, SWITCH HOUSING, AND ACTUATOR **ARM.** - With disconnect locked out, perform the following:

4<u>7</u> min/

10

unit

1. Clean dirt and accumulated material from pit.

Frequency Code: ----Q---A-

Clean switch housing and actuator arm with solvent.

Attachment 2

3

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | |
|-------------------------|------------------------------|------------|------------------|---|---|-----|--------------------|---------------|-----|--------|---|------|---|
| Maintenance Checklist | Wo Co | ork ode | Equipm Acrony | | | | | Class Code | | Number | | Туре | |
| | 0 | 3 | Т | 0 | W | ٧ | Ε | S | Α | 0 | 0 | 2 | M |
| Equipment Nomenclature | Equipment Model Bulletin Fil | | | | | | Filename Frequency | | | | | | |
| TOWVEYOR (SPUR), TYPE C | SI HANDLING M98066AA AI | | | | | | ALL | | | | | | |

| Part or Component | Item No. | Task Statement and Instruction (Comply with all current safety precautions) | Est. Time Req'd | Min. Skill Level |
|--|-------------|---|-----------------------|------------------------|
| Frequency Code: QA- | 10. | CHECK SWITCH AND ACTUATOR ARM Look for proper positioning and secure mounting of switch and actuator arm. | 1 min | 4 <u>7</u> |
| Frequency Code: QA- | 11. | LUBRICATE AND CHECK PIVOT POINT Lubricate and check pivot point as follows: | 2 min | 4 <u>7</u> |
| | | Lubricate pivot point. | | |
| | | Operate by hand to see if it is sluggish or binding. | | |
| | | 3. Check for damage. | | |
| Frequency Code: QA- | 12. | CHECK SWITCH MOUNTING Check switch mounting and for freedom of movement in direction of chain travel. | 2 min | 4 <u>7</u> |
| DA-3 SIDE FINGER DRIVE WITH MOTOR | 13. | CHECK CHAIN LUBRICANT LEVEL AND ADJUST VALVE Check lubricant level and adjust valve as follows: | 10 min | 4 <u>7</u> |
| BRAKE | | 1. Check level of lubricant in chain lubricator. | | |
| Frequency | | 2. Refill with GL-3. | | |
| Code: -M-QA- | | Adjust valve on oil container to provide small steady stream to chain for two complete passes. Nozzle should be over center of chain. | | |
| Frequency Code: -M-QA- | 14. | CHECK V-BELTS AND SHEAVES Check V-belts and sheaves for wear and alignment. | 2 min | 4 <u>7</u> |
| Frequency Code: -M-QA- | 15. | CLEAN V-BELT AND SHEAVES Clean foreign material from belts and sheaves by wiping with clean rags. | 4 min | 4 <u>7</u> |
| Frequency Code: -M-QA- | 16. | CHECK SHEAVES. - Check sheave's set screws and belt tension. | 2 min | 4 <u>7</u> |

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | |
|-------------------------|---|------------|----|-----|---------------|------|--------|---------------|-----|-----------|---|------|---|
| Maintenance Checklist | | ork ode | | | uipm crony | | | Class Code | | Number | | Туре | |
| | 0 | 3 | Т | 0 | W | ٧ | Ε | S | Α | 0 | 0 | 2 | M |
| Equipment Nomenclature | | Equipme | | del | | Bull | etin F | ilena | me | Frequency | | | |
| TOWVEYOR (SPUR), TYPE C | S | I HA | ND | LIN | G | M | 980 | 66 <i>F</i> | ۱A | | | ALL | - |

| Part or Component | Item No. | Task Statement and Instruction (Comply with all current safety precautions) | Est. Time Req'd | Min. Skill Level |
|---|-------------|--|-----------------------|------------------------|
| Frequency Code: QA- | 17. | CHECK CHAIN ADJUSTMENT Check chain for proper adjustment. Adjust, if necessary, at take-up screws on drive assembly. | 4 min | 4 <u>7</u> |
| Frequency Code: QA- | 18. | CLEAN AND CHECK CRITICAL SPEED SWITCH Clean and check critical speed switch. | 5 min | 4 <u>7</u> |
| Frequency Code: QA- | 19. | CHECK BROKEN-CHAIN SWITCH. - Check brokenchain switch for secure mount and freedom of movement. Lubricate pivot points with HY-1. | 3 min | 4 <u>7</u> |
| DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE (Cont.) Frequency Code: QA- | 20. | CHECK MOTOR AND REDUCER Check motor and reducer for lubrication leaks. | 2 min | 4 <u>7</u> |
| Frequency Code: QA- | 21. | CLEAN AND CHECK COUPLING Clean and check coupling as follows: 1. Clean and check coupling. 2. Wrench test set screws. 3. Feel keys for tightness. | 10 min | 4 <u>7</u> |
| Frequency Code: QA- | 22. | LUBRICATE GEAR REDUCER. - Add grease to gear reducer. Grease may be applied through a grease nipple provided on the top of the high speed end shield. Amount added should be equal to approximately 1/3 of normal fill. | 20 min | 4 <u>7</u> |

Maintenance Technical Support Center

| U.S. Postal Service | | | | | | IDE | NTIF | ICAT | ION | | | | | |
|-------------------------|---|-----------------|------------------|-----|---|-----|------|-------------------|-----|--------|---|-----------|------|--|
| Maintenance Checklist | | ork ode | Equipm Acrony | | | | | Class Code | | Number | | er | Туре | |
| | 0 | 3 | Т | 0 | W | ۷ | Е | S | Α | 0 | 0 | 2 | M | |
| Equipment Nomenclature | | Equipment Model | | | | | | Bulletin Filename | | | | Frequency | | |
| TOWVEYOR (SPUR), TYPE C | | I HA | ND | LIN | G | M | 980 | 66A | ١A | ALL | | | | |

| Part or | Item | Task Statement and Instruction | Est. | Min. |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| · | | , | Rea'd | Level |

WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

Frequency Code: ----Q---A-

- 3. **CHECK AND CLEAN SPROCKET. -** Check and clean 10 47 sprocket as follows:
 - 1. Check sprocket for wear and alignment.
 - 2. Wrench test set screws.
 - 3. Clean sprocket with solvent and rags.

DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE (Cont.) Frequency Code: -------A- LUBRICATE MOTOR. - Remove grease relief plug. For motors 1/2 HP and over, apply 2 pumps of GR-2.

4<u>4</u> min <u>47</u>

Formatted Table

WARNING

Be cautious when working around or on equipment when power has been applied.

RESTORE EQUIPMENT TO SERVICE. - Restore SYSTEM ΑII equipment to service as prescribed by the procedures min contained in, or locally developed in accordance with, the Frequency Code: current Maintenance Management Order (MMO) providing lockout/restore procedures. Frequency RUN MOTOR. - Run motor for one minute 1 <u>47</u> Code: min SYSTEM POWER DOWN AND LOCKOUT POWER. - Power 4<u>7</u> down the equipment and lockout its electrical power as

| U.S. Postal Service | IDENTIFICATION | | | | | | | | | | | | |
|--|-----------------------------|---|---|----------------------------|---------------|---|---|---------------|---|--------|---|---|------|
| Maintenance Checklist | Work Code | | | | uipm crony | | | Class Code | | Number | | | Туре |
| | 0 | 3 | T | 0 | W | ٧ | Е | S | Α | 0 | 0 | 2 | M |
| Equipment Nomenclature TOWVEYOR (SPUR), TYPE C | Equipment Model SI HANDLING | | | Bulletin Filename M98066AA | | | | Frequency ALL | | | | | |

| Part or Component | Item No. | Task Statement and Instruction (Comply with all current safety precautions) | Est. Time Req'd | Min. Skill Level |
|--|-------------|--|-----------------------|------------------------|
| Frequency Code: A- | | prescribed by the procedures contained in, or locally developed in accordance with, the current Maintenance Management Order (MMO) providing lockout/restore procedures. | | |
| DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE | 28. | REPLACE RELIEF PLUG Replace grease relief plug. | 1 min | 4 <u>7</u> |
| Frequency Code: A- DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE (Cont.) | 29. | LUBRICATE COUPLING Drain and refill coupling with same quantity HY-1 lubricant. | 10 min | 4 <u>7</u> |
| Frequency Code: A- | | | | |
| Frequency Code: A- | 30. | CHECK LUBRICANT ON SHAFT BEARINGS Check bearings for adequate lubricant. Apply new lubricant as necessary, use lubricant GR-2 | 30 min | 4 <u>7</u> |
| Frequency Code: QA- | 31. | CLEAN DRIVE PIT Clean drive pit. | 30 min | 4 <u>7</u> |

WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

Attachment 2

7

Maintenance Technical Support Center

| U.S. Postal Service | IDENTIFICATION | | | | | | | | | | | | |
|--|----------------|---|-----------------------------|---|---|----------------------------|---|---------------|---|---------------|---|------|---|
| Maintenance Checklist | Work Code | | Equipm Acrony | | | - | | Class Code | | Number | | Туре | |
| | 0 | 3 | Т | 0 | W | ٧ | Ε | S | Α | 0 | 0 | 2 | M |
| Equipment Nomenclature TOWVEYOR (SPUR), TYPE C | | | Equipment Model SI HANDLING | | | Bulletin Filename M98066AA | | | | Frequency ALL | | | - |

| Part or | Item | Task Statement and Instruction | Est. | Min. |
|-----------|------|--|-------|-------|
| Component | No. | (Comply with all current safety precautions) | Time | Skill |
| | | | Pog'd | Lovol |

DS-1 DIVERTERS 32. CLEAN TRACK SWITCH PITS AND SWITCH 15 47 HOUSING. - With disconnect locked out, perform the min following:

Frequency Code: ----Q---A-

- Remove dirt and accumulated debris from track switch pits.
- 2. Clean switch housing using solvent and rags.
- 3. Check operation by unlatching switching blade.

WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

DS-1 DIVERTERS (Cont.) 33. CLEAN AND CHECK SOLENOID HOUSING, 3 47
PLUNGER ROD, AND LINKAGE. - Clean and check min solenoid housing, plunger rod, and linkage as follows:

Frequency Code: ----Q---A-

- Using rags and solvent, clean solenoid housing, plunger rod, and linkage.
- 2. Check plunger rod for free movement.
- 3. Check solenoid mounting and switch blade.

Frequency Code: ----Q---A- LUBRICATE LINKAGE. - Lightly lubricate all linkage and 2 pivot points on solenoid and brake assembly with HY-1. min

AT-1 TRACK

35. **CHECK TRACK. -** Check entire length of track for loose wear strips.

1 4<u>7</u> min/

50 ft.

Frequency Code: -M-Q---A-

Item

Est.

| U.S. Postal Service | IDENTIFICATION | | | | | | | | | | | | |
|-------------------------|-----------------|-----------|-------------|---|---------------|-------------------|----------|---------------|---|-----------|---|---|------|
| Maintenance Checklist | Wo Co | ork de | | | uipm crony | | | Class Code | | Number | | | Туре |
| | 0 | 3 | Т | 0 | W | ٧ | Е | S | Α | 0 | 0 | 2 | M |
| Equipment Nomenclature | Equipment Model | | | | | Bulletin Filename | | | | Frequency | | | |
| TOWVEYOR (SPUR), TYPE C | | | SI HANDLING | | | | M98066AA | | | | | | |

Task Statement and Instruction

| Component | No. | (Comply with all current safety precautions) | Time Req'd | Skill Level |
|-------------------------------|-----|--|---------------|----------------|
| ZZ-1 ROUTE COMPLE- TION | 36. | REPLACE COVER PLATES Replace all cover plates. | 20 min | 4 <u>7</u> |
| Frequency | | | | |

Code:

Part or

-M-Q---A-

CLEAN-UP

Frequency your superviso Code:
-M-Q---A-

CLEAN- UP. -.Ensure all tools, lubricants, rags, etc., are a semoved from the work area. Report all deficiencies to min your supervisor.

WARNING

Be cautious when working around or on equipment when power has been applied.

SYSTEM 38. RESTORE EQUIPMENT TO SERVICE. - Restore 3 All equipment to service as prescribed by the procedures min contained in, or locally developed in accordance with, the Code: current Maintenance Management Order (MMO) providing lockout/restore procedures.

START-UP 39. **START-UP. -** Perform normal start-up procedures as 5 All follows:

Frequency Code: -M-Q---A-

1. Start or preset equipment.

2. Check for proper operation.

 Report all deficiencies to your supervisor in order to initiate any necessary work orders to make necessary repairs, or to remove excessive debris. Formatted Table