MAINTENANCE TECHNICAL SUPPORT CENTER / MAINTENANCE POLICIES & PROGRAMS ENGINEERING / UNITED STATES POSTAL SERVICE



Maintenance Management Order

SUBJECT: Preventive Maintenance Guidelines for DATE: May 15, 2006

Automated Airline Assignment System

NO: MMO-051-06

TO: All Automated Airline Assignment System Offices FILE CODE: F3

same:mm06072aa

MAINTENANCE MANAGEMENT ORDER

Daily Checklist, Item 7, substep 2, 3 & 4 and Item 8, substep 1 & 2 have added information for checking the D&R label and Scale check.

This Maintenance Management Order (MMO) supersedes MMO-136-01. This MMO provides Preventive Maintenance (PM) guidelines for the Automated Airline Assignment System (AAA) with updated minimum skill levels.

The minimum maintenance skill level to perform each task on the various checklists is included in the Minimum Skill Level column. This does not preclude higher level employees from performing any of this work.

The work hours represented in this MMO reflect the maximum work hours required to maintain the equipment. Given local conditions, management may modify task frequencies.

WARNING

Various products which require Material Safety Data Sheets (MSDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current MSDS for each product used is on file and available by all employees. When reordering such a product, it is suggested that a current MSDS be requested. Refer to MSDS for appropriate personal protective equipment.

WARNING

The use of compressed or blown air is prohibited. An alternative cleaning method such as a HEPA filtered vacuum cleaner, damp rag, lint-free cloth, or brush must be used in place of compressed or blown air.

Maintenance Managers are to use these Preventive Maintenance guidelines when preparing the route sheets for local maintenance personnel.

For questions or comments concerning this bulletin contact the MTSC HelpDesk, either online at MTSC>HELPDESK>Create/Update Tickets or call (800) 366-4123.

Earl J. Jones Manager Maintenance Technical Support Center Maintenance Policies and Programs

Attachments: 1. Summary Workload Estimate for AAA

AAA Master Checklist: 03-AAA-AA-001-M: Daily
 AAA Master Checklist: 03-AAA-AA-002-M: Weekly
 AAA Master Checklist: 03-AAA-AA-003-M: Monthly

MAINTENANCE MANAGEMENT ORDER

ATTACHMENT 1

SUMMARY

WORKLOAD ESTIMATE

FOR

AAA

SUMMARY WORKLOAD ESTIMATE FOR AAA

Routine Servicing (hrs/yr)	Repair* (hrs/yr)	Total Servicing & Repair Time (hrs/yr)	Nonproductive Time ** (hrs/yr)	Total Servicing Per Machine (hrs/yr)
210	21	231	23	254

Service Condition is based on a seven day per week operation.

- * Repair estimates based on 10% of servicing.
- ** Based on 10% of servicing and repair.

PM CHECKLIST TIME SUMMARY

MAINTENANCE MANAGEMENT ORDER

Checklist	Checklist Times (per year)
03-AAA-AA-001-M (Daily)	10950 minutes
03-AAA-AA-002-M (Weekly)	1300 minutes
03-AAA-AA-003-M-(Monthly)	348 minutes

ATTACHMENT 2

AUTOMATED AIRLINE ASSIGNMENT SYSTEM

03-AAA-AA-001-M

DAILY

AAA

TIME TOTALS: 30 Minutes

Refer to MS-179 if additional maintenance information is required.

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Maintenance Checklist		Work Equipment Code Acronym						Cla Co	ass ide	Number			Type
Maintenance Oneckinst		3	Α	Α	A			Α	Α	0	0	1	M
Equipment Nomenclature		Equipment Model				Bulle	etin F	ilena	me	Free			
Automated Airline Assignment	AAA					M١	<i>1</i> 06	072	AΑ			AIL	Υ

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
•			Req'd	Level

SAFETY STATEMENT

1.

COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED.

When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner, a damp cloth, lint-free cloth, or brush, must be used in place of compressed or blown air. Report safety deficiencies to your supervisor immediately upon detection.

MACHINE

MAINTENANCE MANAGEMENT ORDER

- 2. **Power down and lockout power.** Power down the 3 machine and lockout its electrical power as prescribed by MIN the current local lockout instructions providing lockout/restore procedures.
 - 3 All MIN

5

ΑII

SCANNER

3. Clean the 6 scanner windows. Spray a lint free cloth 3 6 with glass cleaner and gently wipe the scanner window. MIN

WARNING

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED. An alternative cleaning method such as a HEPA filtered vacuum cleaner, damp rag, lint-free cloth, or brush must be used in place of compressed or blown air.

SYSTEM 4. **Cleaning and mail search.**

5 6 MIN

- 1. Vacuum each module of the AAA.
- 2. Complete a mail search and return any found mail to the appropriate mail stream.

8

U.S. Postal Service						IDEI	NTIF	ICAT	ION				
Maintenance Checklist	Wo				uipm				ass		l l.		T
Maintenance Checkiist	Code Acronym			m		Co	de	N	lumb	er	Type		
	0	3	Α	Α	Α			Α	Α	0	0	1	M
Equipment Nomenclature Automated Airline Assignment		Equipment Model					etin F	ilena	me	Free			
		AAA					106	072	AA		D	AIL	Υ

Part or	Item	Task Statement and Instruction (Comply with all current safety precautions)	Est.	Min.
Component	No.		Time	Skill
		(, ,	Req'd	Level

5. **Visually check** all rollers, belts, and photo sensors for worn or defective parts. MIN

WARNING

Be cautious when working around or on equipment when power has been applied.

MACHINE 6. **Restore equipment to service.** Return AAA to normal 4 8 operation. MIN

SCALE 7. **Test scale for functionality.**

1 8 MIN

NOTE

If scale does not return to zero refer to MS handbook for the scale alignment/adjustment procedure.

1. Check weight display for a zero reading.

NOTE

If discrepancies are found place the equipment out of service.

- 2. Place a calibrated known weight on the scale.
- 3. Ensure the scale is reading the correct weight ± .05 pounds of calibrated weight.
- 4. If no discrepancies are found remove weight and check display for a zero reading.

PRINTER LABEL APPLICATOR

MAINTENANCE MANAGEMENT ORDER

- 8. **Test printer label applicator** for proper operation.
 - 1. Print a test label.

3 MIN 8

2. Check the label quality to ensure it does not have any defects as described in MMO-012-09.

NOTE

If discrepancies are found place the equipment out of service.

MAINTENANCE MANAGEMENT ORDER

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Mat de la companya de la contraction		1.					Cla	ass					
Maintenance Checklist	Co	Code			crony	/m		Co	de	N	lumb	er	Type
	0	3	Α	Α	Α			Α	Α	0	0	1	M
Equipment Nomenclature		iipme	nt Mo	del		Bull	etin F	ilena	me	Fre			
Automated Airline Assignment		AAA					<i>1</i> 06	072	AA			Υ	

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
·			Req'd	Level

CLEAN UP 9. Clean up.

3 All MIN

NOTE

If problems are found and can be corrected on this tour generate a Reactive workorder and correct the problem. If the problem cannot be corrected on this tour generate a Corrective workorder so that the work can be scheduled.

Ensure all tools, lubricants, rags, etc., are removed from the work area. Report all deficiencies to your supervisor.

ATTACHMENT 3

AUTOMATED AIRLINE ASSIGNMENT SYSTEM

03-AAA-AA-002-M

WEEKLY

AAA

TIME TOTALS: 25 Minutes

Refer to MS-179 if additional maintenance information is required.

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Maintenance Checklist		ork ode	Equipment Acronym					Cla Co	ass de	Number			Type
	0	3	Α	Α	Α			Α	Α	0	0	2	M
Equipment Nomenclature		Equipment Model					etin F	ilena	me	Frequency			
Automated Airline Assignment			AAA	١		M١	<i>1</i> 06	072	AΑ		WI	EEK	ĹΥ

	Part or Component	Item No.	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill
ı	, , , , , ,		(, ,	Req'd	Level

SAFETY STATEMENT

1.

COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED.

When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner, a damp cloth, lint-free cloth, or brush, must be used in place of compressed or blown air. Report safety deficiencies to your supervisor immediately upon detection.

MACHINE

MAINTENANCE MANAGEMENT ORDER

2. **Power down and lockout power.** Power down the machine and lockout its electrical power as prescribed by the current local lockout instructions providing lockout/restore procedures.

3 All MIN

5

ΑII

PRINTER APPLICATOR

3.

Clean printer applicator.

2 6 MIN

- 1. Rotate the printhead lever clockwise (CW) until the printhead releases.
- 2. Remove material and ribbon as necessary.
- Remove dirt, adhesive, or debris from the bottom printhead print surface with a cotton swab and appropriate cleaning solution.
- 4. Moisten a lint free cloth with an approved cleaning solution and clean roller surface to remove any adhesive and/or debris.

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Maintanana Obsaldiat		Work Equipment Class											
Maintenance Checklist	Code Acronyr				m		Co	de			Type		
	0	3	Α	Α	Α			Α	Α	0	0	2	M
Equipment Nomenclature		Equipment Model					etin F	ilena	me	Frequency			
Automated Airline Assignment	AAA					MN	106	072	AA		WI	EEK	LY

Part or	Item	Task Statement and Instruction (Comply with all current safety precautions)	Est.	Min.
Component	No.		Time	Skill
Component	INO.	(Comply with all current safety precautions)	Req'd	Level

GUIDES AND 4. Clean material path. PATH

MAINTENANCE MANAGEMENT ORDER

3 6 MIN

NOTE

Lower material guide is spring loaded and must be held open during cleaning process. Pull down lower material guide to access material path.

- 1. Moisten a lint free cloth with an appropriate cleaning solution. Clean the lower material guide.
- 2. Remove all traces of dust, paper, and adhesive from the material path with a soft bristle brush or vacuum cleaner.
- Moisten a lint free cloth with an appropriate cleaner and clean all flat surfaces in the material path, including the edge guide.
- 4. Release the lower material guide.
- 5. Reinstall ribbon and materials.
- 6. Rotate printhead lever counterclockwise (CCW) until it locks in place.

CONVEYOR 5. Clean roller and o-rings. Moisten a lint free cloth with 5 6 an appropriate cleaning solution and clean the conveyor MIN o-rings and rollers.

MACHINE 6. **Restore equipment to service.** Return AAA to normal 4 8 service. MIN

CLEAN UP 7. Clean up. Ensure all tools, lubricants, rags, etc., are 3 All removed from the work area. Report all deficiencies to MIN your supervisor.

U.S. Postal Service	IDENTIFICATION												
Maintananaa Chaaldiat		ork			uipm				ass				_
Maintenance Checklist		Code		Acrony			/m		Code		Number		Type
	0	3	Α	Α	Α			Α	Α	0	0	2	M
Equipment Nomenclature		ipme	ent Model			Bulletin Filename			me	Frequency			
Automated Airline Assignment						MM06072AA				WEEKLY			

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
			Req'd	Level

THIS PAGE BLANK

ATTACHMENT 4

AUTOMATED AIRLINE ASSIGNMENT SYSTEM

03-AAA-AA-003-M

MONTHLY

AAA

TIME TOTALS: 29 Minutes

Refer to MS-179 if additional maintenance information is required.

5

ΑII

U.S. Postal Service	IDENTIFICATION												
Maintenance Checklist		Work Code		Equipm Acrony					Class Code		Number		Type
	0	3	Α	Α	Α			Α	Α	0	0	3	M
Equipment Nomenclature	Equipment Mode					Bulle	etin F	ilena	me	Frequency			
Automated Airline Assignment						MM06072AA			MONTHLY				

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
			Req'd	Level

SAFETY STATEMENT

1.

COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED.

When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner, a damp cloth, lint-free cloth, or brush, must be used in place of compressed or blown air. Report safety deficiencies to your supervisor immediately upon detection.

WARNING

Be cautious when working around or on equipment when power has been applied.

MACHINE

MAINTENANCE MANAGEMENT ORDER

2. **Power down and lockout power.** Power down the machine and lockout its electrical power as prescribed by the current local lockout instructions providing lockout/restore procedures.

3 All MIN

LABEL MARK SENSOR 3.

Clean the label mark sensor.

2 MIN 6

- 1. Rotate the printhead lever clockwise (CW) until the printhead releases.
- 2. Remove material and ribbon as necessary.
- 3. Remove dust, paper, and other debris from label mark sensor with a soft bristle brush or vacuum.
- 4. Moisten cotton swab with appropriate cleaning solution and clean the label mark sensor.

U.S. Postal Service	IDENTIFICATION													
Maintenance Checklist		ork ode		'	uipm cronv			Cla Co	ass ide	N	lumb	er	Type	
I I I I I I I I I I I I I I I I I I I	0	3	Α	Α	A			Α	Α	0	0	3	M	
Equipment Nomenclature	Equipment Model					Bulle	etin F	ilena	me	Frequency				
Automated Airline Assignment		AAA					MM06072AA				MONTHLY			

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
			Req'd	Level

LABEL GAP **SENSOR**

MAINTENANCE MANAGEMENT ORDER

4. Clean the label gap sensor. 2 6

MIN

NOTE

Lower material guide is spring loaded and during held open must be cleaning procedure.

- 1. Pull down lower material guide to access the label gap sensor.
- 2. Remove dust, paper, and other debris with a soft bristle brush or vacuum cleaner.
- 3. Moisten a cotton swab with an appropriate cleaning solution and clean the label gap sensor.
- 4. Release lower material guide.
- Install ribbon and materials.
- 6. Rotate printhead counterclockwise (CCW) until it locks in place.

WARNING

Some electrical components such as capacitors may hold a charge and electrical shock can cause severe injury. Exercise care when working inside the printer /applicator compartment.

PRINTER LABEL **APPLICATOR** HOUSING

5. Clean inside printer applicator housing.

2 MIN

6

- 1. Loosen latches on back panel and open panel.
- 2. Clean all dust and debris using a soft bristle brush and vacuum cleaner.
- 3. Close back panel and latch.

MACHINE

Restore equipment to service. Return AAA to normal 6. operation.

MIN

8

U.S. Postal Service	IDENTIFICATION												
Maintenance Checklist		Work Code		Equipm Acrony					Class Code		Number		Type
	0	3	Α	Α	Α			Α	Α	0	0	3	M
Equipment Nomenclature	Equ	ipme	nt Mc	del	Bulletin F			ilena	me	Frequency			
Automated Airline Assignment						MM06072AA			MONTHLY				

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
			Req'd	Level

IN MOTION SCALE

7. Check Trim.

5 8 MIN

3

MIN

8

the

- 1. Place a weight between 20 and 50 pounds in the center of the scale.
- 2. Record weight.
- 3. Place the weight at the center of one end of the scale, directly above the weighing bar assembly, and record the weight.
- 4. Place the weight at the center of the other end of the scale, above the weighing bar assembly, and record the weight.
- 5. Verify the weight recordings are within \pm 0.05 lbs.
- 6. If the weights are not within ± 0.05 lbs., record the difference between the two weight readings and adjust the trim and re-calibrate the scale. Refer to MS handbook for trim and calibration procedures.

PRINTER LABEL APPLICATOR 8.

9.

Test printer label applicator for proper operation. Print 2 or 3 test labels. Looks for poor or incorrect print quality.

CLEAN UP

MAINTENANCE MANAGEMENT ORDER

Clean up. Ensure all tools, lubricants, rags, etc., are 3 All removed from the work area. Report all deficiencies to MIN your supervisor.