MAINTENANCE TECHNICAL SUPPORT CENTER / MAINTENANCE POLICIES & PROGRAMS ENGINEERING / UNITED STATES POSTAL SERVICE

# maintenance management order

**SUBJECT:** PM Guidelines for Towveyor (Unloaders), **DATE:** December 10, 1998

Type E (SI Handling)

**NO:** MMO-160-98

TO: Bulk Mail Centers FILE CODE: Y

dewa:M98069AA

	Online Change Record									
Change #	Date	Description of Change								
2	4/22/2022	Attachment 2, corrected skill level 4, no longer in use, to level 7.								
1	5/16/2013	This bulletin has been updated to reflect changes to the Attachment 1 Summary. The times have been updated to reflect accurate rollup times using the standard two decimal place rounding.								

This Maintenance Management Order (MMO) supersedes MMO-151-98, dated November 30, 1998 due to recalculation of the roll up times. All other information remains the same.

This Maintenance Management Order (MMO) provides Preventive Maintenance (PM) guidelines for Towveyor (Unloaders), Type E (SI Handling) and supersedes Maintenance Checklist B071.

The minimum maintenance skill level to perform each task on the various checklists is included in the Minimum Skill Level column. This does not preclude higher level employees from performing any of this work.

## WARNING

Various products which require Material Safety Data Sheets (MSDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current MSDS for each product used is on file and available by all employees. When reordering such a product, it is suggested that a current MSDS be requested.

The workhours represented in this MMO reflect the maximum workhours required to maintain the equipment. Given local conditions, management may modify task frequencies.

For questions or comments concerning this bulletin contact the MTSC HelpDesk, either online at MTSC>HELPDESK>Create/Update Tickets or call (800) 366-4123.

Rex M. Gallaher Manager Maintenance Technical Support Center Maintenance Policies and Programs

Attachments: 1. Summary of Revised Workload Estimate

2. Towveyor (Unloaders), Type E (SI Handling) Master Checklist

#### **ATTACHMENT 1**

#### -SUMMARY-

#### **REVISED WORKLOAD ESTIMATE**

#### **FOR**

#### TOWVEYOR (UNLOADERS) TYPE E (SI HANDLING)

Routine Servicing (hrs/yr)	Repair* (hrs/yr)	Total Servicing & Repair Time (hrs/yr)	Nonproductive Time ** (hrs/yr)	Total Servicing Per Machine (hrs/yr)
27.58	8.27	35.85	3.59	39.45

<sup>\*</sup> Repair estimates based on 30% of servicing.

#### TIME TOTALS

Monthly Time Total:	1.26 Hrs.	***
---------------------	-----------	-----

Quarterly Time Total: 2.55 Hrs. \*\*\*

Annual Time Total: 1.02 Hrs. \*\*\*

#### **NOTE**

The time shown does not allow for multiple assemblies on any equipment. Should multiple assemblies exist, the time must be modified at the local level to account for those occurrences. Other unique site conditions that require additional time are to be addressed at the local level.

<sup>\*\*</sup> Based on 10% of total servicing and repair.

<sup>\*\*\*</sup> These times are provided for data entry for the MARS System.

## THIS PAGE BLANK

#### **ATTACHMENT 2**

#### TOWVEYOR (UNLOADERS), TYPE E (SI HANDLING) MASTER CHECKLIST

#### 03-TOWVE-ZZ-004-M

The "Part or Component" column for each step on the Master Checklist provides a "Frequency Code" designation followed by a letter or series of letters. These letters correspond to the frequency codes as published in MS-63 and specify the frequency for which that instruction (step) must be performed. These frequency codes are in compliance with NMICS superseding route structure. The possible frequencies and their codes are given in the table below:

Table 2-1. MS-63 (NMICS) Frequency-Codes

CODE	FREQUENCY	DESCRIPTION
Α	ANNUAL	Once every 13 APs.
В	BI-WEEKLY	Once every 2 weeks
С	BI-MONTHLY	Once every 2 APs.
D	DAILY	Once a day; 7 days a week.
Ε	DAILY	Once a day; 6 days a week.
F	DAILY	Once a day; 5 days a week.
G	DAILY	Once a day; 4 days a week.
Н	DAILY	Once a day; 3 days a week.
J	SEMI-WEEKLY	2 days a week.
K	BI-ANNUAL	Once every 2 years.
L	TRI-ANNUAL	Once every 3 years.
M	MONTHLY	Once every AP.
N	QUAD-ANNUAL	Once every 4 years.
Р	QUINT-ANNUAL	Once every 5 years.
Q	QUARTERLY	4 times every 13 APs.
S	SEMI-ANNUAL	Twice every 13 AP.
T	TOURLY	3 times a day; 7 days a week.
U	TOURLY	Twice a day; 7 days a week.
V	TOURLY	3 times a day; 6 days a week.
W	WEEKLY	Once a week.
Χ	TOURLY	Twice a day; 6 days a week.
Υ	TOURLY	3 times a day; 5 days a week.
Z	TOURLY	Twice a day; 5 days a week.

SAFETY 1. COMPLY WITH ALL SAFETY PRECAUTIONS. - 3 All

U.S. Postal Service	IDENTIFICATION												
Maintenance Checklist		ork ode	Equipment Acronym					Class Code		Number			Туре
	0	3	Т	0	W	٧	Ε	Ζ	Ζ	0	9	2	M
Equipment Nomenclature	Equ	iipme	nt Mc	del		Bull	etin F	ilena	me	Frequency			
TOWVEYOR TYPE E	S	I HA	ND	LIN	G	M	980	69A	Α		Frequency <b>ALL</b>		

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
•			Req'd	Level

#### STATEMENT

Frequency Code: -M-Q--A- Disconnect power and activate lockouts as appropriate while working on this equipment. Where air pressure is required for cleaning, use a low air pressure (30 psi or less) air source. Eye protection (goggles or face shield) must be used when utilizing compressed air for cleaning. Check to ensure all employees are clear of the machine. Report safety deficiencies to your supervisor immediately upon detection.

AA-1

2. **CHECK FOR MAIL. -** Look for loose mail while 2.5 performing activities.

Frequency Code: -M-Q--A-

#### WARNING

Eye protection (goggles or face shield) must be worn when using compressed air, steam, or a high pressure cleaner/washer device for cleaning.

CH-1 TOWPIN CHAIN 3. **CLEAN CHAIN. -** Clean chain as follows:

min per 10. ft.

min

7

7

7

Frequency Code: 1. Clean chain with steam or high pressure cleaner/washer device. Run chain at least one (1) complete cycle.

2. Remove foreign material by blowing or vacuuming.

Frequency Code: -M-Q--A- 4. **LUBRICATE CHAIN. -** With equipment operating, pour GL-3 slowly over return strand of chain. Two (2) complete turns.

min per 10 ft.

U.S. Postal Service	IDENTIFICATION												
Maintenance Checklist	Work Equipment Code Acronym					Class Code		Number		Туре			
	0	3	Т	0	W	٧	Е	Ζ	Ζ	0	9	1	M
Equipment Nomenclature	Equipment Model Bulletin Filename Frequency												
TOWVEYOR TYPE E	S	I HA	ND	LIN	G	M	980	69 <i>A</i>	ΙA	0 9 1 M		-	

Part or Component	Item No.	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time Req'd	Min. Skill Level
DA-3 SIDE FINGER DRIVE WITH MOTOR	5.	CHECK BRAKE With equipment operating, perform the following:  1. Check for proper brake action.	5 min	7
BRAKE Frequency Code:QA-		<ul><li>2. Feel for vibration.</li><li>3. Listen for noise.</li></ul>		
SYSTEM Frequency Code: -M-QA-	6.	<b>POWER DOWN AND LOCKOUT POWER.</b> - Power down the equipment and lockout its electrical power as prescribed by the procedures contained in, or locally developed in accordance with, the current Maintenance Management Order (MMO) providing lockout/restore procedures.	1 min	7
Frequency Code: -M-QA-	7.	<b>REMOVE COVER PLATES</b> Remove cover plates. Erect barricades around open pits.	20 min	7

## WARNING

Eye protection (goggles or face shield) must be worn when using compressed air for cleaning.

Frequency Code: QA-	8.	<b>CHECK CHAIN.</b> - Check chain for bent, cracked, or excessively worn links.	1 min per 10 ft.	7
CO-1 CROSS OVER BOX	9.	CLEAN, CHECK AND LUBRICATE CROSS OVER BOX Clean/check/lubricate cross over box.	15 min	7
Frequency Code: QA-				

U.S. Postal Service	IDENTIFICATION												
Maintenance Checklist		ork ode	Equipment Acronym					Class Code		Number			Туре
	0	3	Т	0	W	٧	Ε	Ζ	Ζ	0	9	2	M
Equipment Nomenclature	Equ	iipme	nt Mc	del		Bull	etin F	ilena	me	Frequency			
TOWVEYOR TYPE E	S	I HA	ND	LIN	G	M	980	69A	Α		Frequency <b>ALL</b>		

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
· ·			Rea'd	Level

## WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

CS-1 CONTAINER SENSORS	10.	CLEAN PIT, SWITCH HOUSING, AND ACTUATOR ARM With disconnect locked out, perform the following:	10 min	7		
Frequency		<ol> <li>Clean dirt and accumulated material from pit.</li> </ol>				
Code: QA-		<ol><li>Clean switch housing and actuator arm with solvent.</li></ol>				
Frequency Code: QA-	11.	CHECK SWITCH AND ACTUATOR ARM Look for proper positioning and secure mounting of switch and actuator arm.	1 min	7		
Frequency Code:	12.	<b>LUBRICATE AND CHECK PIVOT POINT</b> Lubricate and check pivot point as follows:				
QA-		Lubricate pivot point.				
		<ol><li>Operate by hand to see if it is sluggish or binding.</li></ol>				
		3. Check for damage.				
Frequency Code: QA-	13.	<b>CHECK SWITCH MOUNTING</b> Check switch mounting and for freedom of movement in direction of chain travel.	2 min	7		
DA-3 SIDE FINGER DRIVE WITH	14. CHECK CHAIN LUBRICANT LEVEL Check challubricant level and adjust valve as follows:		10 min	7		
MOTOR BRAKE		<ol> <li>Check level of lubricant in chain lubricator. Refill with GL-3.</li> </ol>				
Frequency Code: -M-QA-		<ol> <li>Adjust valve on oil container to provide small steady stream to chain for two complete passes. Nozzle should be over center of chain.</li> </ol>				

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Maintenance Checklist		Vork Equipment code Acronym				Class Code		Number			Туре		
	0	3	Т	0	W	٧	Е	Ζ	Ζ	0	9	1	M
Equipment Nomenclature	Equ	iipme	nt Mo	del		Bull	etin F	ilena	me	Frequency			
TOWVEYOR TYPE E	SI HANDLING			M98069AA					•				

Part or Component	Item No.	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time Req'd	Min. Skill Level
Frequency Code: QA-	15.	CHECK CHAIN ADJUSTMENT Check chain for proper adjustment. Adjust if necessary at take-up screws on drive assembly.	3 min	7
Frequency Code: QA-	16.	CLEAN AND CHECK CRITICAL SPEED SWITCH Clean and check critical speed switch.	5 min	7
Frequency Code: QA-	17.	<b>CLEAN AND CHECK COUPLING</b> Clean and check coupling as follows:	10 min	7
QA-		1. Clean and check coupling.		
		2. Wrench test set screws.		
		3. Feel keys for tightness.		
Frequency Code: QA-	18.	<b>LUBRICATE GEAR REDUCER.</b> - Add grease to gear reducer. Grease may be applied through a grease nipple provided on the top of the high speed end shield. Amount added should be equal to approximately 1/3 of normal fill.	20 min	7

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Maintenance Checklist		Work Equipment Code Acronym						Class Code		lumb	Туре		
	0	3	T	0	W	٧	Е	Ζ	Ζ	0	9	2	M
Equipment Nomenclature	Equ	iipme	nt Mo	del		Bull	etin F	ilena	me	Frequency			
TOWVEYOR TYPE E	S	SI HANDLING			M98069AA				ALL			-	

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
·			Req'd	Level

## WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE (Cont.)	19.	<ul> <li>CHECK AND CLEAN SPROCKET Check and clean sprocket as follows:</li> <li>1. Check sprocket for wear and alignment.</li> <li>2. Wrench test set screws.</li> <li>3. Clean sprocket with solvent and rags.</li> </ul>	10 min	7
Frequency Code: QA-		3. Glean sprocket with solvent and rags.		
Frequency Code: A-	20.	LUBRICATE MOTOR Remove grease relief plug. For motors 1/2 HP and over, apply 2 pumps of GR-2.  WARNING  Be cautious when working around or on equipment when power has been applied.	4 min	7
SYSTEM Frequency Code:A-	21.	<b>RESTORE EQUIPMENT TO SERVICE.</b> - Restore equipment to service as prescribed by the procedures contained in, or locally developed in accordance with, the current Maintenance Management Order (MMO) providing lockout/restore procedures.	3 min	All
Frequency Code: A-	22.	RUN MOTOR Run motor for one minute	1 min	7

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Maintenance Checklist		Work Equipment Code Acronym					Class Code		Number			Туре	
	0	3	Т	0	W	٧	Е	Ζ	Ζ	0	9	1	M
Equipment Nomenclature	Equ	iipme	nt Mo	del		Bull	etin F	ilena	me	Frequency			
TOWVEYOR TYPE E	S	SI HANDLING			M98069AA				ALL			-	

Part or Component	Item No.	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time Req'd	Min. Skill Level
SYSTEM Frequency Code:A-	23.	<b>POWER DOWN AND LOCKOUT POWER.</b> - Power down the equipment and lockout its electrical power as prescribed by the procedures contained in, or locally developed in accordance with, the current Maintenance Management Order (MMO) providing lockout/restore procedures.	1 min	7
DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE	24.	<b>REPLACE RELIEF PLUG</b> Replace motor grease relief plug.	1 min	7
Frequency Code: A-				
Frequency Code: A-	25.	<b>LUBRICATE COUPLING</b> Drain and refill coupling with same quantity HY-1 lubricant.	20 min	7
Frequency Code: A-	26.	<b>CHECK LUBRICANT ON SHAFT BEARINGS</b> Check bearings for adequate lubricant. Apply new lubricant as necessary use lubricant GR-2	30 min	7
Frequency Code: QA-	27.	CLEAN DRIVE PIT Clean drive pit.	30 min	7
Frequency Code: QA-	28.	CHECK AND LUBRICATE BROKEN CHAIN SWITCH Check and lubricate broken chain switch as follows:  1. Check broken chain switch for secure mount	3 min	7

- and freedom of movement.
- 2. Lubricate pivot points with HY-1.

U.S. Postal Service						IDE	IDENTIFICATION								
Maintenance Checklist		Work Equipment Code Acronym							Number			Туре			
	0	3	Т	0	W	٧	Ε	Ζ	Ζ	0	0 9 2		M		
Equipment Nomenclature	Equ	iipme	nt Mc	del		Bull	etin F	ilena	me	Frequency					
TOWVEYOR TYPE E			ND	LIN	G	M	980	69A	Α			ALL			

Part or Component	Item No.	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time Req'd	Min. Skill Level
DA-3 SIDE FINGER DRIVE WITH MOTOR BRAKE (cont.) Frequency Code: -M-QA-	29.	CHECK V-BELTS AND SHEAVES Check belts and sheaves as follows:  1. Check V-belts and sheaves for wear and alignment.  2. Check sheaves set screws and belt tension.	2 min	7
Frequency Code: -M-QA-	30.	<b>CLEAN V-BELT AND SHEAVES</b> Clean foreign material from belts and sheaves by wiping with clean rags	4 min	7
PD-1 EMPTY PUSHER SENSOR	31.	CLEAN EPD PIT Clean dirt and debris from EPD pit.	10 min	7
Frequency Code: QA-				
Frequency Code: QA-	32.	CHECK PHOTOCELL LENS, HOUSING, AND REFLECTOR Check photocell housings, lens, and reflector.	2 min	7

U.S. Postal Service						IDE	NTIF	ICAT	ION				
Maintenance Checklist		Work Equipment Code Acronym					Class Code		Number			Туре	
	0	3	Т	0	W	٧	Е	Ζ	Ζ	0	9	1	M
Equipment Nomenclature	Equ	iipme	nt Mo	del		Bull	etin F	ilena	me	Frequency			
TOWVEYOR TYPE E	S	SI HANDLING			M98069AA				ALL			-	

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
·			Req'd	Level

## WARNING

Discard solvent soaked materials according to local procedures to prevent spontaneous combustion.

PS-1 ACCUMULA- TION STOP Frequency Code: QA-	33.	<ul> <li>CLEAN STOP PIT AND SWITCH HOUSING Clean stop pit and switch housing as follows:</li> <li>1. Remove dirt and accumulated debris from accumulation stop pit.</li> <li>2. Clean switch housing using solvent and rags.</li> </ul>	10 min	7
		3. Check operation by unlatching switch blade.		
Frequency Code: QA-	34.	CLEAN AND LUBRICATE CENTER SLIDE ASSEMBLY Clean and grease center slide assembly (4) pivots.	2 min	7
Frequency Code: QA-	35.	<b>LUBRICATE SOLENOID LINKAGE</b> Lightly lubricate all linkage and pivot points on solenoid.	2 min	7
Frequency Code: QA-	36.	CLEAN LIMIT SWITCH HOUSING AND ACTUATOR Clean limit switch housing and actuator as follows:  1. Clean limit switch housing and actuator with solvent.  2. Check mounting and freedom of movement in direction of chain travel.	10 min	7
AT-1 TRACK Frequency Code: -M-QA-	37.	CHECK TRACK Check entire length of track for loose wear strips	1 min/ 50 ft.	7

U.S. Postal Service			IDENTIFICATION										
Maintenance Checklist	Work Code		Equipme Acrony					Class Code		Number		Туре	
	0	3	Т	0	W	٧	Е	Ζ	Ζ	0	9	2	M
Equipment Nomenclature	Equipment Model			Bulletin Filename			Frequency						
TOWVEYOR TYPE E	S	I HA	ND	LIN	G	M	980	69A	NΑ	ALL		-	

Part or	Item	Task Statement and Instruction	Est.	Min.
Component	No.	(Comply with all current safety precautions)	Time	Skill
			Req'd	Level

ZZ-1 ROUTE COMPLE-TION

38. **REPLACE COVER PLATES. -** Replace all cover plates 20

7

min

Frequency Code:

-M-Q--A-

CLEAN-UP

Frequency Code: -M-Q--A-

39. **CLEAN-UP.** - Ensure all tools, lubricants, rags, etc., are 3 ΑII removed from the work area. Report all deficiencies to your supervisor.

#### WARNING

Be cautious when working around or on equipment when power has been applied.

SYSTEM

Frequency Code: -M-Q--A-

RESTORE EQUIPMENT TO SERVICE. - Restore 40. 3 ΑII equipment to service as prescribed by the procedures min contained in, or locally developed in accordance with, the Maintenance Management Order (MMO) current providing lockout/restore procedures.

START-UP

41. START-UP. - Perform normal start-up procedures as follows:

5 ΑII min

Frequency Code:

-M-Q--A-

- Start or preset equipment.
- Check for proper operation. 2.
- Report all deficiencies to your supervisor in order to initiate any necessary work orders to make necessary repairs, or to remove excessive debris.