

OPTION REMOCON

Remote Control Operation Check Procedure 1

Remote Control Operation Check Procedure 1

Check the operation of the paired Option Remote Control.

1. With your smartphone out of range, or with the Z-GUARD app's AUTO • MANUAL button set to OFF (button in grayed-out state), stand near the vehicle you want to register.
2. Press the "Pairing (Registration) Button"  on the Option Remote Control once.
3. The operation indicator LED will light up.
4. If authentication with the vehicle (Z-GUARD main unit) is successful (Z-GUARD OFF), the LED will turn blue.
5. Perform the following operations according to the color of the operation indicator LED.
 - If the LED is blue (flashing) • • • Start the engine (for Z-GUARD-1)
 - If the LED is blue (flashing) • • • Lock / Unlock the doors of the vehicle and disarm / arm the smart key (for Z-GUARD-3)
6. If the operation indicator LED lights up, the Z-GUARD ON (Security ON) status.

Note: If the LED does not light up when you operate the remote control, or if an error occurs after the button is pressed, repeatedly press the button until the LED goes off, then try the operation again.
(Insufficient engine start/stop operation, door lock/unlock operation)

OPTION REMOCON

Remote Control Operation Check Procedure 2

Remote Control Operation Check Procedure 2

