## **MaxAir Technical - Zone Types**


MaxAir supports nodes based on their type, these types define the basic capability of the zone:

- A node which is associated with both a sensor and a system controller relay
- A node which is associated with only a sensor
- A node which is associated with only a system controller relay
- A node which is not associated with either a sensor or system controller relay


A number of Zone Types are pre-defined:

- Heating has both a temperature sensor and a system controller relay
- Water has both a temperature sensor and a system controller relay
- Immersion has a temperature sensor
- Switch has system controller relay
- HVAC has both a temperature sensor and system controller relays
- Humidity has a humidity sensor
- Binary has a ON/OFF sensor

The currently defined Zone Types can be viewed from the 'Zone Type' menu option in the 'Settings/Node and Zone Configuration' menu.



Zone Types can be deleted by clicking on the 'trash' icon or addition ones added by clicking on the 'Add Type' button.



Enter a name for the new Zone the and select the appropriate 'Category' from the dropdown list, finally click on the 'Save' button.