
Setup Guide - Schedules

The example configuration has both a Central Heating and Hot Water zone, in the case of HVAC systems, there will only be a single HVAC zone.



MaxAir - Smart Thermostat 0.1 - Build Beta 4.0

© BrainMax 2020. All Rights Reserved

Click on the toolbar clock icon to configure schedules.




Click on + or 'Add Schedule' Or Click on an existing schedule to edit.

The Add or Edit schedule screen will be presented, the example below shows:

- An enabled schedule
- Operated Monday to Friday
- Titled Weekdays AM
- Operated between 0630 hours and 0930 hours
- Controls both the Central Heating and Hot Water Zones
- Uses 40°C as the Hot Water Zone cut-off temperature
- Uses 19.5°C as the Central Heating Zone cut-off temperature

Coop Start Feature

Coop Start schedule won't start Zone heating if Boiler is not already running. If Boiler is running and temperature is below setpoint minus deadband, schedule will start the Zone heating. After starting it operates as any other schedule, and will stop the Zone heating when setpoint temperature is reached.



Once configured, click on the 'Submit' button to save the schedule.

Lamp Schedules

In the case of 'Lamp' schedules, the Sunset time from the Weather data can be used as the start time for the schedule, an optional offset can be applied. For the example below the start time will be the sunset time minus forty-five minutes.

Note: Set the 'Start Time' to be after the expected Sunset time, but less than the 'End Time'.

