

## **USED GPIO PINS:**

GPIO07 (CE1) GPIO08 (CE0)

**GPIO16** 

**GPIO18** 

**GPIO19** 


**GPIO20** 

**GPIO21** 


**GPIO23** 

GPIO24

**GPIO25** 



## **Current Sense Circuit**



<sup>\*\*</sup> Load resistor may change based on signal from coil.