

In this section



KB-00000313

CHECK-IN

OCTOPLANT INFO

READING TIME: 8 MIN

CREATED: 2024-10-31

LAST UPDATED: 2026-07-30

AVAILABLE IN EN DE ES ZH

AutoCheckIn allows you to check in components via the command line and, if necessary, create a new Version. Master data and the component type can be changed via settings in the configuration file.

The following Command must be entered in the command line:

```
C:\Program Files (x86)\vdogClient\VDogAutoCheckIn.exe /at:c "/rd:{vdClientArchive}" [/account:{User}]
```

The necessary parameters and values for the command line call can be found in the following table.

Parameter	Description
/rd:{ClientArchive}	Fully qualified path to the client archive
/account:{user}	Name of the user who performs the Check-In Only required if the user name is not transferred in the configuration file.
/domain:{domain}	Domain of the user Only required if the user name is transferred via the Command line.
/password: {password}	User's password Only required if the user name is transferred via the command line.
/CFile: {configuration file}	Fully qualified path to the configuration file

Parameter	Description
/JobConfig	Indicates that a Job is to be created > Only required if only the job configuration is to be changed and no component is to be created, no versioning and no Check-In is to be performed.

CONFIGURATION FILE

To check in a component via the command line, to version it or to create a job, an INI file is required. Below you will find a list of sections, keys and values used in the configuration file.

Info

If a value has leading or trailing spaces, it must be enclosed in quotation marks in the configuration file. If a default value is specified for a key, this key does not have to be transferred in the configuration file.

USER

In the [User] section, the following keys can be configured:

Key	Description	Values	Default
Account	Name of the user who carries out the Check-In. Only required if the user name is not transferred via the command line.		Empty string
Domain	Domain of the user. Only required if the user name is also transferred in the configuration file.		Empty string
Password	Password of the user. Only required if the user name is also transferred in the configuration file		Empty string
PasswordMode	Specifies how the password is to be handled. Only required if the user name is	0: The password is treated as unencrypted and transferred directly. 2: The key is ignored and the	

Key	Description	Values	Default
	also transferred in the configuration file.	password must be entered via the command line.	

COMPONENT

In the [Component] section, the following keys can be configured:

Key	Description
Dir	Relative path to the component. There is a backslash at the beginning, not at the end.
ComponentTypeId	Valid component type ID with which the existing component type ID is replaced.

CREATECOMPONENT

In the [CreateComponent] section, the following keys can be configured:

Key	Description
ComponentTypeId	If the component does not yet exist, it can be created. The prerequisite for this is that a valid component type ID has been stored, which is then used as a template. If both the ComponentTypeId and ComponentId keys exist, the ComponentId key is always used (i.e. if you have entered a value for the ComponentId key, you do not need to enter a value for the ComponentTypeId key).
ComponentId	If the component does not yet exist, it can be created. The prerequisite for this is that a valid component ID has been stored, which is then used as a template. If both the ComponentTypeId and ComponentId keys exist, the ComponentId key is always used (i.e. if you have entered a value for the ComponentId key, you do not need to enter a value for the ComponentTypeId key).
WorkingDir	Specification of an external working directory
Source	The working directory can be filled directly with files. The source is either a directory or a ZIP file. If there is already data in the working directory (e.g. in the case of reusing a component or importing a directory structure), the component is not created and the entire AutoCheckIn process fails.

VERSION

In the [Version] section, the following keys can be configured:

Key	Description	Values	Default
Enabled	Specifies whether a version should be created before Check-In.	Y: A new version is created. N: No new version is created.	N
HversionUserDefined	Version number of the version that may be created.		Empty string
Comment	Comment for this version. A line break is displayed with <code>
</code> .		Empty string
ChangeReason	Change reason for this version. A line break is displayed with <code>
</code> .		Empty string
WithoutComparison	Specifies whether a comparison is to be performed. If no comparison is performed (Y), a new version is created even if there are no differences to the previous version.	Y: No Comparison is performed. N: The comparison is performed.	N
SilentMode	Specifies whether VDogAutoCheckIn.exe may open a message during comparison.	Y: Messages can be opened. N: No messages are opened.	N
UserId	User ID under which the version is to be generated. Format: {ID with 32 characters}.		The logged-in user
ComputerName	Name of the computer on which the version is to be generated.		The name of the computer on which the VDogCheckIn is running
TimeStamp	Timestamp on which the version was created.		The current timestamp

Key	Description	Values	Default
	Format: {YYYYMMDD HHMMSS}.		
TagName	Tag to be assigned to the generated version. This key is optional.		
CreateTagIfNotAlreadyExists	Specifies whether a tag is created if no tag exists for the version.	Y: The tag is created if it does not yet exist. N: Only existing Tags are linked to the created Version. If the tag does not exist, the application fails. The generated version remains without a tag.	
TagComment	If a new tag is created, a comment can be added to the tag here.		

CHECKIN

In the [CheckIn] section, the following keys can be configured:

Key	Description	Values	Default
ReleaseAfterCheckIn	Specifies whether the version of the component should be released after Check-In.	Y: The version is released. N: The version is not released.	Y
SilentMode	Specifies whether VDogAutoCheckIn.exe may open a message during Check-In.	Y: Messages can be opened. N: No messages are opened.	N
IgnoreProjectDatalsNot Versioned	Specifies whether VDogAutoCheckIn.exe should ignore non-versioned project	Y: If there are non-versioned project changes in the working directory, a warning appears. Versions	N

Key	Description	Values	Default
	changes in the editor during Check-In.	that have already been saved are checked in. N: If there are non-versioned project changes in the working directory, an error message appears. The Check-In is canceled. Versions that have already been saved are not checked in.	

MASTERDATA

In the [MasterData] section, the following keys can be configured:

Key	Description	Values	Default
Data{1..10}	Specify the master data to be changed. The following applies here: If you enter a value, this value is entered in the master data field. To clear the master data field, do not enter a value.		Nothing is changed by default.

RESULT

In the [Result] section, the following keys can be configured:

Key	Description
ErrorText{0..n}	Error message(s) in case of error
ErrorCode{0..n}	Error code(s) in case of error. Format: {Display type}{Space}{Error code in hexadecimal notation} Display type 0: Error code is displayed as an unsigned decimal number. Display type 1: Error code is displayed as a signed decimal number. Display type 2: Error code is displayed as a hexadecimal number.
HVersion	Version number of the created version (if a version was created).
JobId	ID of the created job. Only required if the keys in the [JobConfig] section are used.

EXAMPLES

TRANSFER OF THE USER AND PASSWORD IN THE CALL

Command line call:

```
C:\Programs\vdogClient\VDogAutoCheckIn.exe /at:c "/rd:D:\vdClientArchive" /account:{User} /domain:Te
```

Configuration file AutoCheckIn.ini:

```
[Component]
```

```
Dir=\Factory 1\Hall 1\Area 1\110 S7
```

TRANSFER OF THE USER AND PASSWORD IN THE CONFIGURATION FILE

Command line call:

```
C:\Programs\vdogClient\VDogAutoCheckIn.exe /at:c"/rd:D:\vdClientArchive" /CFile:d:\AutoCheckIn.ini
```

Configuration file AutoCheckIn.ini:

```
[User]
```

```
Account={User}
```

```
Domain={Testdomain}
```

```
Password={Password}
```

```
[Component]
```

```
Dir=\Werk 1\Halle 1\Bereich 1\110 S7
```

PASSING THE PASSWORD IN THE CALL AND THE USER IN THE CONFIGURATION FILE

Command line call:

```
C:\Programs\vdogClient\VDogAutoCheckIn.exe /at:c "/rd:D:\vdClientArchive" /password:{password} /CFile
```

Configuration file AutoCheckIn.ini:

```
[User]
```

```
Account=User
```

```
Domain=Testdomain
```

```
PasswordMode=2
```

```
[Component]
```

```
Dir=\Werk 1\Halle 1\Area 1\110 S7
```

APPLICATION EXAMPLE: CREATING A NEW COMPONENT

Batch file:

```
@echo off
set VDTOOL=C:\Program Files (x86)\vdogClient\VDogAutoCheckIn.exe
set CLIENTARCHIVE=D:\vdClientArchive
set PASSWD=*****
set USERNAME=Administrator
set CFGFILE=CheckInTest.ini
SET mypath=%~dp0
set CFGFILE=%mypath%CFGFILE%
echo [ * ] Start Check-In
"%VDTOOL%" "/AT:C" "/RD:%CLIENTARCHIVE%" "/CFile:%CFGFILE%" "/Password:%PASSWD%" "/Account:%USERNAME%"
echo [ * ] Check-In finished (%ERRORLEVEL%)
pause
```

Configuration file CheckInTest.ini:

```
[Component]
```

```
Dir=\Test\NewComponent
```

```
[CreateComponent]
```

```
// Binary
```

```
ComponentTypeId=D565D656350A428E8B286F834C4F74BA
```

APPLICATION EXAMPLE: CUSTOMIZING THE MASTER DATA FOR SEVERAL COMPONENTS AT THE SAME TIME

File CheckIn.bat

```
@echo off
set VDTOOL=C:\Program Files (x86)\vdogClient\VDogAutoCheckIn.exe
set CLIENTARCHIVE=D:\vdClientArchive
set PASSWD=*****
set USERNAME=Administrator
set CFGFILE=CheckInTest.ini
SET mypath=%~dp0
set CFGFILE=%mypath%CFGFILE%
echo [ * ] Start Check-In
type %CFGFILE% > %CFGFILE%.cfg
echo [Component] >> %CFGFILE%.cfg
```



```
echo dir=%*>> %CFGFILE%.cfg
"%VDT00L%" "/AT:C" "/RD:%CLIENTARCHIVE%" "/CFile:%CFGFILE%.cfg" "/Password:%PASSWD%" "/Account:%USERI
echo [ * ] Check-In has finished (%ERRORLEVEL%)
```

File CheckIn.ini

```
[Version]
Enabled=Y
WithoutComparison=Y
[MasterData]
Data1="Offline"
```

File Loop.bat

```
for /F "tokens=*" %A in (myfile.txt) do checkin.bat %A
```

File myfile.txt

```
\Plant 1\Hall 1\Area 1\110 S7
\Plant 1\Hall 1\Area 2\Documentation\Book list
\Plant 1\Hall 1\Area 2\Documentation\CADD
```

Related topics

- [Creating and configuring jobs](#)
- [UserClient -> Creating new version and performing a Check-In](#)

WAS THIS ARTICLE HELPFUL?

Please help us to continuously improve by providing feedback

 Yes

 No

On this page

WANT TO CHAT?

Asking questions is easy. Just start chatting with our chatbot.



START CHATTING

NEED SUPPORT?

Can't find the answer you're looking for? Don't worry, we're here to help!

OPEN SERVICE REQUEST