

Time Start Setup

Note: 2 way LCD remote required. This option will allow the user to set a predetermined time to remote start on the 2 way LCD remote. Once the timer mode is activated it will start the countdown timer on the Control Unit based on the difference of time between what the remote clock is set to and the timer mode time is set to. I.e. remote time reads 7:00pm and timer mode time is set to 7:00 am the control unit will activate the timer mode to go for 12hours before it starts. Note: it is important that the remote time is as accurate as possible when activating the timer mode to ensure that it will start at the desired time. If there is any interaction with the vehicle or system after timer mode has been activated it will cancel the timer.

Step 1 - Controller Option Table Settings

Option 2-13: Enables the time, repeat and temp starting features

- **Setting 1** - Off (default)
- **Setting 2** - On

Option 2-06: Activation style

- **Setting 3** - Reservation (Runtime is 2-07 setting)

Note: 2 way LCD remote required.

Step 2 - User Operation

On the LCD remote the start time must be set, then the user would need to activate the timer mode on the system.

Once the controller has been programmed with behaviours the feature then can be turn on and off. To activate this feature on or off:

- Press and release "unlock" + "key" buttons, press and release "II" + "IV" buttons or press "F" button twice then "unlock"
- One parking light flash for timer mode on
- Two parking light flashes for timer mode off
- Three parking light flashes for system not programmed

These features must be activated by remote when the feature is to be used

These will work for 24 hours or until ignition is turned on with key