

Details



Below are all items available on the current component location. Locate the highlighted items in red on the image by moving the mouse over the items in the tables below.

Starter Cable Wire Harness	
T1	
Engine Wire Harness	
CKP Sensor 3P Connector	
Turbocharger Bypass Control Solenoid Valve 2P Connector	
Alternator 1P Connector	
T4	
Throttle Body 6P Connector	
No. 1 Injector 2P Connector	
No. 2 Injector 2P Connector	
No. 3 Injector 2P Connector	
No. 4 Injector 2P Connector	
Knock Sensor 2P Connector	
Junction Connector (C006)	
Junction Connector (C007)	
Starter 1P Connector	
Rocker Arm Oil Pressure Sensor 3P Connector	
Turbocharger Boost Sensor 3P Connector	
Fuel Rail Pressure Sensor 5P Connector	
MAF Sensor/IAT Sensor 2 4P Connector	
VTC Oil Control Solenoid Valve A 2P Connector	
Rocker Arm Oil Pressure Switch 2P Connector	
Rocker Arm Oil Control Solenoid 2P Connector	

Components
Alternator
CKP Sensor
Fuel Rail Pressure Sensor
Knock Sensor
MAF Sensor/IAT Sensor 2
No. 1 Injector
No. 2 Injector
No. 3 Injector
No. 4 Injector
Rocker Arm Oil Control Solenoid
Rocker Arm Oil Pressure Sensor
Rocker Arm Oil Pressure Switch
Starter
Throttle Body
Turbocharger Boost Sensor
Turbocharger Bypass Control Solenoid Valve
VTC Oil Control Solenoid Valve A

Connectors
T1