

# Passive Arming Setup

Automated locking if a programmed amount of time passes after closing a door without receiving an arm command

## Step 1 - Controller Option Table Settings

**Option 1-08** will control the passive arming/locking behaviours.

- **Setting 1** Off: (default)
- **Setting 2** Passive locking with passive arming: This option, when passive is activated will send lock/arm outputs to lock/arm the control unit 30 seconds after the last zone is closed.
- **Setting 3** No lock output with Passive arm: This option, when passive arm feature is activated, will NOT send the lock command one the control unit has passively armed itself.

Door trigger required for proper operation.

## Step 2 - User Operation

Once the controller has been programmed with behaviours the feature then can be turn on and off. To cycle this feature on or off:

- Press and release "unlock" + "trunk" buttons or press and release "II" + "III" buttons
- One parking light flash for on
- Two parking light flashes for off

The system should lock the vehicle 30 seconds after the door closes.

The control unit will flash the parking lights and chirp the siren 1 time every 10 seconds 3 times total as a warning that it is going to arm itself.