

24 hour repeat with cold starting

24 hour repeat starting option is designed to monitor the temperature 24 hours after timer mode is set and start if it is at or below the preset cold start temperature. This process will continue until the user manually starts or remote starts the vehicle.

Step 1 - Controller Option Table Settings

Option 2-13: Enables the repeat starting features

- **Setting 1** - Off (default)
- **Setting 2** - On

Option 2-06: Sets style of automated start

- **Setting 4** - 24 hour repeat with cold starting

Option 2-08: Sets cold start temperature

- **Setting 1** - 14°F/-10°C
- **Setting 2** - -4°F/-20°C
- **Setting 3** - 23°F/-5°C
- **Setting 4** - 5°F/-15°C

Step 2 - User Operation

Once the controller has been programmed with behaviours the feature then can be turn on and off. To activate this feature on or off:

- Press and release "unlock" + "key" buttons, press and release "II" + "IV" buttons or press "F" button twice then "unlock" dependant on remote style
- One parking light flash for on
- Two parking light flashes for off
- Three parking light flashes for not programmed

This process will continue until the user manually starts or remote starts the vehicle.