

Voltage Start Setup

Voltage start feature will activate the remote start at a programmed voltage level. The feature will only activate one time with a runtime that of option 2-07.

Step 1 - Controller Option Table Settings

Option 2-13: Enables timer start features

- **Setting 1** - Off (default)
- **Setting 2** - On

Option 2-06: Style of automated starting

- **Setting 3** - Reservation

Option 4-14: Voltage start points

- **Setting 3** - Low battery start at 11.3v
- **Setting 4** - Low battery start at 11.7v

Step 2 - User Operation

Once the controller has been programmed with behaviours the feature then can be turn on and off. To activate this feature on or off:

- Press and release "unlock" + "key" buttons, press and release "II" + "IV" buttons or press "F" button twice then "unlock" dependant on remote style
- One parking light flash for on
- Two parking light flashes for off
- Three parking light flashes for not programmed

This feature must be activated by remote when the feature is to be used. This feature will start the vehicle once with a runtime of option 2-07