1. Engine Coolant - Drain	
2. Engine Cover - Remove	
3. A/C Condenser Fan Shroud Assembly - Remove	
4. Water Bypass Pipe - Move	
5. Turbocharger Inlet Joint Pipe - Remove	
6. TWC Assembly - Remove	
7. Charge Air Cooler Hose - Disconnect	
	NOTE: Remove the necessary part(s).
8. Water Pipe - Move	
9. Oil Feed Pipe - Remove	
10.Turbocharger - Remove	
	NOTE: Do not hold the wastegate control valve rod (A) and the turbocharger wastegate control actuator (B).



11. Charge Air Cooler Pipe - Remove

NOTE: Remove the necessary part(s).

12.Oil Return Pipe - Remove