

Details



Below are all items available on the current component location. Locate the highlighted items in red on the image by moving the mouse over the items in the tables below.

Driver's Door Wire Harness
Driver's Door Lock Actuator/Knob Switch/Key Cylinder Switch 10P Connector
Junction Connector (C011)
Driver's Power Window Motor 6P Connector
Left Power Mirror 14P/4P Connector
Driver's Door Outer Handle 8P Connector
Driver's Door Speaker 2P Connector
Left Front Tweeter 2P Connector
In-line Connector (C107)
Power Window Master Switch 37P Connector
Power Mirror Switch 13P Connector

Components
Driver's Door Lock Actuator/Knob Switch/Key Cylinder Switch
Driver's Door Outer Handle
Driver's Door Speaker
Driver's Power Window Motor
Left Front Tweeter
Left Power Mirror
Power Mirror Switch
Power Window Master Switch

Connectors
Driver's Door Lock Actuator/Knob Switch/Key Cylinder Switch 10P Connector
Junction Connector (C011)
Driver's Power Window Motor 6P Connector
Left Power Mirror 14P/4P Connector
Driver's Door Outer Handle 8P Connector
Driver's Door Speaker 2P Connector
Left Front Tweeter 2P Connector
In-line Connector (C107)
Power Window Master Switch 37P Connector
Power Mirror Switch 13P Connector