

## Details



<b>Body Control Module Connector C (28P)</b>
<b>Body Control Module Connector D (40P)</b>
<b>Body Control Module Connector E (24P)</b>
<b>Body Control Module Connector F (36P)</b>
Under-Dash Fuse/Relay Box Connector F (12P)
<b>Under-Dash Fuse/Relay Box Connector E (18P)</b>
<b>Under-Dash Fuse/Relay Box Connector G (20P)</b>
<b>Under-Dash Fuse/Relay Box Connector D (4P)</b>
<b>In-line Connector (C110)</b>
<b>In-line Connector (C106)</b>
<b>In-line Connector (C112)</b>
<b>In-line Connector (C131)</b>
<b>Electric Steering Lock 12P Connector</b>
<b>In-Car Temperature Sensor 2P Connector</b>
<b>In-line Connector (C107)</b>
<b>In-line Connector (C108)</b>
In-line Connector (C105)
<b>In-line Connector (C132)</b>
<b>Driver's Junction B Connector B (4P)</b>
Driver's Junction B Connector A (4P)
<b>Driver's Junction B Connector C (4P)</b>
Driver's Junction B Connector D (4P)
Driver's Junction B Connector E (4P)
Driver's Junction C Connector B (4P)
Driver's Junction C Connector A (4P)
Driver's Junction C Connector C (4P)
Driver's Junction C Connector D (4P)
Driver's Junction C Connector E (4P)
<b>Junction Connector (C008)</b>
<b>Gauge Control Module Connector B (12P)</b>
<b>Gauge Control Module Connector A (32P)</b>
<b>Engine Start/Stop Switch 10P Connector</b>
<b>Under-Dash Relay Holder</b>
<b>VSA OFF Switch 4P Connector</b>

### Components

<b>ACC Cut Relay</b>
B-CAN Junction
Body Control Module
Cable Reel
<b>CAN Gateway</b>
Combination Light Switch
Driver's Junction B
Driver's Junction C
<b>Electric Steering Lock</b>

### Components

<b>Engine Start/Stop Switch</b>
<b>Gauge Control Module</b>
GPS Antenna
<b>IG2 Cut Relay</b>
<b>In-Car Temperature Sensor</b>
<b>VSA OFF Switch</b>
Wiper/Washer Switch

### Fuse/Relay Boxes

Under-Dash Fuse/Relay Box
---------------------------

### Connectors

Gauge Control Module Connector C (3P)
---------------------------------------

### Grounds

G501
G502