

Auto Relock Setup

This option allows the controller to automatically relock/rearm after it has been disarmed/unlocked. This will only happen if no zones have not been opened.

Step 1 - Controller Option Table Settings

Option 1-10: Controls the auto door lock behaviours.

- **Setting 1** - Off (default)
- **Setting 2** - 30 seconds
- **Setting 3** - 60 seconds
- **Setting 4** - 5 minutes

Note: Door trigger required for proper operation.

Step 2 - User Operation

No user interaction required. Door will relock if a zone is not opened within programmed time.