

# Secure Auxiliary Setup

Secure Aux Output: this feature is designed to prevent accidental activation of the AUX outputs by requiring an additional step when using any 4 button or 2 way LCD remote. The additional step before activating AUX output using any Firstech 4 button or 2 way LCD remote (2way remotes with Roman numeral buttons will require a 0.5 second tap of button IV before activating any of the AUX outputs. 2Way LCD remotes with lock/unlock/trunk/start icons on the buttons use the start button for the same. 1way remotes require the user to hold trunk + start buttons for 2.5 seconds before activating AUX outputs.)

## Step 1 - Controller Option Table Settings

**Option 1-09** Secure auxiliary behaviours.

- **Setting 1** - On: (default) this option will require the user to perform the additional step
- **Setting 2** - Off: this option will disable the additional step required to activate AUX 1 and 2
- **Setting 3** - On while armed: this feature will only require the user to perform the additional override step to activate Aux outputs ONLY WHEN the control unit it is ARMED. While the system is disarmed or unlocked this step is not required.

## Step 2 - User Operation

If Secure Aux has been turned off, the first step of activating the Aux feature would not need to be preformed.