
## DTC Troubleshooting: C0023-F0, C0044-F0, U0416-68, U0416-F8



DTC C0023-F0: Brake Light Drive Relay Circuit Malfunction

DTC C0044-F0: Master Cylinder Pressure Sensor Failure

DTC U0416-68: Brake Actuator Malfunction

DTC U0416-F8: VSA Modulator-Control Unit Malfunction

NOTE:

- Before you troubleshoot, <u>review the general troubleshooting information</u>.
- These DTCs are recorded when the millimeter wave radar receives failure information from the VSA modulator-control unit via the F-CAN.
- If a DTC is recorded again after it is cleared with the HDS, perform a troubleshooting for the VSA system.
- The functions of the integrated driver support system that will be temporarily canceled when this DTC is recorded can be confirmed with the DTC troubleshooting index.

DTC Description	DTC
C0023-F0 Brake Light Drive Relay	
Circuit Malfunction	
C0044-F0 Master Cylinder Pressure	
Sensor Failure	
U0416-68 Brake Actuator Malfunction	
U0416-F8 VSA Modulator-Control Unit	
Malfunction	

DTC (IDAS)

- 1. Problem verification:
  - -1. Turn the vehicle to the ON mode.
  - -2. Clear the DTC with the HDS.

Clear DTCs

- -3. Turn the vehicle to the OFF (LOCK) mode.
- -4. Turn the vehicle to the ON mode, then wait for at least 6 seconds.
- -5. Check for DTCs with the HDS.

DTC Description	DTC
C0023-F0 Brake Light Drive Relay	
Circuit Malfunction	
C0044-F0 Master Cylinder Pressure	
Sensor Failure	
U0416-68 Brake Actuator Malfunction	

DTC Description	DTC
U0416-F8 VSA Modulator-Control Unit	
Malfunction	

## Is DTC C0023-F0, C0044-F0, U0416-68, or U0416-F8 indicated?

- YES The failure is duplicated. <u>Go to the indicated DTC's troubleshooting in the VSA system</u>.■
- NO Intermittent failure, the system is OK at this time. Refer to intermittent failures troubleshooting.■