

## Details



Below are all items available on the current component location. Locate the highlighted items in red on the image by moving the mouse over the items in the tables below.

Left-Rear Electric Parking Brake Actuator Wire Harness
In-line Connector (C118)
Left-Rear Damper Actuator 2P Connector
In-line Connector (C137)
Left-Rear Electric Parking Brake Actuator 2P Connector
Left-Rear Wheel Speed Sensor 2P Connector

Floor Wire Harness
In-line Connector (C118)
Adaptive Damper Control Unit 24P Connector
In-line Connector (C137)
In-line Connector (C134)
<b>In-line Connector (C133)</b>
<b>Junction Connector (C002)</b>
Junction Connector (C003)
<b>Fuel Tank Unit 4P Connector</b>
Rear Interior LF Antenna 2P Connector
<b>Left Side Curtain Airbag Inflator 2P Connector</b>
Left Side Impact Sensor (Second) 2P Connector
<b>Left Rear Relay Holder A</b>
<b>Left Rear Relay Holder B</b>
<b>Left-Rear Acceleration Sensor 3P Connector</b>
<b>Left-Rear Suspension Stroke Sensor 3P Connector</b>
Left Satellite Speaker 2P Connector
Left Rear Door Switch 1P Connector

Components
Adaptive Damper Control Unit
Fuel Tank Unit
Left Rear Door Switch
Left Rear Seat Heater Relay (High)
Left Rear Seat Heater Relay (Low)
Left Satellite Speaker
Left Side Curtain Airbag Inflator
Left Side Impact Sensor (Second)
Left-Rear Acceleration Sensor
Left-Rear Damper Actuator
Left-Rear Electric Parking Brake Actuator
Left-Rear Suspension Stroke Sensor
Left-Rear Wheel Speed Sensor
Rear Interior LF Antenna
Right Rear Seat Heater Relay (High)
Right Rear Seat Heater Relay (Low)

Connectors
In-line Connector (C118)
Left-Rear Damper Actuator 2P Connector
In-line Connector (C137)
Left-Rear Electric Parking Brake Actuator 2P Connector
Left-Rear Wheel Speed Sensor 2P Connector

Grounds
G603