

## Details



Below are all items available on the current component location. Locate the highlighted items in red on the image by moving the mouse over the items in the tables below.

LVDS2 Harness Wire Harness
Gauge Control Module Connector C (3P)
Dashboard Wire Harness
Combination Light Switch 12P Connector
Wiper/Washer Switch 10P Connector
Cable Reel Connector A (20P)
Cable Reel Connector B (4P)
CAN Gateway 12P Connector
B-CAN Junction A Connector A (4P)
B-CAN Junction A Connector B (4P)
B-CAN Junction A Connector C (4P)
B-CAN Junction A Connector D (4P)
B-CAN Junction A Connector E (4P)
Body Control Module Connector G (32P)
<b>Body Control Module Connector A (14P)</b>
Body Control Module Connector B (36P)
Body Control Module Connector C (28P)
Body Control Module Connector D (40P)
Body Control Module Connector E (24P)
Body Control Module Connector F (36P)
Under-Dash Fuse/Relay Box Connector F (12P)
Under-Dash Fuse/Relay Box Connector E (18P)
Under-Dash Fuse/Relay Box Connector G (20P)
Under-Dash Fuse/Relay Box Connector D (4P)
In-line Connector (C110)
In-line Connector (C106)
In-line Connector (C112)
In-line Connector (C131)
Electric Steering Lock 12P Connector
In-Car Temperature Sensor 2P Connector
In-line Connector (C107)
In-line Connector (C108)
In-line Connector (C105)
<b>In-line Connector (C132)</b>
Driver's Junction B Connector B (4P)
Driver's Junction B Connector A (4P)
Driver's Junction B Connector C (4P)
Driver's Junction B Connector D (4P)
Driver's Junction B Connector E (4P)
Driver's Junction C Connector B (4P)
Driver's Junction C Connector A (4P)
Driver's Junction C Connector C (4P)
Driver's Junction C Connector D (4P)
Driver's Junction C Connector E (4P)
Junction Connector (C008)
Gauge Control Module Connector B (12P)
Gauge Control Module Connector A (32P)
Engine Start/Stop Switch 10P Connector
Under-Dash Relay Holder
VSA OFF Switch 4P Connector

## Components

ACC Cut Relay
B-CAN Junction
Body Control Module
Cable Reel
CAN Gateway
Combination Light Switch
Driver's Junction B