AI Data Engine Software User Manual

The software primarily consists of two major databases: a Scenario Management Library and a Trigger Condition Library, along with two key functions: AI-assisted scenario generation and AI-driven scene creation based on user requirements.

1. Initial user interface display:

1. Scenario Management Library Description:

Click on the Scenario Management Library to access the following interface:

The Scenario Management Library primarily consists of a Public Library and a Private Library. The Public Library includes CSAE scenarios and CDA scenarios. Within the Private Library, the Project Library contains generalized scenarios derived from accident data collected in Chongqing over the past five years by the Chongqing university Laboratory.

Process for Creating a New Public/Private Library:

Click the New Library button in the Public or Private Library to create a new public or private library. You can name it as needed, and for private libraries, an access password can be set. For any newly created library, you can click the delete button on the right to remove it.

Similarity Search Process:

Enter any text function or related description, then click Search . The system will recommend scenarios with a high similarity to the input.

Complete Simulation Scenario Process for Observing the Database:

① : Click on the corresponding database card to access the relevant data.

② : Click "Load Scenario for Simulation & Code Generation" to access the following interface.

③ : Click Load Scenario to Memory to access its corresponding physical scenario.

④ : Click Load Scenario to Memory , close its corresponding OS code.

Among these, the above data including the speed and position of the ego vehicle and traffic participants can be modified as needed.

⑤ : Click Run Scenario , close the code generation window, and start the simulation. To avoid data redundancy after saving the code, you can click Delete Code to delete the saved code.

2.Triggering Condition Library.

The Triggering Condition Library serves as a resource for AI to generate complex scenarios through layering and combination.

3. AI Scenario Generation Function.

When using AI features, you need to enter the corresponding model and

its API information in the upper-right corner.

for functions mainly consist of three parts. AI-assisted scenario import, AI scenario generation, and user-defined scenario editing.

① : AI-Assisted Scenario Import Process:

Click AI-Assisted Scenario Import to enter the AI-assisted scenario import function interface.

First, select the threat you wish to add to.

In the scenario description field, you can provide a brief text description of

the scenario. The UI or UI levels below are optional. If the user needs to specify some levels or data, they can fill in the relevant fields; otherwise, the AI will appropriately supplement and generate the scenario based on the description provided.

Then click Upload Scenario to complete the scenario.

Finally, you can click Generate to edit the document or click Upload Scenario to save the scenario.

② : AI Scenario Generation Function Process.

Click Generate Scenario to enter the AI scenario generation function

process.

Users can fill in the text function or scenario description based on actual needs; UI is not are also optional. Click Generate Scenario to generate the logical scenario.

The section ahead displays scenario library scenes recommended by the AI based on the user's description, while the section that follows shows scenes generated by the AI. Click on any scenario card.

Then click Run Scenario to generate the corresponding physical scenario.

Finally, click Save Scenario to save the code, and then click Run Scenario to start the simulation.

③ : Custom Scenario Addition Function Process.

Click Scenario Creation to enter the user-defined scenario addition interface.

Select the appropriate target storage library as needed.

After entering the scenario name and description, upload the corresponding Open Scenario/OpenDrive code file, then click Upload Scenario to save the scenario.

3.System Tools Description

The system tools include an Update Vector Database function. After uploading existing or new scenarios, you can click Update Vector DB to enter the password admin4455, and then proceed to update the vector database. This allows you to search for the desired scenarios in Scenario Management.

4.Administrator Mode

On the UI interface, click Admin Login and enter the password: admin4455 to enter Administrator Mode.