Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER TLM-TR-053		SUBJECT SCHEDULE A			TASK CARD NO. TR-TLD-025-A-TLM
CHA NO N/A	ENG NO N/A				W.O. NO. 2345230
SER NO T99203	HR METER 5374.6	INSP. TYPE SVC	INTERVAL 250 H / 3 MO	EFFECTIVITY TLD-025	PAGE : 1 of 5

GENERAL

This task include check list on daily check, basic check, shortest repetitive interval until 250 service hours.

A. References :

Reference	**Title**
GRS-RM-CK-060	Preventive Maintenance for Baggage Tractor (TR)

B. Fixtures, Tools, Test and Support Equipment

REFERENCE	DESCRIPTION
กล่องเครื่องมือ	1 กล่อง
เครื่องมือพิเศษ	1 ชุด.

C. (onsumables Materials

DESCRIPTION	SPECIFICATION
น้ำมันเครื่อง	9 L.
กรองน้ำมันเครื่อง	1 ชิ้น.

DATE	REPORTED BY	DATE	VERIFIED BY
21/8/26	247476 , 269690	21/08/26.	Chaiwat P. 13020/

Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-053	T99203	TR-TLD-025-A-TLM	2345230	2 of 5

ITEM	DESCRIPTION	PERFORMED BY
	BASIC CHECK (GENERAL&ELECTRICAL SYSTEM)	
	1. Check fuel level	214976
	2. Check engine oil	214976
	3. Tires pressure Rear: 104 Psi, Front: 58 Psi	214978
	4. Check tire treads / clean tire if necessary	214976
	5. Check headlight for normal operation	214976
	6. Check stop light, warning light, rear light, beacon light, etc.	214976
	7. Check all cabin function wiper, roof light	214976
	8. Check horn and backup alarm	214976
	9. Check brake fluid level	214976
	10. Check battery charge	214976
	11. Check wheel nuts torque Front: 88.5 ft.lb (120 N.M), Rear:362 ft. lbs (500 N.M)	214976
	12. Check axle fixation on the leaf springs	214976
	13. Check beacon light for available	214976

Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-053	T99203	TR-TLD-025-A-TLM	2345230	3 of 5

ITEM	DESCRIPTION	PERFORMED BY
	14. Check rear axle oil level	
	15. Check exhaust pipe for leak	
	16. Drian water at the water / fuel separator side	
	250 HOURS	
	1. Check king pins and hub bearing for play	
	2. Parking brake. With parking brake engaged, tractor have to stay parked in position on a 8% slope if tractor is not parking brake cable accordingly	
	3. Alternator belt tighten, if necessary check manufacturer OM for details	
	4. Check hydraulic oil level and refill if necessary	
	5. Inspection engine coolant hoses and transmission oil cooled hoses	
	6. Check brake pads and disk wear, refer to below spreadsheet	
	7. Check brake pedal pivot and spring grease if necessary	
	8. Check abnormal play in the cardan shaft between transmission and rear axle grease the shaft nipples	
	9. Inspect acceleration cable for abnormal wear	

Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-053	T99203	TR-TLD-025-A-TLM	2345230	4 of 5

ITEM	DESCRIPTION	PERFORMED BY
	10. Check front axle toe-in and inspect hub bearing	2A7976
	11. Check brake calipers to detect any abnormal leak	2A7976
	12. Gresae all greasing ports and nipples	2A7976
	13. Check engine hood lock	2A7976
	14. Grease steering swivels	2A7976
	15. Drain and replace engine oil. Check related manufacturer OM manual Every 250hr on Cummins engine. Every 500hr on other engine (Deutz, Perkins)	2A7976

Thai Lion air

PREVENTIVE MAINTENANCE SCHEDULE MONTHLY OF DIESEL TRACTOR TLD 025 A (TR)

GSE NUMBER	SER NO	TASK CARD NO.	W.O. NO.	PAGE :
TLM-TR-053	T99203	TR-TLD-025-A-TLM	2345230	5 of 5

GENERAL

DEFECT FOUND : ☐ Yes ☑ No

RECTIFICATION : N/A

COMPONENT / MATERIAL REQUIRED

NO.	DESCRIPTION	PART NO.	QTY	S/N NO. / BATCH NO. / P.O NO.

☐ Time Critical ☐ Time Sensitive ☐ Frequently Used ☑ Reference

☐ Doc. Level 1 ☐ Doc. Level 2 ☐ Doc. Level 3 ☑ Doc. Level 4

Please use "✓" upon ticking the box.